Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Qorol Fabric Shaver Lint Remover

Qorol Fabric Shaver Lint Remover User Manual

Model: Fabric Shaver Lint Remover

Brand: Qorol

1. Introduction

The Qorol Fabric Shaver Lint Remover is designed to effectively remove lint, fuzz, bobbles, and pills from various fabric types, restoring garments and textiles to a smoother, cleaner appearance. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your fabric shaver to ensure optimal performance and longevity.

2. Product Overview

The Qorol Fabric Shaver features a compact design for easy handling and efficient lint removal. Key components include a honeycomb-like mesh cover, rotating alloy blades, a transparent lint container, and a simple on/off switch.



Figure 2.1: Main view of the Qorol Fabric Shaver Lint Remover, showing its compact design and transparent lint collection chamber.



Figure 2.2: Side view of the fabric shaver, highlighting the ergonomic shape and the power switch.



Figure 2.3: The fabric shaver held in a hand, demonstrating its portable size and comfortable grip.



Figure 2.4: View of the internal 3 rotating alloy blades, designed for durability and efficient lint cutting.



Figure 2.5: Top-down view of the fabric shaver, showing the mesh cover and the lint container.



Figure 2.6: Close-up of the honeycomb-like mesh cover and the underlying blades, illustrating how lint is captured and cut.



Figure 2.7: The fabric shaver positioned next to various fabric types, including woollen skirts, sweaters, coats, plush toys, socks, and bedding sets, demonstrating its versatility.

Features:

- **3 Rotating Washable Alloy Blades:** Designed for durability, resistance to rust, and easy removal of pills and bobbles.
- **Efficient Lint Collection:** Lint and fuzz are cut by the rotor blades and deposited into the thrum storage area.
- **Distance Ring:** Includes a distance ring to prevent damage to delicate fabrics.
- **Battery Operated:** Powered by 2 x AA batteries (not included).
- **Simple Operation:** Easy push-up switch to turn the device on, suitable for all kinds of fabric lint.

3. Setup

Battery Installation:

1. Ensure the device is turned off.
2. Locate the battery compartment cover on the back or bottom of the shaver.
3. Slide or unclip the cover to open the compartment.
4. Insert 2 x AA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
5. Close the battery compartment cover securely.

Note: Batteries are not included with the product.

4. Operation

Using the Fabric Shaver:

1. Lay the fabric flat on a hard, smooth surface. Ensure the fabric is taut to prevent snagging.
2. Push the switch up to turn on the device. The blades will begin to rotate.
3. Gently glide the shaver over the fabric surface in a circular motion or back and forth, applying light pressure. Do not press down firmly.
4. For delicate fabrics, attach the included distance ring to provide an extra layer of protection and prevent direct contact with the blades.
5. Observe the lint and fuzz being drawn into the transparent lint container.
6. Continue until the desired smoothness is achieved.
7. Once finished, push the switch down to turn off the device.

Important Usage Notes:

- Do not use the device as a personal shaver.
- Avoid pressing too hard when using, as this can damage the fabric or the shaver.
- Do not use the fabric shaver on clothes while you are wearing them.

5. Maintenance

Cleaning the Lint Container:

1. Ensure the shaver is turned off.
2. Detach the transparent lint container by sliding it off or unlatching it (refer to the "OPEN" indicator on the device).
3. Empty the collected lint and fuzz into a waste bin.
4. The container can be cleaned with a soft brush or a damp cloth. Ensure it is completely dry before reattaching.
5. Securely reattach the lint container to the main unit.

Cleaning the Blades:

1. With the device off and the lint container removed, gently unscrew or twist the mesh cover to expose the blades.
2. Carefully remove any lint or debris from around the blades using a small brush (often included with the shaver) or a soft cloth.
3. The alloy blades are washable; if necessary, they can be carefully rinsed under water. Ensure they are completely dry before reassembly.
4. Reattach the mesh cover and then the lint container.

Storage:

- If you will not use the fabric shaver for a long period, please take out the batteries to prevent leakage and damage to the device.
- Store the shaver in a cool, dry place, away from direct sunlight and moisture.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	• Batteries are dead or incorrectly inserted. • Power switch is not fully engaged.	• Replace batteries with new ones, ensuring correct polarity. • Ensure the power switch is pushed completely to the "ON" position.
Not removing lint effectively.	• Lint container is full. • Blades are dull or clogged with lint. • Mesh cover is damaged or clogged. • Insufficient pressure or incorrect angle.	• Empty the lint container. • Clean the blades and mesh cover. Consider replacing blades if excessively dull (replacement blades not typically included, contact support). • Ensure the mesh cover is clean and free of obstructions. • Apply gentle, even pressure and glide smoothly over the fabric.
Lint container falls off easily.	• Container not securely latched. • Wear and tear on latching mechanism.	• Ensure the lint container is fully pushed into place until it clicks or feels secure. • If the issue persists, contact customer support.

7. Specifications

Brand	Qorol
Model	Fabric Shaver Lint Remover
Colour	Purple
Material	Stainless Steel (Blades), Plastic (Handle)
Item Weight	140 g
Package Dimensions	17.4 x 12 x 5.5 cm
Operation Mode	Automatic
Power Source	2 x AA Batteries (Not Included)
UPC	729680722377

8. Safety Information

- Keep out of reach of children and pets.
- Do not immerse the device in water or any other liquid.
- Do not use the shaver on wet or damp fabrics.
- Exercise caution when handling the blades, as they are sharp.
- Do not attempt to disassemble the device beyond what is necessary for cleaning and battery replacement.
- If the device appears damaged or malfunctions, discontinue use immediately.

9. Warranty and Support

Qorol aims to provide high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any product inquiries, technical support, or warranty claims, please contact the retailer or the manufacturer directly through their official website or customer service channels.

© 2024 Qorol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06W57QLQP

More documents and user manuals: **https://manuals.plus/**