Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RMT-24

RMT-24 Replacement Remote Control

INSTRUCTION MANUAL

Product Overview

This RMT-24 replacement remote control is designed for use with various Westinghouse TV models. It offers a direct replacement solution, eliminating the need for complex programming or pairing procedures. Simply insert the required batteries, and the remote is ready for immediate operation.

Key Features

- Direct replacement for original RMT-24 remote.
- No programming or pairing required.
- Compatible with a wide range of Westinghouse TV models.
- Operates on 2x 1.5V AAA Alkaline Batteries (not included).

Setup Guide

Battery Installation

To install batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two (2) AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the correct placement of AAA batteries.

Initial Use

This remote control is pre-programmed and does not require any additional setup. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible Westinghouse TV.

Operating Instructions



Image: Front view of the RMT-24 remote control, displaying its full button layout.

Basic Functions

- **POWER (Red Button):** Turns the TV on or off.
- **MUTE (Green Button):** Mutes or unmutes the TV audio.
- **Number Buttons (0-9):** Directly select channels.
- **SOURCE:** Selects input sources (HDMI, AV, Component, etc.).

- **CH +/-:** Changes channels up or down.
- **VOL +/-:** Adjusts volume up or down.
- **MENU:** Accesses the TV's main menu.
- **Navigation Arrows (Up/Down/Left/Right):** Navigate through menus and options.
- **OK:** Confirms selections in menus.
- **EXIT:** Exits the current menu or function.
- **INFO:** Displays program information.
- **SLEEP:** Sets the sleep timer.
- **MTS:** Selects Multi-channel Television Sound (audio modes).
- **CC:** Activates or deactivates Closed Captions.
- **V-CHIP:** Accesses V-Chip parental control settings.
- **CH.LIST:** Displays the channel list.
- **ASPECT:** Changes the screen aspect ratio.
- **FAV** / **ADD/ERASE** / **FAV+** / **FAV-:**Functions related to favorite channels.

Compatible TV Models

This remote control is compatible with the following Westinghouse TV models:
DW39F1Y1, DW46F1Y2, DW50F1Y1, DWM32H1A1, DWM32H1G1, DWM32H1Y1, DWM40F1A1, DWM40F1Y1, DWM40F1Y1C, DWM40F1Y1-C, DWM40F2G1, DWM40F3G1, DWM42F2G1, DWM48F1A1, DWM48F1G1, DWM48F1Y1, DWM48F1Y1C, DWM48F1Y1-C, DWM50F1Y1, DWM50F3G1, DWM55F1A1, DWM55F1G1, DWM55F1Y1, DWM55F1Y2, DWM55F2Y1, EU50F2G1, EUM24F1G1, EWM24F1Y1, WD24FC1360, WD24FT1360, WD28HC1160, WD32HB1120, WD32HT1360, WD40FX1170, WD40FX1360, WD40FX1400, WD40FX1450, WD50FC1120, WD50FX1120, WD55FC1180, WD55FX1180, WD55FB1530.

Maintenance

Battery Replacement

Replace the batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's finish or internal components.

Troubleshooting

Problem	Solution
Remote not responding.	Check battery orientation and charge. Replace batteries if necessary. Ensure there is a clear line of sight between the remote and the TV's infrared (IR) receiver.

Problem	Solution
Certain buttons not working.	Clean the remote surface around the affected buttons. If the issue persists, the batteries may be low, or the remote may be faulty. Try replacing the batteries first.
Remote works intermittently.	Replace the batteries. Ensure no obstructions are blocking the signal between the remote and the TV. Avoid strong light sources that might interfere with the IR signal.

Product Specifications

- **Model Number:** RMT-24
- **Product Dimensions:** 6 x 2 x 0.5 inches
- **Item Weight:** 0.81 ounces
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Color:** Black
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** Television

Warranty and Support

This product is a replacement remote control. Specific warranty information is typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for details regarding warranty coverage and support.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WD2ZD82

More documents and user manuals: **https://manuals.plus/**