Lasika SW002

Lasika SW002 Digital Watch Instruction Manual

Model: SW002

Introduction

Thank you for choosing the Lasika SW002 Digital Watch. This manual provides detailed instructions to help you understand and utilize all the features of your new watch. Please read this manual carefully before using the watch to ensure proper operation and longevity. Keep this manual for future reference.

Product Overview



Image 1: Front view of the Lasika SW002 Digital Watch. This image shows the watch face with its digital display, indicating time, date, and other function icons. The four control buttons are visible on the sides.

The Lasika SW002 is a robust, multifunction digital watch designed for active lifestyles. It features a durable silicone band, a clear digital display, and is equipped with essential functions such as time, date, alarm, and stopwatch. Its 3ATM water resistance makes it suitable for daily use and various sports activities.

Watch Components



Image 2: Side view of the Lasika SW002 Digital Watch. This image clearly shows the four buttons located on the sides of the watch case, labeled 'LIGHT', 'MODE', 'START', and 'RESET'.

- **LIGHT Button (Top Left):** Activates the backlight for visibility in low-light conditions.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button (Top Right):** Used to start/stop functions or adjust settings.
- **RESET Button (Bottom Right):** Used to reset functions or adjust settings.



Image 3: Back view of the Lasika SW002 Digital Watch. This image displays the stainless steel case back and the texture of the black silicone strap, along with the strap buckle.

Setup

Initial Power-Up and Time Setting

Your Lasika SW002 watch comes with a pre-installed Lithium Metal battery. Upon first use, or after a battery replacement, you may need to set the current time and date.

1. From the normal time display mode, press the**MODE** button repeatedly until the seconds begin to flash. This indicates you are in time setting mode.
2. Press the **RESET** button to cycle through the settings: seconds, hour, minute, month, date, day of the week.
3. Use the **START** button to adjust the flashing value. Pressing it once will increment the value. Hold it down for faster adjustment.
4. Once all settings are correct, press the**MODE** button again to exit the setting mode and return to the normal time display.

Operating Instructions

Mode Selection

Press the **MODE** button to cycle through the watch's functions in the following order:

- Normal Time Display
- Stopwatch Mode
- Alarm Setting Mode

Using the Stopwatch

1. From the normal time display, press the **MODE** button once to enter Stopwatch Mode. The display will show '00:00:00'.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button while the stopwatch is paused to reset it to '00:00:00'.
5. Press the **MODE** button to return to normal time display.

Setting the Alarm

1. From the normal time display, press the **MODE** button twice to enter Alarm Setting Mode. The alarm time will flash.
2. Press the **RESET** button to select between setting the hour and minute.
3. Use the **START** button to adjust the flashing hour or minute value.
4. Once the desired alarm time is set, press the **MODE** button to exit the alarm setting mode.
5. To turn the alarm ON/OFF, in normal time display, press and hold the **START** button and then press the **RESET** button. An alarm icon will appear/disappear to indicate its status.

Using the Backlight

Press the **LIGHT** button (top left) to illuminate the watch display for a few seconds, allowing you to read the time in dark environments.

Water Resistance Information

The Lasika SW002 watch is 3ATM water resistant, meaning it can withstand splashes, rain, and brief immersion in water. However, it is crucial to **NOT press any buttons while the watch is submerged in water**, as this can compromise the water seal and lead to internal damage.

Maintenance

Cleaning

To maintain the appearance and functionality of your watch, regularly wipe the case and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the watch's finish.

Battery Replacement

The watch is powered by a Lithium Metal battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is properly maintained.

Storage

When not in use for extended periods, store your watch in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing it near strong magnetic fields.

Troubleshooting

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Time is incorrect:** Re-set the time following the 'Time Setting' instructions in the Setup section. Ensure the correct AM/PM setting if applicable.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not a feature of this model). If the issue persists, a battery replacement or professional inspection may be required.
- **Water inside the watch:** Immediately take the watch to a professional for inspection and repair to prevent further damage. Avoid pressing buttons when wet.

Specifications

Feature	Detail
Model Number	SW002
Product Dimensions	16.5 x 2.5 x 17.8 cm
Item Weight	50 Grams
Case Diameter	3.5 Inches
Band Material Type	Silicone
Band Colour	Black
Watch Movement Type	Automatic (Digital Module)
Water Resistance	3 ATM (30 meters)
Battery Type	1 Lithium Metal battery (included)

Warranty and Support

Warranty Information

This Lasika SW002 watch comes with a Manufacturer's Warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and what is covered.

Customer Support

For any questions, technical assistance, or warranty claims, please contact the manufacturer or authorized service center:

- **Manufacturer:** North Moon Enterprise Pvt Ltd
- **Address:** 225A, NSC Bose Road, Kolkata 700047
- **Importer:** North Moon Enterprise Pvt Ltd.
- **Importer Address:** 225A, N.S.C Bose Road, Kolkata 700047

- **Contact:** 9874449968
- **Email:** northmoon2012@yahoo.com



Image 4: Lasika SW002 Digital Watch in its retail packaging. The watch is presented in a red box, indicating how the product is typically received.

© 2023 Lasika. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question