Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit GA667WJSA

ZdalaMit GA667WJSA Replacement Remote Control for Sharp TV User Manual

Model: GA667WJSA

Introduction

This manual provides instructions for the ZdalaMit GA667WJSA replacement remote control, designed for use with various Sharp TV models. This remote control offers a direct replacement experience, requiring no programming or pairing for most compatible televisions. Simply install batteries to begin operation.

Setup: Battery Installation

To prepare your remote control for use, follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) 1.5V AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is now ready for use with your compatible Sharp TV.



Image: Rear view of the remote control with the battery cover open, illustrating the battery placement for two AA batteries.

Operating Instructions: Button Functions

The ZdalaMit GA667WJSA remote control features standard buttons for controlling your Sharp TV. Refer to the image below for button layout and descriptions.



Image: Front view of the remote control, displaying all functional buttons.

- **POWER** (Red Button): Turns the TV on or off.
- **DISPLAY**: Shows on-screen information.
- **SLEEP**: Sets the TV sleep timer.
- **AV MODE**: Cycles through audio/video modes.
- **CC**: Activates/deactivates Closed Captions.
- **AUDIO**: Adjusts audio settings or selects audio tracks.
- **MUTE**: Mutes or unmutes the TV sound.
- **Number Buttons (0-9)**: Directly select channels.

- **VOL +/-** (Blue Button): Increases or decreases volume.
- **CH +/-** (Green Button): Changes channels up or down.
- **FLASHBACK**: Returns to the previously viewed channel.
- **VIEW MODE**: Cycles through different screen display modes (e.g., Standard, Zoom, Stretch).
- **PC**: Switches input to PC mode.
- **INPUT**: Selects different input sources (e.g., HDMI, AV).
- **FREEZE**: Pauses the current image on screen.
- **MENU**: Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigate through menus and options.
- **ENTER**: Confirms selections in menus.
- **EXIT**: Exits the current menu or function.
- **RETURN**: Returns to the previous screen or menu.
- **FAVORITE CH (A, B, C, D)**: Accesses favorite channels or special functions as defined by your TV model.

Compatible Sharp TV Models

This replacement remote control is compatible with a wide range of Sharp TV models. A partial list of compatible models includes:

- LC-32M44, LC-32M44L, LC-32SB21, LC-32SB21U, LC-32SB220, LC-SB220U, LC-32SB23, LC-32SB23U, LC-32SB24U, LC-37SB24U
- LC-40D68, LC-40D68UT, LC-40D78, LC-40D78UN, LC-42SB45UN, LC-46D78, LC-46D78UN, LC-46SB54, LC-46SB54U, LC-46SB57, LC-46SB57U, LC-46SB57UN
- LC-52D78, LC-52D78UN, LC-52SB55, LC-52SB55U, LC-52SB57
- LC-32D44, LC-32D44U, LC-32D47, LC-32D47U, LC-32D47UA, LC-32D47UN, LC-32D47UT, LC-32D49, LC-32D49U
- LC-32SB27, LC-32SB27U, LC-32SB27UN, LC-32SB27UT, LC-37D44, LC-37D44U, LC-37M44, LC-37M44L, LC-37SB24

This list is not exhaustive. If your Sharp TV model is not listed, please verify compatibility with the GA667WJSA model number.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the proper polarity (+/-).
  - Replace old batteries with new 1.5V AA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure the remote control is pointed directly at the TV.
- **Buttons not working or intermittent response:**
  - This can sometimes be caused by improperly seated batteries or a loose battery spring. Open the battery compartment and ensure the batteries are firmly in place and the springs make good contact.
  - Clean the remote control's infrared emitter (the clear plastic at the front) and the TV's sensor with a soft, dry cloth.
- **Remote works for some functions but not others:**
  - Verify that your TV model is listed as compatible. While this remote is a direct replacement, some specific TV functions might vary.

- Some advanced TV settings or specific "View Mode" options might require the original TV remote for initial setup or specific adjustments.

Specifications

- **Model Number:** GA667WJSA
- **Brand:** ZdalaMit
- **Power Source:** 2 x 1.5V AA Alkaline Batteries (not included)
- **Product Dimensions:** 8 x 2 x 0.6 inches
- **Item Weight:** 2.5 ounces
- **Color:** Black
- **Max Number of Supported Devices:** 1 (Television)
- **Special Feature:** Ergonomic design

Support

For any questions or further assistance regarding your ZdalaMit GA667WJSA replacement remote control, please contact the manufacturer or seller directly. Refer to your purchase documentation for contact information.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WLK8XYQ

More documents and user manuals: **https://manuals.plus/**