Thomas Sabo WA0240-201-201

Thomas Sabo Women's Chronograph Watch WA0240-201-201 Instruction Manual

Introduction

This instruction manual provides essential information for the proper use, care, and maintenance of your Thomas Sabo Women's Chronograph Watch, model WA0240-201-201. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.


Thomas Sabo
AS SABO
984
BLISHED IN

Image: Front view of the Thomas Sabo WA0240-201-201 Women's Chronograph Watch, showcasing the silver dial and stainless steel bracelet.

Setup

Setting the Time

1. Pull the crown (located on the right side of the watch case) out to position 2.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into position 1 (normal operating position).

Bracelet Adjustment

The stainless steel bracelet may require adjustment to fit your wrist comfortably. It is recommended to have this procedure performed by a qualified jeweler or watchmaker to avoid damage to the bracelet or clasp.



Image: Side view of the watch, showing the crown and chronograph pushers.

Operating Instructions

Using the Chronograph Function

Your watch features a chronograph function for measuring elapsed time.

1. **Start:** Press the upper pusher (A) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.

3. **Reset:** After stopping the chronograph, press the lower pusher (B) to reset all chronograph hands to their zero positions.

The sub-dials on the watch face indicate minutes and hours for the chronograph function.

Maintenance

Cleaning

Wipe your watch regularly with a soft, dry cloth to remove dust and dirt. For the stainless steel case and bracelet, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

Water Resistance

This watch is designed with a degree of water resistance suitable for everyday use, such as splashes or brief exposure to rain. It is **not** suitable for swimming, showering, diving, or prolonged water immersion. Ensure the crown is fully pushed in before any contact with water.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to skip, the battery may need replacement. It is recommended to have the battery replaced by an authorized Thomas Sabo service center or a professional watchmaker to ensure proper sealing and maintain water resistance.



Image: Back view of the watch, showing the engraved case back.

Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Depleted battery; Crown not pushed in	Replace battery (professional service recommended); Push crown fully into position 1
Incorrect time	Time not set correctly; Crown pulled out	Reset time as per 'Setting the Time' instructions; Push crown fully into position 1
Chronograph hands do not reset to zero	Requires calibration	Consult a professional watchmaker for calibration.

Specifications

Brand: Thomas Sabo

Model Number: WA0240-201-201-33 MM

Display: Chronograph

Movement Type: Quartz

Case Material: Stainless Steel

Case Diameter: 33 Millimeters

Case Thickness: 13 Millimeters

Strap Material: Stainless Steel

Strap Width: 17 Millimeters

Clasp Type: Buckle

Dial Color: Silver

Glass: Mineral

Special Features: Arabic numerals

Item Weight: 118 Grams

Water Resistance: Splash resistant (not suitable for swimming or showering)

Warranty Information

Your Thomas Sabo watch is covered by a **2-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty booklet included with your watch or visit the official Thomas Sabo website.

Support

For further assistance, service, or repair inquiries regarding your Thomas Sabo watch, please contact:

The authorized Thomas Sabo retailer where you purchased the watch.

An authorized Thomas Sabo service center.

The official Thomas Sabo customer service via their website:www.thomassabo.com

When contacting support, please have your watch model number (WA0240-201-201) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question