Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit N2QAYB000570

ZdalaMit N2QAYB000570 Replacement Remote Control User Manual for Panasonic TVs

1. Introduction

This manual provides instructions for the ZdalaMit N2QAYB000570 replacement remote control. This remote is designed to function as a direct replacement for the original Panasonic N2QAYB000570 remote, compatible with various Panasonic LCD, LED, and Plasma TV models from 2011. No programming or pairing is required for operation.

2. Setup

2.1. Battery Installation

The remote control requires two (2) 1.5V AA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Figure 1: Battery compartment with AA batteries.

Once batteries are installed, the remote is ready for use without any additional programming or pairing.

2.2. Compatible Panasonic TV Models

This replacement remote control is compatible with the following Panasonic TV models:

- TC-32LX34

- TC-32LX44S
- TC-42PX34
- TC-50PX34
- TC-60PS34
- TC-60PS34UA
- TC-L19C30
- TC-L24C3
- TC-L3232C
- TC-L32C3
- TC-L32C3S
- TC-L32E3
- TC-L32X30
- TC-L37E3
- TC-L37U3
- TC-L42E3
- TC-L42E30
- TC-L42U30
- TC-P4232C
- TC-P42S30
- TC-P42X3
- TC-P46S30
- TC-P46ST30
- TC-P46X3
- TC-P50S30
- TC-P50X3
- TC-P60S30
- TC-P60S30UA

3. Operating Instructions

The ZdalaMit N2QAYB000570 remote control provides full functionality for compatible Panasonic TVs. Point the remote directly at the TV's infrared sensor for optimal performance.



Figure 2: Front view of the remote control with button layout.

3.1. Basic Functions

- **POWER (Red Button):** Turns the TV on or off.
- **INPUT:** Selects the video input source (e.g., HDMI 1, AV, Component).
- **VOL +/-:** Adjusts the volume level.
- **CH ^/v:** Changes the TV channel up or down.

- **MUTE:** Silences or restores the TV audio.
- **Number Buttons (0-9):** Directly selects TV channels or enters numerical data.

3.2. Navigation and Menu Functions

- **MENU:** Opens the TV's main menu.
- **Directional Pad (Up, Down, Left, Right):** Navigates through menu options.
- **OK:** Confirms a selection in the menu.
- **EXIT:** Closes the current menu or on-screen display.
- **RETURN:** Goes back to the previous screen or menu.

3.3. Special Functions

- **VIERA TOOLS:** Accesses Panasonic's VIERA Tools menu for smart TV features.
- **SD CARD:** Accesses content from an inserted SD card (if supported by the TV).
- **CC:** Activates or deactivates Closed Captions.
- **SAP:** Selects Secondary Audio Program (if available).
- **LINK:** Activates Panasonic's VIERA Link (HDMI-CEC) functions.
- **INFO:** Displays program information.
- **FORMAT:** Changes the screen aspect ratio or picture format.
- **FAVORITE:** Accesses favorite channels or content.
- **Colored Buttons (Red, Green, Blue, Yellow):** Used for specific functions within menus or interactive applications, as indicated on the TV screen.
- **Media Playback Controls (Rewind, Play, Fast Forward, Stop, Pause):** Controls media playback for compatible devices or content.

4. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AA alkaline batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Avoid exposing the remote to extreme temperatures, humidity, or direct sunlight.

5. Troubleshooting

Problem	Solution

Problem	Solution
Remote control is not working.	◦ Ensure batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new AA alkaline batteries. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Point the remote directly at the TV.
Some buttons are not responding.	◦ Check if the batteries are low and replace them. ◦ Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris. ◦ Ensure the TV model is listed in the compatible models section.
Remote works intermittently.	◦ Replace batteries. ◦ Ensure you are within a reasonable range and line of sight to the TV.

6. Specifications

- **Model Number:** N2QAYB000570
- **Brand:** ZdalaMit
- **Compatible Devices:** Panasonic Televisions
- **Power Supply:** 2 x 1.5V AA Alkaline Batteries (not included)
- **Special Feature:** Pre-Programmed (No setup required)
- **Color:** Black
- **Product Dimensions:** 10 x 2 x 0.65 inches (approximately)
- **Item Weight:** 1.41 ounces (approximately)

7. Support

For any queries or assistance regarding your ZdalaMit N2QAYB000570 replacement remote control, please contact the seller or manufacturer. Refer to your purchase documentation for specific contact details.
Note: Batteries and a user manual are not included in the product package. This document serves as the user manual.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WV7X9V9

More documents and user manuals: **https://manuals.plus/**