De'Longhi CGH1012D

De'Longhi CGH1012D Multigrill Instruction Manual

Model: CGH1012D

Introduction

Thank you for choosing the De'Longhi CGH1012D Multigrill. This appliance is designed to offer versatile cooking options, including grilling, paninis, and griddling, with precise digital control. To ensure safe and optimal performance, please read this instruction manual thoroughly before using the appliance and keep it for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The De'Longhi CGH1012D Multigrill is a versatile cooking appliance featuring a robust design and intuitive controls. It includes interchangeable cooking plates and a digital interface for precise temperature and time management.



Figure 1: De'Longhi CGH1012D Multigrill. This image shows the closed grill with its digital LED control panel, featuring a start/stop button, temperature displays for both plates, a timer, and two rotary knobs for temperature adjustment.

Key Components:

- **Digital Control LED Panel:** Displays temperature settings for each plate and the cooking timer.
- **Temperature Control Knobs:** Independent control for the upper and lower plates.
- **Start/Stop Button:** Initiates and halts the cooking process.
- **Removable Cooking Plates:** Includes one grill plate and one griddle plate, interchangeable and dishwasher safe.
- **Integrated Fat Drip Tray:** Collects excess fat and is removable for easy cleaning.
- **Cool-Touch Handle:** Ensures safe operation when opening and closing the grill.

Setup

1. **Unpacking:** Carefully remove the Multigrill and all accessories from the packaging. Retain packaging for storage or disposal.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash the removable cooking plates and the drip tray with warm, soapy water, then rinse and dry thoroughly.
3. **Plate Installation:** Ensure the cooking plates are correctly inserted and locked into place. The appliance comes with one grill plate and one griddle plate.
4. **Positioning:** Place the Multigrill on a stable, heat-resistant, and flat surface, away from walls or heat-sensitive materials, ensuring adequate ventilation.
5. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet (220V).

Operating Instructions

Cooking Functions:

The De'Longhi CGH1012D Multigrill offers 6 distinct cooking functions:

- **Contact Grill & Panini Press:** For quick cooking of sandwiches, burgers, and thinner cuts of meat.
- **Open Full Grill:** Opens 180 degrees to double the cooking surface, ideal for grilling larger quantities.
- **Open Full Griddle:** Utilizes both griddle plates in the open position for pancakes, eggs, or delicate items.
- **Half Grill Half Griddle:** Combines one grill plate and one griddle plate in the open position for varied cooking.
- **Top Melt:** Allows the top plate to hover above the food, ideal for melting cheese or warming.
- **Oven Grill:** Similar to top melt, providing radiant heat from the top plate.

Digital Control LED Panel:

The LED panel allows precise control over cooking temperature and time for both plates.

1. **Power On:** Press the On/Off switch. The LED panel will illuminate.
2. **Set Temperature:** Use the individual rotary knobs to set the desired temperature for the upper and lower plates. The temperature range is typically from 80°C to 230°C.
3. **Start Preheating:** Press the **START/STOP** button. The indicator light will turn red, and the plates will begin to heat. The display will show the current temperature rising.
4. **Ready Indicator:** Once the set temperature is reached, the appliance will emit an audible signal, and the display will indicate it is ready for cooking.
5. **Set Timer:** Use the timer buttons (up/down arrows next to "TIMER") to set the desired cooking duration.
6. **Cooking:** Place food on the preheated plates. Close the grill for contact cooking or open it for full grill/griddle functions.
7. **End of Cooking:** When the timer expires, the appliance will signal. Press the**START/STOP** button to stop heating.
8. **Power Off:** Turn the On/Off switch to the off position and unplug the appliance from the wall outlet after use.

Dedicated App:

A dedicated application is available to suggest optimal settings for various recipes. While the app provides guidance, users may adjust settings based on personal preference and food type for best results.

Cleaning and Maintenance

Regular cleaning ensures the longevity and hygienic operation of your Multigrill.

1. **Cool Down:** Always allow the appliance to cool completely before cleaning.
2. **Unplug:** Ensure the Multigrill is unplugged from the power outlet.
3. **Remove Drip Tray:** Slide out the integrated fat drip tray and empty its contents. Wash it with warm, soapy water.
4. **Remove Cooking Plates:** Press the plate release buttons to detach the cooking plates.
5. **Clean Plates:** The cooking plates are dishwasher safe. Alternatively, wash them by hand with warm, soapy water and a non-abrasive sponge. For stubborn residue, soak the plates before cleaning.
6. **Clean Exterior:** Wipe the exterior housing with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.
7. **Reassemble:** Once all parts are clean and dry, reattach the cooking plates and reinsert the drip tray.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power switch off.	Ensure power cord is securely plugged into a working outlet and the On/Off switch is in the 'On' position.
Plates not heating.	Temperature not set; START/STOP button not pressed.	Set desired temperature using the knobs and press the START/STOP button to begin heating.
Food not cooking evenly.	Uneven food thickness; plates not fully preheated.	Ensure food is of uniform thickness. Allow plates to fully preheat until the 'Ready' indicator sounds.
Excessive smoke.	Food residue on plates; too much oil.	Clean plates thoroughly before use. Use minimal oil or cooking spray.

Specifications

Model: CGH1012D

Brand: De'Longhi

Power: 2000 Watts

Voltage: 220V

Product Dimensions (W x D x H): 45.8 cm x 34.3 cm x 18.5 cm

Item Weight: 7 Kilograms

Material: Alloy Steel, Plastic (housing)

Cooking Surface (W x D): 370 x 230 mm

Number of Plates: 2 (1 Grill, 1 Griddle)

Special Features: Dishwasher safe removable plates, Integrated fat drip tray, Digital LED display, Adjustable thermostat, Cool touch handle.

Warranty and Support

For warranty information, service, or support, please refer to the warranty card included with your purchase or contact De'Longhi customer service. Keep your proof of purchase for warranty claims.
You can find more information and support on the official De'Longhi website.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question