Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NS-RC4NA-17

ZdalaMit NS-RC4NA-17 Replacement Remote Control User Manual

Model: NS-RC4NA-17

Introduction

This manual provides instructions for the ZdalaMit NS-RC4NA-17 Replacement Remote Control. This remote is designed to function as a direct replacement for original Insignia TV remotes, requiring no programming.

Compatibility

The NS-RC4NA-17 remote control is compatible with various Insignia TV models. A partial list includes:

- NS-24D510MX17
- NS-24D510NA17
- NS-32D310MX17
- NS-32D310NA17
- NS-39D310NA17
- NS-40D510MX17
- NS-40D510NA17
- NS-48D510NA17
- NS-50D510MX17
- NS-50D510NA17
- NS-55D510MX17
- NS-55D510NA17

Setup and Battery Installation

The NS-RC4NA-17 remote control requires two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Slide the battery cover back into place until it clicks securely.



This image illustrates the rear of the ZdalaMit NS-RC4NA-17 remote control. The battery compartment is open, revealing the slots for two AAA batteries and the correct polarity markings for installation.

Operating Your Remote Control

This remote control is designed for immediate use with compatible Insignia TVs without any programming.

Key Functions



This image displays the front of the ZdalaMit NS-RC4NA-17 remote control, highlighting the layout of all functional buttons including power, input, channel, volume, menu, navigation, and number keys.

Button	Function
Power	Turns the TV on or off.
Input	Selects the input source (e.g., HDMI 1, AV).
CH+/CH-	Changes channels up or down.
VOL+/VOL-	Adjusts volume up or down.

Button	Function
Mute	Mutes or unmutes the TV audio.
Menu	Accesses the TV's main menu.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
Enter	Confirms selections in menus.
Exit	Exits the current menu or screen.
Number Buttons (0-9)	Directly selects channels.
Sleep	Sets a sleep timer for the TV.
CCD	Activates or deactivates Closed Captioning.
Game	Switches to Game picture mode (if supported by TV).
Picture	Cycles through picture modes (if supported by TV).
Info*	Displays program information.
Rewind/Fast Forward/Play/Pause/Stop	Controls media playback (if supported by TV/device).

Troubleshooting

- **Remote not responding:** Ensure fresh AAA batteries are correctly installed. Check for any obstructions between the remote and the TV's infrared sensor.
- **Some functions not working:** Verify your TV model is listed as compatible. Some advanced functions may vary depending on the specific Insignia TV model.
- **Intermittent response:** Replace batteries with new ones. Ensure the remote is pointed directly at the TV.

If issues persist, refer to your TV's original user manual for specific TV settings or contact customer support.

Care and Maintenance

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Product Specifications

- **Model:** NS-RC4NA-17
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Connectivity:** Infrared (IR)
- **Dimensions:** Approximately 4 x 2 x 0.6 inches (10.16 x 5.08 x 1.52 cm)
- **Weight:** Approximately 1.41 ounces (40 grams)
- **Compatible Devices:** Insignia Televisions (specific models listed in Compatibility section)

Warranty and Customer Support

For warranty information or technical assistance, please refer to the retailer where the product was purchased or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WVZ4V49

More documents and user manuals: **https://manuals.plus/**