Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Clatronic LS 3658

Clatronic Lady-Shaver LS 3658 Instruction Manual

Model: LS 3658 (Type 263799)

Brand: Clatronic

1. Introduction

Thank you for choosing the Clatronic Lady-Shaver LS 3658. This instruction manual provides important information regarding the safe operation, maintenance, and care of your new shaver. Please read this manual thoroughly before first use and keep it for future reference.

The Clatronic Lady-Shaver LS 3658 is designed for gentle and thorough hair removal on legs, underarms, and the bikini area. It features a stainless steel shaving head with fine foil for a perfect shave and is splash-proof (IPX4) for safe use in damp environments.

2. Safety Instructions

Always observe the following safety precautions to reduce the risk of electric shock, injury, or fire.

- This appliance is intended for household use only.
- Do not immerse the charging station or power adapter in water or other liquids. The shaver itself is splash-proof (IPX4) but not suitable for immersion.
- Keep the appliance away from children.
- Do not use the appliance if the shaving head or foil is damaged, as this may cause injury.
- Only use the original power adapter and charging station supplied with the appliance.
- Unplug the power adapter from the mains socket before cleaning or if not in use for a long period.
- Do not attempt to repair the appliance yourself. Contact qualified service personnel for repairs.
- Ensure your hands are dry when handling the power adapter or charging station.
- Do not use the shaver on irritated skin, open wounds, or if you have skin conditions.

3. Parts Identification

Familiarize yourself with the components of your Clatronic Lady-Shaver LS 3658.

1. Stainless Steel Shaving Head with Fine Foil
2. On/Off Switch
3. Ergonomically Shaped Housing
4. LED Charging Indicator

5. Charging Station/Stand with Rubberized Feet
6. Long Hair Trimmers (2x)
7. Detachable Long Hair Attachment
8. Cleaning Brush
9. Power Adapter



Figure 3.1: Clatronic Lady-Shaver LS 3658 on its charging stand, showing the ergonomic design and LED indicator.

4. Setup

4.1 Initial Charging

1. Place the charging station on a stable, flat surface. The rubberized feet ensure a secure stand.
2. Connect the power adapter to the charging station.
3. Plug the power adapter into a suitable mains socket (e.g., 230V~, 50Hz).
4. Place the Lady-Shaver into the charging station. Ensure it is correctly seated.
5. The LED charging indicator will illuminate, indicating that the shaver is charging.
6. For first use, charge the shaver for approximately 8-10 hours to ensure optimal battery performance. Subsequent charges will take less time.

4.2 Attaching the Long Hair Attachment

The long hair attachment can be used for trimming longer hairs before shaving.

- Ensure the shaver is switched off.
- Align the long hair attachment with the shaving head and gently press it down until it clicks into place.
- To remove, gently pull the attachment upwards from the shaving head.

5. Operating Instructions

5.1 General Shaving Tips

- For best results, use the shaver on clean, dry skin.
- If hairs are long, use the long hair attachment or the integrated long hair trimmers first.
- Hold the shaver at a right angle (90 degrees) to the skin.
- Gently stretch the skin with your free hand to ensure hairs stand upright.
- Move the shaver slowly against the direction of hair growth.
- Do not press too hard, as this can cause irritation or damage the foil.

5.2 Shaving Legs

Start at the ankle and move upwards towards the knee, using slow, steady strokes against the direction of hair growth.

5.3 Shaving Underarms

Raise your arm to stretch the skin. Shave in various directions as hair growth in this area can be irregular.

5.4 Shaving Bikini Area

Gently stretch the skin. Shave carefully in the direction that feels most comfortable and effective.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your shaver.

6.1 Cleaning the Shaving Head

1. Ensure the shaver is switched off and disconnected from the charging station.
2. Gently detach the shaving head from the shaver body.
3. Use the supplied cleaning brush to remove any trapped hairs from the shaving foil and the cutter block.
4. The shaving head is washable: rinse it under running water. Ensure the water is not too hot.

5. Allow the shaving head to air dry completely before reattaching it to the shaver body.
6. Do not use abrasive cleaning agents or harsh chemicals.

6.2 Cleaning the Shaver Body

Wipe the shaver body with a soft, damp cloth. Do not rinse the main body under water.

6.3 Storage

Store the shaver in a dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is discharged.	Place the shaver in the charging station and allow it to charge.
Poor shaving performance.	Shaving head is clogged with hair. Shaving foil or cutter block is worn or damaged. Hairs are too long.	Clean the shaving head thoroughly. Replace the shaving head/foil. Use the long hair attachment or trimmers first.
LED charging indicator does not light up.	Power adapter not properly connected. Faulty power outlet.	Check all connections. Try a different power outlet.
Skin irritation after shaving.	Pressing too hard. Shaving against hair growth too aggressively. Shaving head is dirty.	Apply less pressure. Shave more gently. Clean the shaving head.

If the problem persists after trying these solutions, please contact Clatronic customer support.

8. Specifications

Model Name	Clatronic Lady Shaver Flieder Sanfte Haarentfernung An Beinen (LS 3658)
Model Number	263799
Brand	Clatronic
Power Source	Battery-operated (Rechargeable)
Battery Type	1x 1.2 V / 600 mAh Nickel-Metal-Hydride (Ni-MH)
Protection Class	IPX4 (Splash-proof)
Head Type	Foil
Blade Material	Stainless Steel
Dimensions (L x W x H)	5.5 x 19 x 21 cm

Weight	120 grams
Accessories	Charging Station/Stand, Long Hair Attachment, Cleaning Brush, Power Adapter

9. Warranty and Support

Clatronic products are subject to statutory warranty regulations in the country of purchase. Please retain your proof of purchase for any warranty claims.
For technical support, spare parts, or further information, please visit the official Clatronic website or contact their customer service department.
www.clatronic.de

10. Disposal

Do not dispose of this appliance with normal household waste. Electrical and electronic equipment contains valuable materials and substances that can be harmful to the environment if not disposed of properly. Please dispose of this appliance at designated collection points for electrical and electronic waste. This helps protect the environment and human health.
The integrated battery is rechargeable and should be removed and disposed of separately at appropriate collection points if possible, or the entire device should be handed in at a collection point that handles battery disposal.

© 2024 Clatronic. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WW837PT

More documents and user manuals: **https://manuals.plus/**