Schleich 42379

Schleich Farm World Tractor Toy Instruction Manual

Model: 42379 | Brand: Schleich

1. Product Overview

The Schleich Farm World Tractor with Trailer playset offers an immersive experience into farm life. This 8-piece set is designed for imaginative play, featuring a detailed tractor with a front loader, a trailer, and various farm accessories. It encourages children aged 3-8 to explore and learn about the daily activities on a farm.



Image 1.1: The complete Schleich Farm World Tractor with Trailer set, including the tractor, trailer, front loader, hay bale, and calf figure.

2. Safety Information

Warning! Swallowable small parts. Choking hazard. Not suitable for children under 36 months due to small parts.

- Always supervise children during play.
- Inspect all parts regularly for damage. Discontinue use if any part is broken or damaged.
- Keep packaging materials away from children to prevent suffocation.

3. What's Included

Your Schleich Farm World Tractor with Trailer set includes the following 8 pieces:

- 1 x Tractor
- 1 x Trailer
- 1 x Front Loader (detachable)
- 1 x Farmer Figure
- 1 x Calf Figure
- 1 x Large Round Bale (hay bale)
- 2 x Sticker Sheets (for decoration)



Image 3.1: An illustration of all 8 components included in the Schleich Farm World Tractor with Trailer playset.

4. Setup

The Schleich Farm World Tractor with Trailer set requires minimal assembly to begin play.

4.1 Unboxing

1. Carefully remove all components from the packaging.
2. Dispose of packaging materials responsibly.

4.2 Attaching the Front Loader

1. Locate the front loader piece.
2. Align the attachment points on the front loader with the corresponding slots on the front of the tractor.
3. Gently push until the front loader clicks securely into place.

4.3 Attaching the Trailer

1. Locate the trailer and the hitch on the rear of the tractor.
2. Align the trailer's hitch with the tractor's connection point.
3. Push the trailer onto the hitch until it is securely connected.



Image 4.1: The detailed Schleich tractor, ready for the front loader and trailer attachment.



Image 4.2: The Schleich trailer, designed to connect to the tractor for hauling.

4.4 Applying Stickers

1. Refer to the included sticker sheet for placement suggestions.
2. Carefully peel and apply stickers to the designated areas on the tractor and trailer for added detail.

5. Operating Instructions

The Schleich Farm World Tractor with Trailer is designed for open-ended imaginative play. Here are some ways to operate and interact with your new farm set:

5.1 Using the Tractor and Trailer

- **Driving:** Push the tractor and trailer along flat surfaces. The wheels are designed for smooth movement.
- **Front Loader Operation:** The front loader can be manually raised and lowered. Use it to scoop up the hay bale or other small items.
- **Hauling:** Place the hay bale or other small farm items into the trailer for transport around your imaginary farm.
- **Detaching:** The trailer can be easily detached from the tractor when not needed for hauling.



Image 5.1: A child demonstrating how to use the front loader to move the hay bale, engaging in imaginative farm play.



Image 5.2: A close-up view of the farmer figure seated in the tractor, ready to operate the farm machinery.

5.2 Interacting with Figures

- The farmer figure can be placed in the tractor's driver seat or used independently to tend to the farm animals.
- The calf figure can be positioned anywhere on the farm, interacting with other Schleich Farm World animals (sold separately).





Image 5.3: The detailed farmer figure, an essential part of the farm playset.

5.3 Official Product Video

Watch this video for more ideas on how to play with your Schleich Farm World set, including the tractor and hay bale features:

Your browser does not support the video tag.

Video 5.1: An official Schleich video demonstrating various play scenarios with Farm World sets, including the tractor and hay bale.

6. Maintenance

To ensure the longevity of your Schleich Farm World Tractor set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the toy with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow all parts to air dry completely before storing.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

7. Troubleshooting

While the Schleich Farm World Tractor set is designed for durability, here are some common considerations:

- **Loose Parts:** If any parts become loose, gently reattach them. If a part is broken, discontinue use and contact customer support.
- **Stickers Peeling:** If stickers begin to peel, ensure the surface is clean and dry before attempting to re-adhere them.
- **Difficulty with Movement:** Ensure no debris is caught in the wheels or moving parts. Clean as per maintenance instructions.

8. Specifications

Feature	Detail
Product Dimensions	15.31 x 6.5 x 9.09 inches
Item Weight	3.28 pounds
Model Number	42379
Recommended Age	36 months - 8 years
Number of Pieces	8

9. Warranty and Support

Schleich is committed to manufacturing high-quality, durable toys. While specific warranty details are not provided in this manual, Schleich products are designed to meet or exceed the strictest applicable national and international toy safety requirements.

For any questions, concerns, or support regarding your Schleich Farm World Tractor set, please visit the official Schleich website or contact their customer service department. You can often find contact information on the product packaging or the brand's official website.

Visit the Schleich Store on Amazon for more products and information.

© 2024 Schleich. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question