Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit COV31736202

ZdalaMit COV31736202 Replacement Remote Control User Manual

For LG DVD Player Models: DP132, DP132NU, DP132H, DP132-H

Introduction

This manual provides instructions for the ZdalaMit COV31736202 replacement remote control, designed for use with various LG DVD Player models including DP132, DP132NU, DP132H, and DP132-H. This remote requires no programming or pairing; simply insert batteries for immediate use.

Setup: Battery Installation

The remote control requires two 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two 1.5V AAA alkaline batteries into the compartment. Ensure that the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment. Incorrect polarity can prevent the remote from functioning.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.
5. The remote control is now ready for use. No programming or pairing is required for compatible LG DVD players.



This image shows the rear view of the ZdalaMit COV31736202 remote control with its battery cover removed. The compartment is designed to hold two AAA batteries, with clear markings for positive (+) and negative (-) terminals to guide correct insertion.

Operating the Remote Control

This remote control operates via infrared (IR) technology. For optimal performance, ensure a clear line of sight between the remote control and the infrared sensor on your LG DVD player.

- **Power On/Off:** Press the **POWER** button to turn your LG DVD player on or off.
- **Playback Controls:** Use the **PLAY**, **PAUSE**, **STOP**, **FAST FORWARD**, and **REWIND** buttons to control media playback.

- **Navigation:** Utilize the directional arrow buttons (**UP**, **DOWN**, **LEFT**, **RIGHT**) to navigate through menus and options. Press the **ENTER** or **OK** button to confirm selections.
- **Volume Control:** Adjust the audio output level using the **VOLUME UP** and **VOLUME DOWN** buttons.
- **Channel/Track Selection:** Use the **CHANNEL/TRACK** buttons to switch between tracks or chapters.
- **Numeric Keypad:** Input specific track numbers or other numerical data using the numeric keypad (0-9).

The maximum effective operating range for this remote control is approximately 33 feet (10 meters).

Maintenance

- **Cleaning:** Clean the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's performance degrades, or it stops responding. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Environmental Protection:** Do not dispose of used batteries with household waste. Follow local regulations for proper battery disposal.

Troubleshooting

If your ZdalaMit COV31736202 remote control is not functioning as expected, please refer to the following common issues and solutions:

- **Remote Not Responding:**
  - **Check Batteries:** Ensure that the batteries are inserted correctly with the proper polarity (+ and -).
  - **Replace Batteries:** Install fresh 1.5V AAA alkaline batteries. Weak or dead batteries are a common cause of remote control malfunction.
  - **Clear Obstructions:** Make sure there are no objects blocking the line of sight between the remote control's infrared emitter and the LG DVD player's IR receiver.
  - **Operating Distance:** Confirm you are within the maximum operating range of 33 feet (10 meters) from the DVD player.
- **Incorrect Functionality:**
  - **Verify Compatibility:** Ensure your LG DVD player model (DP132, DP132NU, DP132H, DP132-H) is listed as compatible with this remote control.
  - **No Programming Needed:** This remote is pre-programmed. If you are attempting to program it, this is unnecessary and may cause issues.

Specifications

Brand	ZdalaMit
Model Name	COV31736202
Compatible Devices	LG DVD Player (DP132, DP132NU, DP132H, DP132-H)
Connectivity Technology	Infrared
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Maximum Range	33 Feet (10 meters)
Button Quantity	18
Controller Type	Button Control

Item Dimensions (L x W x H)	4.17"L x 1.79"W x 0.55"H
Item Weight	1 Ounce
Special Feature	Pre-Programmed (No setup required)

Warranty Information

This ZdalaMit COV31736202 replacement remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase (e.g., receipt or order confirmation) as it will be required for any warranty claims.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. For warranty service, please contact the seller or the manufacturer directly with your purchase details.

Customer Support

For further assistance, technical support, or any inquiries regarding your ZdalaMit COV31736202 replacement remote control, please contact the retailer from whom you purchased the product. You may also refer to the ZdalaMit official website for additional support resources, if available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06X41F2H7

More documents and user manuals: **https://manuals.plus/**