Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RM-ED047

RM-ED047 Replacement Remote Control User Manual

Model: **RM-ED047** | Brand: **ZdalaMit**

Introduction

This manual provides instructions for the ZdalaMit RM-ED047 Replacement Remote Control. This remote is designed as a direct replacement for various Sony TV models, offering immediate functionality without the need for complex programming or pairing.

The RM-ED047 remote control is compatible with a wide range of Sony TV models, including but not limited to:

- KDL-22BX320, KDL-22BX321, KDL-32BX320, KDL-32BX321, KDL-32BX420, KDL-32BX421
- KDL-40BX420, KDL-40BX421, KDL-46BX420, KDL-46BX421, KDL-55BX520
- KDL-32R300B, KDL-32R330B, KDL-32R400, KDL-32R400A, KDL-32R420B
- KDL-40R350B, KDL-40R380B, KDL-40R450, KDL-40R450A, KDL-40R470B
- KDL-46R450A, KDL-46R453, KDL-46R453A, KDL-48R470B, KDL-46R471A, KDL-50R450, KDL-50R450A
- KDL-32HX750, KDL-32HX751, KDL-32HX753, KDL-32HX755, KDL-32HX757, KDL-32HX758, KDL-32HX759
- KDL-40HX750, KDL-40HX751, KDL-40HX753, KDL-40HX755, KDL-40HX756, KDL-40HX757, KDL-40HX758, KDL-40HX759, KDL-40HX75G
- KDL-40HX850, KDL-40HX853, KDL-40HX855, KDL-46HX750, KDL-46HX751, KDL-46HX753, KDL-46HX755, KDL-46HX756
- KDL-46HX757, KDL-46HX758, KDL-46HX759, KDL-46HX75G, KDL-46HX850, KDL-46HX853, KDL-46HX855
- KDL-55HX750, KDL-55HX751, KDL-55HX753, KDL-55HX755, KDL-55HX75G, KDL-55HX850, KDL-55HX853
- KDL-50W790B, KDL-50W800B, KDL-55W790B, KDL-55W800B, KDL-55W950B, KDL-55X830B
- KDL-60W840B, KDL-60W850B, KDL-65W950B, KDL-65X830B, KDL-70W830B, KDL-70W840B, KDL-70W850B, KDL-70X830B
- XBR-49X850B, XBR-55X850B, XBR-55X900B
- Also replaces RM-ED044, RM-GD026, RM-GD025, RM-GD027, RM-GD024, RM-GD028, RM-GD017, RM-GD019, RM-GD020

Setup

Battery Installation

The RM-ED047 remote control requires two (2) 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Sony TV models. No programming or pairing is required.



Figure 1: Front view of the RM-ED047 remote control, showing all buttons and layout.

Operating Instructions

The RM-ED047 remote control functions identically to the original Sony remote it replaces. Simply point the remote control

towards your Sony TV and press the desired button.

Key Functions Overview

- **Power (I/O)**: Turns the TV on or off.
- **TV Pause**: Pauses live TV (if supported by TV model).
- **Numeric Buttons (0-9)**: Direct channel selection.
- **Channel (+/-)**: Changes channels up or down.
- **Volume (+/-)**: Adjusts volume up or down.
- **Mute**: Mutes or unmutes TV audio.
- **Home**: Accesses the TV's main menu or smart TV interface.
- **Return/Back**: Returns to the previous screen or menu.
- **Guide**: Displays the electronic program guide (EPG).
- **Options**: Displays context-sensitive options for the current screen.
- **Directional Pad (Up, Down, Left, Right) & Enter (SEN)**: Navigates menus and confirms selections.
- **Input/Source**: Changes the input source (HDMI, AV, etc.).
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functions vary by TV model and application.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip)**: Controls media playback.



Figure 2: Angled view of the RM-ED047 remote control, showing its form factor.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote control.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Dispose of used batteries according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	Batteries are dead or incorrectly installed.	Replace batteries with new 1.5V AAA alkaline batteries. Ensure correct polarity (+/-).
Remote control range is poor.	Low batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Remove any objects blocking the line of sight to the TV's IR sensor. Ensure the TV's IR sensor is clean.
Certain buttons do not respond.	Button stuck or damaged; TV model may not support that specific function.	Check if the button is physically stuck. Verify if your TV model supports the function. If not, the button may not be active.
Remote works intermittently.	Loose battery connection; Interference from other devices.	Re-seat batteries firmly. Move away from strong light sources or other electronic devices that might cause interference.

Specifications

- **Model:** RM-ED047
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Sony Televisions (various models as listed in Introduction)
- **Product Dimensions:** 8 x 2 x 1 inches (approximately)
- **Item Weight:** 2 ounces (approximately)
- **Special Feature:** Ergonomic design

Warranty and Support

Specific warranty information for this replacement remote control is not provided in this manual. Please refer to the

product packaging or contact your retailer for details regarding warranty coverage.

For technical support or further inquiries, please contact the ZdalaMit customer service through the retailer's platform where the product was purchased.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06X9KNMTR

More documents and user manuals: **https://manuals.plus/**