Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Picket House DJX100DTB

Picket House Furnishings Dex Dining Table & Base Instruction Manual

Brand: Picket House | Model: DJX100DTB

Introduction

Thank you for choosing the Picket House Furnishings Dex Dining Table & Base. This manual provides essential information for the safe assembly, proper use, and maintenance of your new dining table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Product Overview

The Dex Dining Table & Base is a robust and stylish addition to any dining area. It features a durable wood construction with a smokey walnut finish, designed for stability and longevity. The table is supplied with a separate base that requires assembly.



Image: The Dex Dining Table, showcasing its rectangular shape and overall dimensions of 42 inches deep, 60-78 inches wide

(indicating potential extension), and 30 inches high.



Image: A front view of the Dex Dining Table, highlighting the sturdy base and the rich smokey walnut finish of the tabletop.

Setup and Assembly

Assembly of the Dex Dining Table & Base is required. Please ensure all components are present and undamaged before beginning. A screwdriver is recommended for assembly.

Required Tools:

- Screwdriver

Assembly Steps:

1. Unpack all components and verify against the parts list (not provided in this manual, refer to packaging).
2. Carefully attach the table base to the tabletop using the provided hardware. Ensure all screws are tightened securely.
3. Place the assembled table in its desired location.
4. Check for stability and ensure all connections are firm before use.

Caution: Assembly should be performed by at least two adults to prevent injury or damage to the product due to its weight.

Operating Instructions

The Dex Dining Table is designed for indoor use as a dining surface. Ensure the table is placed on a level surface to prevent wobbling. Avoid placing excessively heavy items on the table, especially near the edges, to maintain stability and prevent damage.

Maintenance and Care

Proper care will help maintain the appearance and longevity of your dining table. This product is not stain resistant.

General Care:

- Wipe spills immediately with a soft, dry cloth.

- Use coasters and placemats to protect the surface from heat, moisture, and scratches.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish. A damp cloth with mild soap is generally sufficient for cleaning, followed by immediate drying.
- Keep the table away from direct sunlight and heat sources to prevent warping or fading.
- Periodically check and tighten all hardware to ensure the table remains stable.



Image: A detailed view of the table's surface, showing the textured wood grain and smokey walnut finish. This highlights the importance of proper care to preserve its appearance.

Troubleshooting

Table Wobbles:

- Ensure the table is on a level surface.
- Check all assembly hardware and tighten any loose screws.

Surface Damage:

- Minor scratches may be touched up with a wood repair kit matching the smokey walnut finish.
- For significant damage, contact customer support.

Specifications

Feature	Detail
Brand	Picket House
Model Number	DJX100DTB
Product Dimensions (D x W x H)	42"D x 60"W x 30"H
Item Weight	144 Pounds
Frame Material	Wood
Color	Smokey Walnut
Included Components	Dex Dining Table & Base
Required Assembly	Yes
Tools Recommended For Assembly	Screwdriver
Is Stain Resistant	No
UPC	848853049995

Warranty and Support

For information regarding the product warranty, please refer to the product description or the store page where the item was purchased. For further assistance, technical support, or to report missing/damaged parts, please contact Picket House Furnishings customer service through their official website or the retailer from whom you purchased the product.

© 2024 Picket House Furnishings. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XB7Q6ZF

More documents and user manuals: **https://manuals.plus/**