Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luxor WSCC-3

Luxor WSCC-3 Three-Shelf Collapsible Wire Utility Cart

User Manual

1. Introduction

Thank you for choosing the Luxor WSCC-3 Three-Shelf Collapsible Wire Utility Cart. This heavy-duty cart is designed for efficient transport and storage in various settings, including offices, warehouses, and hospitality environments. Its robust steel construction, chrome finish, and collapsible design offer durability and convenience.

1.1 Safety Information

- Read all instructions before assembly and use.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg) for the entire cart. Distribute weight evenly across shelves.
- Ensure all casters are locked when the cart needs to remain stationary.
- Keep hands clear of moving parts during folding and unfolding.
- Use on flat, stable surfaces only.

2. Package Contents

Please verify that all components are present before beginning assembly:

- Collapsible Wire Cart Frame with Shelves (pre-assembled)
- 4 x Thermoplastic Rubber (TPR) Casters (2 with locking brakes)

3. Setup and Assembly

The Luxor WSCC-3 cart is designed for quick and easy assembly. No tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Casters:** Turn the folded cart upside down. Insert the stem of each caster into the designated holes at the bottom of the cart legs. Push firmly until each caster clicks securely into place. Ensure the two locking casters are installed on the same side for easier access.
3. **Unfold the Cart:** Stand the cart upright. Gently pull the top shelf upwards and outwards. The side panels will extend. Continue to unfold until the cart is fully extended and the shelves lie flat.
4. **Secure Shelves:** Ensure all shelf locking mechanisms (small clips or latches) are engaged to hold the shelves in

their flat, open position.



Image 3.1: The Luxor WSCC-3 utility cart displayed in both its folded and unfolded configurations, illustrating its space-saving design.



Image 3.2: A detailed diagram illustrating the dimensions of the Luxor WSCC-3 utility cart, including height, width, depth, and shelf clearance.

4. Operating Instructions

4.1 Unfolding for Use

To prepare the cart for use, simply pull the top shelf upwards and outwards until the frame fully extends and locks into place. Ensure all shelves are flat and secure before loading items.

4.2 Folding for Storage

To fold the cart for compact storage:

1. Remove all items from the shelves.

2. Release any shelf locking mechanisms.
3. Gently push the top shelf downwards and inwards. The side panels will collapse.
4. Continue pushing until the cart is fully folded flat.

4.3 Loading and Transport

- Distribute weight evenly across the three shelves to maintain stability.
- Do not exceed the 300 lbs (136 kg) total weight capacity.
- Use the comfortable tubular handle for easy pushing and maneuvering.
- Engage the locking brakes on the casters when the cart needs to remain stationary, especially on sloped surfaces.



Image 4.1: Two Luxor WSCC-3 utility carts in a functional setting, demonstrating their versatility for holding kitchen items, dishes, and bulk goods.



Image 4.2: The Luxor WSCC-3 utility cart loaded with various items, including canned goods and a wooden crate of potatoes, showcasing its capacity for transporting bulk items.



Image 4.3: The Luxor WSCC-3 utility cart in an office setting, loaded with various items such as vases, cleaning supplies, and boxes, illustrating its versatility for different environments.

Your browser does not support the video tag.

Video 4.1: This official video provides a comprehensive demonstration of the Luxor WSCC-3 Three-Shelf Collapsible Wire Utility Cart. It showcases the cart's easy folding and unfolding mechanism, its heavy-duty steel construction with chrome finish, the ventilation benefits of wire shelves, its 300 lbs weight capacity, and the smooth maneuverability provided by its locking casters. The video also highlights its suitability for various environments like kitchens, restaurants, and offices.

5. Maintenance

To ensure the longevity and optimal performance of your utility cart, follow these maintenance guidelines:

- **Cleaning:** Wipe down the chrome-plated steel surfaces with a soft, damp cloth and a mild detergent. Avoid abrasive cleaners or scouring pads, which can damage the finish. Dry thoroughly after cleaning.
- **Caster Inspection:** Periodically check the casters for any accumulated debris (hair, string, etc.) that might hinder smooth movement. Clean as necessary. Ensure casters are securely attached.
- **Frame Inspection:** Regularly inspect the frame and shelf connections for any signs of damage or loose components. Tighten or address issues promptly.

6. Troubleshooting

- **Cart not rolling smoothly:**
  - Check casters for debris (hair, lint, etc.) and remove if present.
  - Ensure caster wheels are not locked.
- **Cart feels unstable:**
  - Verify that the cart is fully unfolded and all shelf locking mechanisms are engaged.
  - Ensure weight is distributed evenly across the shelves and within the weight capacity.
  - Check that all casters are securely attached.
- **Cart difficult to fold/unfold:**
  - Ensure all items are removed from the cart.
  - Check for any obstructions in the folding mechanism.

7. Specifications

Feature	Specification
Model Number	WSCC-3
Product Dimensions (Unfolded)	37" W x 18.25" D x 30.5" H (94 cm W x 46.4 cm D x 77.5 cm H)
Weight Capacity	300 lbs (136 kg)
Material	Alloy Steel (Chrome Finish)
Number of Shelves	3
Caster Type	4" Thermoplastic Rubber (TPR) Swivel Casters (2 with locking brakes)
Item Weight	35 lbs (15.9 kg)

8. Warranty and Support

For warranty information, technical support, or replacement parts, please contact Luxor customer service. Refer to your purchase documentation for specific warranty terms and contact details.

© 2023 Luxor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XDHQGJM

More documents and user manuals: **https://manuals.plus/**