Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 8541714385

ZdalaMit Replacement Remote Control User Manual

For Element ELEFT406, ELEFT466, ELEFT502 LED TVs

Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for use with specific Element LED TV models. This remote control offers a direct replacement solution, requiring no complex programming or pairing.
Compatible Element TV Models:

- ELEFT406
- ELEFT466
- ELEFT502

Setup

The ZdalaMit Replacement Remote Control is designed for immediate use with compatible Element TV models. No programming or pairing is required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Figure 1: Rear view of the remote control with the battery cover removed, illustrating the battery insertion process.

Once batteries are installed, the remote control is ready for operation.

Operating Instructions

This remote control provides full functionality for your compatible Element LED TV. Below is a general overview of common button functions.



Figure 2: Front view of the ZdalaMit Replacement Remote Control, highlighting key operational buttons.

- **Power (Red Button):** Turns the TV on or off.
- **Input (Green Button):** Selects the input source (e.g., HDMI 1, AV).
- **Number Buttons (0-9):** Directly select TV channels.
- **Menu:** Accesses the TV's main menu.
- **Mode Buttons (e.g., 2 MODE, 5 MODE):** May switch between different display modes or functions depending on the TV model.
- **Aspect:** Adjusts the screen aspect ratio.

- **Mute:** Mutes or unmutes the TV audio.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes TV channels up or down.
- **Replay:** Jumps back a few seconds in playback (if supported by content).
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **Exit:** Exits the current menu or function.
- **Home:** Returns to the TV's home screen or main menu.
- **Auto:** Automatic picture adjustment (if supported).
- **Add/Erase:** Manages channel lists.
- **Repeat:** Repeats playback (if supported).
- **MTS:** Multi-channel Television Sound selection.
- **Freeze:** Freezes the current image on screen.
- **CC (Closed Caption):** Toggles closed captions on or off.
- **V-CHIP:** Accesses V-Chip parental control settings.
- **Setup:** Enters TV setup menu.
- **Content:** Accesses content-related features.
- **Enter:** Confirms selections.
- **Clear:** Clears input or selections.

Specific button functionality may vary slightly based on your Element TV model. Refer to your TV's original manual for detailed descriptions of advanced features.

Maintenance

To ensure the longevity and optimal performance of your ZdalaMit Replacement Remote Control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or if it stops functioning. Always replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the remote control to water or other liquids.
- **Dropping:** Avoid dropping the remote control, as this can damage internal components.

Troubleshooting

If you experience issues with your ZdalaMit Replacement Remote Control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm that the remote control is pointed directly at the TV's infrared sensor.
- **Limited Functionality:**

- Verify that your TV model is listed as compatible (ELEFT406, ELEFT466, ELEFT502).
- Some advanced functions may be specific to the original TV remote. This replacement remote is designed to cover primary functions.

- **Buttons Not Working:**
  - Ensure the remote is clean and free of debris that might obstruct button presses.
  - If only specific buttons are not working, it might indicate internal damage or wear.

If problems persist after attempting these steps, please refer to the Support section for further assistance.

Specifications

Brand	ZdalaMit
Model Number	8541714385
Compatible TV Models	Element ELEFT406, ELEFT466, ELEFT502
Power Supply	2 x AAA 1.5V Batteries (Not Included)
Dimensions	7.15 x 1.79 x 0.55 inches
Item Weight	1.41 ounces
Color	Black
Special Feature	Ergonomic design
Manufacturer	ZdalaMit Factory

Warranty Information

Specific warranty details for this ZdalaMit Replacement Remote Control are not provided in the product information. Please refer to the retailer or manufacturer's website for any applicable warranty policies or contact customer support for further inquiries.

Support

For any questions, concerns, or technical assistance regarding your ZdalaMit Replacement Remote Control, please contact the seller or manufacturer directly. Contact information is typically available on the product packaging or the retailer's website where the item was purchased.
When contacting support, please have your product model number (8541714385) and the specific Element TV model (ELEFT406, ELEFT466, or ELEFT502) ready to provide for efficient assistance.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XHD13M6

More documents and user manuals: **https://manuals.plus/**