Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 4330246903

Replacement Remote Control User Manual

Brand: ZdalaMit | Model: 4330246903

Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for various Seiki TV models. This remote control is a direct replacement and requires no programming or pairing. Simply install batteries, and it is ready for immediate use with compatible Seiki televisions.
Compatible Seiki TV models include, but are not limited to: SE55GY19, SE65UY04, SE22FE01, SE65GY25, SE40FY27, SE32FY22, SE24FE01-W, SE19HE01, SE39HE02, LC-32G82, SE24FT01, SE20HS04, SE26HQ04, SE50FY28, SC151FS, SC221FS, SE65FY18, and many more listed in the product description.

Setup

Battery Installation

The remote control requires two (2) 1.5V AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 1: Angled view of the remote control, illustrating its design and the location of the battery compartment on the rear.

Once batteries are installed, the remote control is ready for use without any additional programming or pairing.

Operating Instructions

This section describes the primary functions of the buttons on your replacement remote control.


1
2
3
4
5
6
7
8
9
0
P.MODE
S.MODE
MTS
SLEEP
SOURCE
CH
VOL
INFO
CC
V-CHIP
AUTO
ASPECT
OK
MENU
EXIT
A
B
C
D
CH.LIST
ADD/ERASE
FAV
FAV+
HDMI
FAV-



Figure 2: Front view of the remote control with all buttons clearly visible.

Button Functions

Button	Function
Power (Red)	Turns the TV on or off.
Mute (Green)	Mutes or unmutes the TV sound.
Number Buttons (0-9)	Directly select TV channels.
SOURCE	Selects input sources (e.g., HDMI, AV, Component).
CH +/-	Changes TV channels up or down.
VOL +/-	Adjusts the volume level up or down.
MENU	Opens the TV's main menu.
OK / **Directional Arrows**	Navigates through menus and confirms selections.
EXIT	Exits the current menu or on-screen display.
P.MODE / **S.MODE** / **MTS** / **SLEEP**	Accesses Picture Mode, Sound Mode, Multi-channel Television Sound, and Sleep Timer functions respectively.
INFO	Displays current channel information.
AUTO / **CC** / **I-CHIP** / **ASPECT**	Accesses Auto-tuning, Closed Captioning, I-Chip (parental control), and Aspect Ratio settings.
Colored Buttons (A, B, C, D)	Functions vary by TV model, often used for specific menu options or smart TV features.
HDMI	Directly switches to an HDMI input.
CH.LIST / **ADD/ERASE** / **FAV** / **FAV+** / **FAV-**	Accesses Channel List, Add/Erase channels, and Favorite channel functions.

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. Do not use liquid cleaners, sprays, or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact. Dropping it can cause internal damage.

Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Solution
Remote control is not working.	• Ensure batteries are installed correctly with the correct polarity (+/-). • Replace old batteries with new 1.5V AAA batteries. • Check if there is a clear line of sight between the remote control and the TV's infrared sensor. Remove any obstructions. • Ensure the TV is powered on.
Remote control has limited range or intermittent response.	• Replace batteries with new ones. • Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the TV's IR sensor. • Move closer to the TV.
Certain buttons do not function.	• Verify that the button's function is supported by your specific Seiki TV model. Some buttons may be TV-specific. • Ensure the remote is clean and there is no debris under the buttons.

Specifications

Feature	Detail
Product Dimensions	7 x 1.5 x 0.5 inches
Item Weight	1.41 ounces
Power Supply	2 x 1.5V AAA batteries (Not Included)
Color	Black
Max Number of Supported Devices	1 (Television)
Compatible Devices	Various Seiki TV models (LCD, LED)
Model Number	4330246903

Warranty and Support

This product is a replacement remote control. Specific warranty information is not provided in this manual. For any queries or support regarding this product, please contact the seller or manufacturer directly.
"Please feel free to contact us if you have any query, thanks!"

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XJ1PSJP

More documents and user manuals: **https://manuals.plus/**