JustFine Replacement Remote Control for Sharp AQUOS TVs

JustFine Replacement Remote Control Instruction Manual

For Sharp AQUOS LED LCD HD TVs

Introduction

This manual provides comprehensive instructions for the JustFine replacement remote control, designed for seamless compatibility with various Sharp AQUOS LED LCD HD TV models. This remote is pre-programmed and requires no additional setup beyond battery installation. It offers full functionality, including dedicated buttons for Netflix and 3D features, where supported by your television model.

Setup

1. Battery Installation

To begin using your remote control, you must first install two AAA batteries (not included). Follow these steps:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *Batteries are not included with this remote control. Please use new AAA alkaline batteries for optimal performance.*







Image: The back of the remote control, illustrating the location of the battery compartment. The compartment cover is visible at the lower section of the remote's back, designed for easy access to insert or replace AAA batteries.

2. Initial Use

This replacement remote control is pre-programmed for immediate use with compatible Sharp AQUOS LED LCD HD TVs. No additional programming or code entry is required. Once batteries are installed, simply point the remote at your television and begin operation.

Operating Instructions

The remote control functions identically to your original Sharp TV remote. Point the remote directly at your television's infrared receiver for best performance. Key functions include:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Channel Up/Down:** Navigates through channels.
- **Volume Up/Down:** Adjusts the sound level.
- **Mute:** Silences the TV audio.
- **Input/Source:** Selects different input sources (HDMI, AV, etc.).
- **Menu:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** For navigating menus and making selections.
- **Netflix Button:** Provides direct access to the Netflix application (requires an active Netflix subscription and internet connection on your TV).
- **3D Button:** Activates or deactivates 3D mode (if your TV model supports 3D functionality).

Maintenance

Proper care will extend the life and functionality of your remote control.

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote to direct sunlight, heat, moisture, or extreme temperatures.

Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

- **Remote is not working:**
  - Ensure batteries are installed correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range (up to 10 meters) and pointing the remote directly at the

TV.

- **Limited range or intermittent response:**
  - Replace batteries.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the remote's signal.
- **Specific buttons (e.g., Netflix, 3D) are not working:**
  - Verify that your Sharp TV model supports the specific feature (e.g., 3D functionality or smart TV apps like Netflix).
  - Ensure your TV is connected to the internet for smart features like Netflix.

Specifications

Feature	Detail
Brand	JustFine
Compatible Devices	Sharp AQUOS LED LCD HD Televisions (Models: LC-60LE847, LC-60LE640UD, LC-52LE830, LC-46LE810UN, LC-70LE735, LC46LE830U)
Connectivity Technology	Infrared (IR)
Battery Type	2 x AAA (not included)
Maximum Range	10 Meters
Special Feature	Ergonomic design, Pre-programmed
Controller Type	Button Control

Warranty and Support

This JustFine replacement remote control is sold with a money-back guarantee and a 30-day quality warranty, ensuring a hassle-free return process if needed. The product undergoes a check before shipping to ensure functionality.
If you encounter any problems or have questions regarding the operation or compatibility of your remote control, please contact the seller directly for assistance. Your satisfaction is important, and support is available to help resolve any issues.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question