**Victrola VTA-600B**

# Victrola Navigator 8-in-1 Bluetooth Record Player (Model VTA-600B-BLK) Instruction Manual

Comprehensive guide for setup, operation, and maintenance.

## 1. Important Safety Instructions

Please read and understand all safety instructions before using this product. Keep these instructions for future reference.

- **Water and Moisture:** Do not use this apparatus near water.
- **Heat:** Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Power Cord Protection:** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.

## 2. Package Contents

Verify that all items listed below are included in your package:

- Victrola Navigator 8-in-1 Bluetooth Record Player
- Remote Control
- 45 RPM Adapter
- Instruction Manual

- Power Adapter




Image: The Victrola Navigator 8-in-1 Bluetooth Record Player, black model, shown with its lid open, revealing the turntable. A remote control is placed next to the unit. This image represents the main product and its included remote.

## 3. Product Overview

### 3.1 Front Panel Controls

- **Power Button:** Turns the unit on or off.
- **Volume Knob:** Adjusts the master volume level.
- **Input Select Buttons:** Switches between Phono, CD, Cassette, FM, Bluetooth, USB, and AUX modes.
- **Tuning Knob:** Adjusts FM radio frequency.
- **CD Player Controls:** Play/Pause, Stop, Skip/Search, Eject.
- **USB Port:** For USB playback and recording.
- **Headphone Jack:** For private listening.
- **Display:** Shows current mode, track information, and radio frequency.




Image: A close-up view of the front panel of the Victrola Navigator, mahogany model, highlighting the various controls such as the volume knob, tuning dial, input selection buttons, CD player, and display. This illustrates the user interface.

## 3.2 Rear Panel Connections

- **RCA Line Out:** Connects to external amplifiers or powered speakers.
- **FM Antenna Jack:** Connects the included FM wire antenna.
- **AC Power Input:** Connects the power adapter.




Image: The rear view of the Victrola Navigator, mahogany model, displaying the RCA Line Out ports and the power input. This image demonstrates how to connect external speakers or power the unit.

## 4. Setup

### 4.1 Unpacking and Placement

1. Carefully remove the unit from its packaging.
2. Place the unit on a flat, stable surface away from direct sunlight, heat sources, and excessive dust or vibration.
3. Remove any protective materials from the turntable platter and tonearm.

### 4.2 Power Connection

1. Connect the AC power adapter to the AC Power Input jack on the rear of the unit.
2. Plug the power adapter into a wall outlet.

### 4.3 FM Antenna Connection

1. Uncoil the included FM wire antenna.
2. Connect the antenna to the FM Antenna Jack on the rear of the unit.

3. Extend the antenna for optimal FM reception.

### 4.4 External Speaker Connection (Optional)

1. To connect external powered speakers or an amplifier, use RCA cables (not included).
2. Connect one end of the RCA cables to the RCA Line Out ports on the rear of the unit.
3. Connect the other end of the RCA cables to the corresponding audio input on your external audio system.

## 5. Operating Instructions

### 5.1 General Operation

1. Press the **Power Button** to turn the unit on.
2. Adjust the **Volume Knob** to a desired listening level.
3. Press the appropriate **Input Select Button** to choose your desired audio source (Phono, CD, Cassette, FM, Bluetooth, USB, AUX).

### 5.2 Turntable Operation

1. Press the **Input Select Button** to choose PHONO mode.
2. Lift the turntable lid.
3. Place a record on the turntable platter. If playing a 45 RPM single, use the included 45 RPM adapter.
4. Select the appropriate speed (33, 45, or 78 RPM) using the speed selector switch.
5. Release the tonearm lock.
6. Gently lift the tonearm and position the stylus over the desired track on the record.
7. Lower the tonearm slowly onto the record. Playback will begin.
8. At the end of the record, manually lift the tonearm and return it to its rest. Secure the tonearm lock.

### 5.3 CD Player Operation

1. Press the **Input Select Button** to choose CD mode.
2. Press the **Eject Button** to open the CD tray.
3. Place a CD with the label side facing up into the tray.
4. Press the **Eject Button** again to close the tray. The unit will read the CD.
5. Press the **Play/Pause Button** to start playback.
6. Use the **Skip/Search Buttons** to navigate between tracks.




Image: A hand is shown inserting a compact disc into the CD player slot of the Victrola Navigator, mahogany model. This illustrates the process of loading a CD for playback.

## 5.4 Cassette Player Operation

1. Press the **Input Select Button** to choose TAPE mode.
2. Insert a cassette tape into the cassette slot on the side of the unit.
3. Push the tape in until it clicks into place and playback begins automatically.
4. To fast forward, partially press the cassette into the slot.
5. To stop playback and eject the tape, fully press the cassette into the slot until it ejects.

## 5.5 FM Radio Operation

1. Press the **Input Select Button** to choose FM mode.
2. Rotate the **Tuning Knob** to select your desired FM radio station.
3. Adjust the FM antenna for best reception.

## 5.6 Bluetooth Operation (Receiving)

1. Press the **Input Select Button** to choose BLUETOOTH mode. The Bluetooth indicator will flash.

2. Enable Bluetooth on your external device (smartphone, tablet, etc.).
3. Select "Victrola Navigator" from the list of available devices.
4. Once paired, the Bluetooth indicator will stop flashing and remain solid. You can now stream audio from your device to the Victrola Navigator.

### 5.7 Bluetooth Operation (Transmitting - VinylStream™)

This feature allows the Victrola Navigator to stream audio from its sources (turntable, CD, cassette, FM, AUX, USB) to an external Bluetooth speaker or headphones.

1. Ensure your external Bluetooth speaker or headphones are in pairing mode.
2. Select the desired audio source on the Victrola Navigator (e.g., PHONO for records).
3. Press and hold the **PAIR/BT Button** on the Victrola Navigator for a few seconds until the Bluetooth indicator flashes rapidly.
4. The Victrola Navigator will search for and connect to the nearest available Bluetooth receiving device.
5. Once connected, the Bluetooth indicator will remain solid, and audio will play through your external Bluetooth device.

### 5.8 USB Playback

1. Insert a USB flash drive into the USB port on the front panel.
2. Press the **Input Select Button** to choose USB mode.
3. The unit will automatically detect and begin playing compatible audio files (MP3).
4. Use the **Play/Pause** and **Skip/Search Buttons** to control playback.

### 5.9 Auxiliary Input

1. Connect an external audio device (e.g., MP3 player) to the AUX IN jack using a 3.5mm audio cable (not included).
2. Press the **Input Select Button** to choose AUX mode.
3. Control playback from your external device.

### 5.10 Headphone Use

1. Plug headphones into the Headphone Jack on the front panel.
2. Audio will be routed to the headphones, and the built-in speakers will be muted.

## 6. Maintenance

### 6.1 Cleaning the Unit

- Wipe the exterior of the unit with a soft, dry cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

### 6.2 Stylus Care

- Handle the stylus carefully to avoid bending or damaging it.
- Clean the stylus periodically with a soft brush, brushing from back to front.
- Replace the stylus when sound quality deteriorates or if it is visibly damaged.

### 6.3 Record Care

- Keep records in their sleeves when not in use.
- Handle records by their edges to avoid touching the grooves.
- Clean records with a specialized record cleaning brush or solution.

## 7. Troubleshooting

Refer to the table below for common issues and their solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| No power | Power cord not connected; Outlet not active | Ensure power cord is securely plugged in; Test outlet with another device. |
| No sound | Volume too low; Incorrect input selected; Headphones connected | Increase volume; Select correct input mode; Disconnect headphones. |
| Turntable not spinning | Unit not powered on; Speed setting incorrect | Ensure unit is on; Verify correct speed (33/45/78 RPM) is selected. |
| Poor FM reception | Antenna not extended or positioned incorrectly | Extend and adjust the FM wire antenna for better signal. |
| Bluetooth device not pairing | Unit not in pairing mode; Device too far | Ensure Victrola Navigator is in Bluetooth mode and indicator is flashing; Move device closer to the unit. |

## 8. Specifications

- **Model:** VTA-600B-BLK
- **Product Dimensions:** 10 x 18.2 x 13.2 inches (25.4 x 46.2 x 33.5 cm)
- **Item Weight:** 16.5 pounds (7.5 kg)
- **Power Input:** AC 100-240V ~ 50/60Hz
- **Turntable Speeds:** 33 1/3, 45, 78 RPM
- **Bluetooth Version:** (Not specified, typically 4.0 or higher)
- **Included Components:** Bluetooth Record Player, Remote Control, 45 RPM Adapter
- **Material:** Plastic, Wood




Image: A diagram showing the dimensions of the Victrola Navigator, mahogany model. The width is 18 inches (460mm), depth is 13.2 inches (335mm), and height is 9.6 inches (243mm). This provides precise measurements for placement.

## 9. Warranty Information

Victrola products are designed and manufactured to the highest quality standards. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Victrola website. Keep your proof of purchase for warranty claims.

## 10. Support

For further assistance, technical support, or customer service inquiries, please visit the official Victrola website or contact their customer support team. You can often find FAQs and additional resources online.

**Victrola Official Website:** www.victrola.com