Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Victrola VTA-600B-ESP

Victrola Navigator 8-in-1 Bluetooth Record Player

Model: VTA-600B-ESP

Brand: Victrola

Product Overview

The Victrola Navigator 8-in-1 Solid Wood Record Player is a versatile entertainment center blending vintage aesthetics with modern technology. It offers multiple playback options and is designed for ease of use in any living space.

Key Features

- 8-in-1 Entertainment Center: Includes 3-speed turntable, CD player, cassette tape player, FM radio, Bluetooth, Auxiliary Input, USB port, and Headphone Jack.
- Built-in Speakers: Integrated speakers provide immediate audio playback without additional equipment.
- 3-Speed Belt-Driven Turntable: Supports 33 1/3, 45, and 78 rpm records for comprehensive vinyl playback.
- Expanded Connectivity: Features RCA Line outputs for connecting external speakers or amplifiers, and Bluetooth out technology.
- Full Function Remote Control: Convenient control over various functions from a distance.



The Victrola Navigator 8-in-1 Record Player, showcasing its classic wooden design and integrated controls.

Setup Guide

Unpacking and Placement

- Carefully remove the unit from its packaging.
- Place the unit on a flat, stable surface away from direct sunlight, heat sources, or excessive dust.
- Ensure adequate ventilation around the unit.
- Connect the power cord to a suitable AC outlet.

Turntable Preparation

- Remove the protective cap from the stylus (needle).
- Gently release the tonearm from its rest.
- For optimal FM radio reception, extend the wire antenna located at the back of the unit. Adjust its position for

best signal.



The Victrola Navigator ready for use, demonstrating the ease of inserting a CD.

Operating Your Victrola Navigator

The Victrola Navigator offers multiple ways to enjoy your audio. Use the function buttons on the front panel or the remote control to select your desired mode.

Turntable Operation (PHONO)

- Lift the lid and place a vinyl record on the platter.
- Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
- Gently lift the tonearm and position the stylus over the desired track on the record.
- Lower the tonearm slowly onto the record. Playback will begin.
- At the end of the record, the tonearm will automatically return to its rest (auto-stop feature). Manually lift and

return the tonearm if needed.

CD Player Operation (CD/USB)

- Press the 'EJECT' button to open the CD tray.
- Place a CD into the tray with the label side facing up.
- Press the 'EJECT' button again to close the tray. The unit will read the CD.
- Use the Play/Pause, Forward, Rewind, Shuffle, and Repeat buttons to control playback.

Cassette Player Operation (TAPE)

- Insert a cassette tape into the slot on the side of the unit.
- The tape will begin playing automatically.
- To fast forward, partially push the tape into the slot. To eject, fully push the tape into the slot. Note: Rewind is not available directly on the unit; you must flip the tape to rewind.



Side view of the Victrola Navigator, highlighting the integrated cassette tape player.

FM Radio Operation (AM/FM)

- Select the AM/FM function.
- Rotate the 'TUNING' knob to select your desired radio station.
- Adjust the volume using the 'VOLUME' knob.

Bluetooth Streaming (AUX/BT)

- Select the AUX/BT function. The unit will enter Bluetooth pairing mode.
- On your Bluetooth-enabled device, search for 'Victrola Navigator' and pair.
- Once paired, you can stream audio from your device to the Victrola Navigator.
- To connect to external Bluetooth speakers, use the 'PAIR/BT OUT' button.

USB Playback (CD/USB)

- Insert a USB flash drive into the USB port.
- The unit will automatically detect and begin playing compatible audio files.
- Use the playback controls (Play/Pause, Folder Up/Down) to navigate your music.

Auxiliary Input (AUX IN)

- Connect an external audio device (e.g., MP3 player, smartphone) to the 'AUX IN' jack using a 3.5mm audio cable.
- Select the AUX/BT function. Audio from your external device will play through the Victrola Navigator.

Headphone Jack

- For private listening, plug your headphones into the headphone jack on the front panel. The built-in speakers will mute automatically.

RCA Line Outputs

- To connect the Victrola Navigator to external speakers or an amplifier, use RCA cables (not included) to connect the 'LINE OUT' jacks on the back of the unit to your external audio system.



The rear panel of the Victrola Navigator, illustrating the RCA Line Out ports for connecting to external audio systems.

Remote Control

- The included remote control allows for convenient operation of most functions, including volume, mode selection, and playback controls for CD/USB.
- Note: The remote control does not have a power on/off button; the unit must be powered on manually.

Care and Maintenance

- Keep the unit clean by wiping it with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Regularly clean the turntable stylus with a soft brush designed for stylus cleaning.
- When not in use, ensure the tonearm is secured in its rest to prevent damage to the stylus.
- Keep the lid closed when not playing records to protect the turntable from dust. The lid features a safety support to prevent accidental closing.

Troubleshooting Common Issues

Problem	Possible Cause / Solution
Low vinyl sound	Ensure the volume is turned up sufficiently. Verify the stylus is properly seated on the record. If connecting to external speakers, ensure they are powered on and correctly connected.
Bluetooth lag or skipping	Ensure your Bluetooth device is within range (approx. 30 feet). Minimize interference from other wireless devices. Try re-pairing the device.
Poor FM radio reception	Adjust the position of the wire antenna on the back of the unit. Try relocating the unit to an area with better signal.
Volume knob not adjusting audio	Ensure the unit is powered on and the correct input source is selected. If using headphones, ensure they are fully plugged in. If the issue persists, contact customer support.
Cassette tape controls are limited	The cassette player is designed for basic playback. Fast forward is available by partially inserting the tape; full rewind requires flipping the tape.

Technical Specifications

Feature	Specification
Product Dimensions	10 x 18.2 x 13.2 inches
Item Weight	16.5 pounds
Item Model Number	VTA-600B-ESP
Brand	Victrola
Connectivity Technology	Bluetooth
Maximum Rotational Speed	78 RPM
Included Components	Bluetooth Record Player
Special Feature	Built In Speaker, AUX Input, RCA Output
Material	Engineered Wood, Plastic
Color	Espresso
Model Name	Navigator



Detailed dimensions of the Victrola Navigator 8-in-1 Record Player.

Warranty and Support

For detailed warranty information and further support, please refer to the official user manual or visit the Victrola brand store.

- Download User Manual (PDF)
- Visit Victrola Brand Store on Amazon

© 2025 Victrola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XJFK5KG

More documents and user manuals: **https://manuals.plus/**