Disney Princess 53114

Disney Princess Style Collection Travel Vanity Playset Instruction Manual

Model: 53114

Introduction

This manual provides instructions for the assembly, operation, and care of your Disney Princess Style Collection Travel Vanity Playset. Please read all instructions carefully before use and retain this manual for future reference.
The Disney Princess Style Collection Travel Vanity is designed for imaginative play, featuring a light-up mirror, storage, and various beauty accessories. Its portable design allows for easy transport and setup.



Image: The Disney Princess Style Collection Travel Vanity Playset in its open configuration, showcasing the light-up mirror and accessory trays. A child is shown interacting with the playset.

Safety Information

- **Recommended Age:** This product is recommended for ages 3 years and up.
- **Battery Safety:** Requires 3 AA batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries from the product. Remove batteries if product is not to be used for an extended period.
- **Choking Hazard:** Small parts may be present. Not suitable for children under 3 years.
- **Adult Supervision:** Adult supervision is recommended during play.

Package Contents

Ensure all items listed below are present in your package:

- 1 x Travel Vanity Playset

- 1 x Hairspray bottle with lid
- 1 x Moisturizer tube
- 1 x Conditioner bottle
- 1 x Shampoo bottle
- 1 x Powder bottle with lid
- 1 x Hair brush



Image: A collection of play beauty accessories including a hairspray bottle, moisturizer tube, conditioner bottle, shampoo bottle, powder bottle, and a hair brush.

Setup Instructions

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport if desired.
2. **Battery Installation:**
    - Locate the battery compartment, typically on the back or bottom of the vanity.
    - Using a screwdriver (not included), open the battery compartment cover.
    - Insert 3 AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
    - Replace the battery compartment cover and secure it with the screw.
3. **Unfolding the Vanity:**
    - Place the vanity on a flat, stable surface.
    - Gently open the top lid of the vanity to reveal the mirror and internal compartments.
    - Extend the folding legs from the base of the vanity until they lock securely into place.
    - Pull out the fold-out drawers from the inside of the vanity to access additional storage and accessory trays.



Image: The vanity fully opened, showing the extended legs, light-up mirror, and the pull-out trays with various play beauty accessories.

Operating Instructions

1. **Activating the Light-Up Mirror:**
    - Once batteries are installed, locate the power button for the mirror lights. This is typically a small button near

the mirror frame.
    - Press the button to turn the lights on. Press again to turn them off.
2. **Using Accessories:**
    - The included play hairspray, moisturizer, conditioner, shampoo, and powder bottles are for imaginative play only and do not contain actual cosmetic products.
    - Use the hair brush for pretend styling.
3. **Storage and Portability:**
    - To close the vanity for storage or travel, push the fold-out drawers back into the main compartment.
    - Fold the legs inward until they are flush with the vanity base.
    - Close the top lid securely. The integrated handle allows for easy carrying.

Maintenance and Care

- **Cleaning:** Wipe the vanity and accessories with a soft, damp cloth. Do not immerse in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight when not in use.
- **Battery Replacement:** Replace batteries when the mirror lights dim or stop working.

Troubleshooting

Problem	Possible Cause	Solution
Mirror lights do not turn on.	Batteries are not installed. Batteries are installed incorrectly. Batteries are depleted. Power button is not pressed.	Install 3 AA batteries. Check battery polarity (+/-). Replace with new AA batteries. Press the power button firmly.
Vanity legs do not stay extended.	Legs are not fully extended or locked.	Ensure legs are fully extended until they click into their locked position.
Drawers are difficult to open/close.	Obstruction or misalignment.	Check for any items blocking the drawers. Gently guide them along their tracks.

Product Specifications

- **Model Number:** 53114
- **Brand:** Disney Princess
- **Product Dimensions:** 10 x 14 x 7 inches (L x W x H, approximate)
- **Item Weight:** 0.96 ounces
- **Power Source:** 3 AA batteries (not included)
- **Recommended Age:** 36 months - 6 years
- **Manufacturer:** Disney

Official Product Video



Video: An official product video demonstrating the features and play patterns of the Disney Princess Style Collection Travel Vanity Playset, including its portability, light-up mirror, and various accessories.

© 2023 Disney Princess. All rights reserved.

For customer support, please refer to the contact information provided with your purchase.