Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RC-057

ZdalaMit RC-057 Replacement Remote Control User Manual

For COBY TV Models: TFTV1925, TFTV2225, LEDTV1935, LEDTV2326, LEDTV3226, LEDTV5536, LEDVD1596, TFTV2425, TFTV4028, TFTV3229, LEDTV1926

1. Product Overview

The ZdalaMit RC-057 is a replacement remote control designed for specific COBY television models. This remote provides full functionality for your compatible COBY TV without requiring any complex programming or pairing procedures. Simply insert batteries, and it is ready for immediate use.



A black remote control with various gray buttons for power, numbers, navigation, volume, channel, menu, and other TV functions. The model number 'RC-057' is printed at the bottom.

2. Setup

2.1 Battery Installation

The RC-057 remote control requires two (2) AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

2.2 Initial Use

This remote control is pre-programmed for compatible COBY TV models. No additional programming or pairing is required. Once batteries are installed, the remote is ready for immediate use with your television.

3. Operating Instructions

Familiarize yourself with the buttons and their functions for optimal control of your COBY TV.

Button	Function
Power (Red)	Turns the TV on or off.
Mute (Icon)	Mutes or unmutes the TV audio.
0-9	Direct selection of channels or inputting numbers.
RETURN	Returns to the previous channel or menu screen.
P.SIZE	Adjusts the picture size or aspect ratio.
P.MODE	Cycles through preset picture modes (e.g., Standard, Dynamic, Movie).
Directional Arrows (Up/Down/Left/Right)	Navigates through menus and options.
OK	Confirms selections in menus.
SLEEP	Sets the TV sleep timer.
EXIT	Exits the current menu or on-screen display.
VOL + / **-**	Increases or decreases the volume level.
CH Up / **Down**	Changes the TV channel up or down.
MENU	Opens the main TV menu.
LIST	Displays the channel list.
FAV	Accesses favorite channels.
MUTE (Text)	Mutes or unmutes the TV audio. (Redundant with icon mute, but present on remote).

Button	Function
CC	Activates or deactivates Closed Captions.
SOURCE	Selects the input source (e.g., HDMI, AV, Component).
LANG	Changes the audio language or SAP (Secondary Audio Program).
INFO	Displays on-screen information about the current program or input.

4. Compatible TV Models

This ZdalaMit RC-057 replacement remote control is compatible with the following COBY TV models:

- TFTV1925
- TFTV2225
- LEDTV1935
- LEDTV2326
- LEDTV3226
- LEDTV5536
- LEDVD1596
- TFTV2425
- TFTV4028
- TFTV3229
- LEDTV1926

5. Important Notes

- This remote control is specifically designed for the listed COBY TV models.
- It will **NOT** program or control other devices such as DVD players, cable boxes, soundbars, or other brands of televisions.
- Ensure fresh AAA alkaline batteries are used for optimal performance.

6. Troubleshooting Guide

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm that the remote is pointed directly at the TV's sensor.
- **Specific Buttons Not Working:**
  - This may indicate a faulty button or a specific TV setting. Try a full battery replacement first.
  - Ensure your TV model is listed in the compatible models section.

7. Product Specifications

- **Model Number:** RC-057
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Product Dimensions:** 7 x 0.5 x 2 inches (approximately)
- **Item Weight:** 1.41 ounces (approximately, without batteries)
- **Color:** Black
- **Compatible Devices:** COBY Televisions (specific models listed)

8. Warranty and Customer Support

For any queries or issues regarding your ZdalaMit RC-057 replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Refer to your purchase documentation for specific warranty information, as it may vary by retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XPC9X2K

More documents and user manuals: **https://manuals.plus/**