Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine Universal Replacement Remote Control

User Manual: JustFine Replacement Remote Control

Model: Universal Replacement Remote Control

1. Introduction and Overview

This manual provides instructions for the JustFine Replacement Remote Control, designed to be compatible with various Sharp AQUOS LED LCD HD TV models. This remote is a direct replacement and comes pre-programmed for immediate use.

Compatible Sharp TV Models include: LC70LE655U, LC70C6500U, LC-60LE633U, LC80LE632UN, LC-46LE832U, and other AQUOS LED LCD HD TVs with Netflix and 3D button functionality.

Key Features:

- Direct replacement for original Sharp TV remotes.
- Pre-programmed for immediate use; no additional programming required.
- Includes dedicated Netflix and 3D buttons.
- Ergonomic design for comfortable handling.



Figure 1: Front view of the remote control, displaying its various buttons and layout.

2. Setup

This remote control is designed for immediate use with compatible Sharp TV models. No complex programming is required.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Figure 2: Back view of the remote control, highlighting the battery compartment.

Once batteries are installed, the remote control is ready to operate your compatible Sharp TV.

3. Operating Instructions

The remote control functions identically to the original Sharp TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

3.1 Basic Functions

- **POWER:** Turns the TV on or off.
- **INPUT:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the television channel.
- **MUTE:** Mutes or unmutes the TV audio.
- **Number Buttons (0-9):** Directly enter channel numbers.
- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **ENTER:** Confirms selections in menus.

- **EXIT:** Exits the current menu or screen.
- **RETURN:** Returns to the previous screen or menu.

3.2 Special Functions

- **NETFLIX:** Direct access button for the Netflix application.
- **3D:** Activates or deactivates 3D mode on compatible TVs.
- **FAV APP:** Accesses favorite applications.
- **DISPLAY (QS):** Displays on-screen information.
- **OPTION:** Accesses context-sensitive options.
- **SLEEP:** Sets a sleep timer for the TV.
- **AUDIO:** Changes audio settings or tracks.
- **FREEZE:** Freezes the current image on screen.
- **CC:** Activates or deactivates Closed Captions.
- **AV MODE:** Cycles through audio/video modes.
- **VIEW MODE:** Changes screen display modes.
- **SMART CENTRAL:** Accesses Smart TV features.

4. Maintenance

4.1 Cleaning the Remote

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or excessive moisture, as this can damage the remote's electronics.

4.2 Battery Replacement

Replace batteries when the remote's performance degrades (e.g., reduced range, unresponsive buttons). Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Dispose of used batteries according to local regulations.

5. Troubleshooting

Problem	Possible Cause / Solution
Remote is not working or unresponsive.	• Check if batteries are inserted correctly with correct polarity (+/-). • Replace old batteries with new AAA batteries. • Ensure there are no obstructions between the remote and the TV's infrared sensor. • Point the remote directly at the TV.

Problem	Possible Cause / Solution
Remote only works at close range or at a specific angle.	• Batteries may be low; replace them. • Ensure the TV's infrared sensor is clean and not obstructed. • Verify that the remote's infrared emitter (at the front tip) is not blocked or dirty.
Certain buttons do not function.	• Ensure the remote is compatible with your specific TV model's features. • Clean the remote, as dirt or debris might be interfering with button contacts. • If the issue persists after battery replacement and cleaning, the remote may be faulty.

6. Specifications

Feature	Detail
Brand	JustFine
Compatible Devices	Sharp AQUOS LED LCD HD Televisions
Connectivity Technology	Infrared (IR)
Special Feature	Ergonomic design, Pre-programmed
Max Number of Supported Devices	1 (Television)
Product Dimensions	8 x 2 x 0.5 inches
Item Weight	2.72 ounces
Batteries Required	2 x AAA (not included)

7. Warranty and Support

This product is sold with a money-back guarantee and hassle-free return policy. A 30-day quality warranty is provided from the date of purchase.

For any problems, questions, or support inquiries regarding your JustFine Replacement Remote Control, please contact the seller directly via email. Refer to your purchase documentation for specific contact details.

Note: This remote is pre-programmed and cannot be reprogrammed.

© 2023 JustFine. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XPNTB9Z

More documents and user manuals: **https://manuals.plus/**