Disney PJ17024

Disney PJ Masks PJ17024 Digital LED Watch User Manual

Model: PJ17024 | Brand: Disney

1. Introduction

This manual provides essential information for the safe and effective use of your Disney PJ Masks PJ17024 Digital LED Watch. Please read this manual thoroughly before operating the device and retain it for future reference.

2. Product Overview

The Disney PJ Masks PJ17024 Digital LED Watch is a digital LED watch designed for children, featuring popular PJ Masks characters. It is a high-quality, officially licensed product that combines fun with functionality.

Key Features:

- Digital display with LED light.
- Features PJ Masks characters on the watch face.
- Designed for young users.



Figure 2.1: PJ Masks Digital LED Watch and its packaging. The watch features a clear strap and a blue bezel with PJ Masks characters. The digital display shows '88:88'.

3. Setup

3.1 Unboxing

Carefully remove the watch from its packaging. Ensure all components are present. The package should contain the PJ Masks Digital LED Watch.

3.2 Battery Installation/Activation

The watch comes with a pre-installed LR44 battery. If the display is not active, check for a plastic pull-tab near the crown (side button) and remove it to activate the battery. If the battery needs replacement, refer to the Maintenance section.

4. Operating Instructions

4.1 Setting the Time

1. Press the button on the side of the watch to display the time.
2. To enter setting mode, press and hold the button for approximately 3 seconds until the hour digits begin to flash.
3. While the hour digits are flashing, press the button repeatedly to advance the hour.
4. Once the correct hour is set, press and hold the button again for 3 seconds. The minute digits will begin to flash.
5. Press the button repeatedly to advance the minutes.
6. After setting the minutes, press and hold the button for 3 seconds to exit setting mode. The time will now be set.

4.2 Activating LED Light

Press the button once briefly to illuminate the LED light on the watch face. The light will typically stay on for a few seconds before automatically turning off to conserve battery life.

5. Maintenance

5.1 Cleaning

Wipe the watch with a soft, dry cloth. Do not use abrasive cleaners or solvents. Avoid submerging the watch in water.

5.2 Battery Replacement

The watch uses one LR44 battery. When the display becomes dim or unresponsive, it's time to replace the battery. This procedure should ideally be performed by an adult.

1. Locate the battery compartment cover on the back of the watch.
2. Using a small screwdriver, carefully open the battery compartment.
3. Remove the old LR44 battery and insert a new one, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover.

Note: *Dispose of used batteries responsibly according to local regulations.*

6. Troubleshooting

Problem	Possible Cause	Solution
Watch display is blank or dim.	Battery is dead or not properly installed.	Replace the LR44 battery or ensure the battery activation tab is removed.
Time cannot be set.	Incorrect button press sequence.	Refer to "4.1 Setting the Time" and follow the steps carefully. Ensure you hold the button for 3 seconds to enter/exit setting mode.
LED light does not activate.	Low battery or faulty LED.	Replace the battery. If the problem persists, contact customer support.

7. Specifications

Feature	Detail

Feature	Detail
Model Number	PJ17024
Brand	Disney
Product Dimensions	7.5 x 16 x 7.5 cm
Weight	50 grams
Battery Type	1 x LR44 (included)
Manufacturer	KIDS EUROSWAN

8. Warranty Information

Specific warranty details for this product may vary by region and retailer. Please refer to your purchase receipt or contact the retailer where the product was purchased for information regarding warranty coverage and terms.

9. Customer Support

For further assistance or inquiries regarding your PJ Masks Digital LED Watch, please contact the retailer or the manufacturer, KIDS EUROSWAN. Contact information can typically be found on the product packaging or the retailer's website.

© 2023 Disney. All rights reserved. PJ Masks © Frog Box / Entertainment One UK Limited / Walt Disney EMEA Productions Limited 2016.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question