Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BN59-01179A

ZdalaMit BN59-01179A Replacement Remote Control User Manual

For Samsung Smart TVs

1. Introduction

This manual provides instructions for the ZdalaMit BN59-01179A replacement remote control, designed for various Samsung Smart TV models. This remote control is a direct replacement and requires no programming or pairing. Simply install the batteries, and it is ready for immediate use.

2. Setup: Battery Installation

To begin using your remote control, you must first install the batteries. Follow these steps:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Rear view of the remote control with the battery cover removed, illustrating correct AAA battery placement.

Important: Use only AAA alkaline batteries. Do not use rechargeable batteries, as they may not provide sufficient power or may cause damage to the remote control.

3. Operating Instructions

Once batteries are installed, the remote control is ready for use with your compatible Samsung TV. Point the remote directly at your television's infrared receiver.



Figure 2: Front view of the remote control, highlighting the button layout.

Key Button Functions:

- **POWER (●)**: Turns the TV on or off.
- **SOURCE**: Selects the input source (e.g., HDMI 1, AV).
- **STB GUIDE / STB MENU**: Functions related to a Set-Top Box, if connected.
- **Number Buttons (0-9)**: Directly select channels.
- **VOL (+/-)**: Adjusts the volume level.

- **MUTE**: Mutes or unmutes the TV sound.
- **CH (▲/▼)**: Changes channels up or down.
- **MENU**: Accesses the TV's main menu.
- **GUIDE**: Displays the electronic program guide.
- **SMART HUB**: Accesses Samsung's Smart Hub for apps and streaming services.
- **TOOLS**: Provides quick access to common functions and settings.
- **INFO**: Displays information about the current program or input.
- **Directional Pad (Up, Down, Left, Right) & ENTER**: Navigates menus and confirms selections.
- **RETURN**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or application.
- **Colored Buttons (A, B, C, D)**: Special functions depending on the TV model or application.
- **P.SIZE**: Adjusts picture size/aspect ratio.
- **MTS**: Multi-Track Sound (audio language selection).
- **CC**: Closed Captions.
- **Playback Controls (◀◀, ▶, ▶▶)**: Control media playback (Rewind, Play/Pause, Fast Forward).

4. Compatible Samsung TV Models

This ZdalaMit BN59-01179A replacement remote control is compatible with the following Samsung TV models:

BN59-01179B
UN32H5500AF
UN32H5500AFXZA
UN32H6350AF
UN32H6350AFXZA
UN39H5204AF
UN39H5204AFXZA
UN40H5500AF
UN40H5500AFXZA
UN40H6350AF
UN40H6350AFXZA
UN48H5500AF
UN48H5500AFXZA
UN48H6300AF
UN48H6300AFXZA
UN48H6350AF
UN48H6350AFXZA
UN50H5500AF
UN50H5500AFXZA
UN50H6300AF
UN50H6300AFXZA
UN50H6350AF
UN50H6350AFXZA
UN55H6300AF

UN55H6300AFXZA

UN55H6350AF

UN55H6350AFXZA

UN55HU6840FX

UN55HU6840FXZA

UN60H6300AF

UN60H6300AFXZA

UN60H6350AF

UN60H6350AFXZA

UN65H6300AF

UN65H6300AFXZA

UN65H6350AF

UN65H6350AFXZA

UN75H6300AF

UN75H6300AFXZA

UN75H6350AF

UN75H6350AFXZA

UN105S9WAF

UN105S9WAFXZA

Un48h6350

Un50h6300

Un50h6350

Un55h6300

Un55h6350

Un60h6300

Un40h6350

Un60h6350

Un65h6300

Un48h6300

Un65h6350

Un75h6300

Un75h6350

Please verify your TV model number to ensure compatibility.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm that the remote is pointed directly at the TV.
- **Slow response or intermittent function:**
  - This can often be resolved by replacing the batteries, even if they are not completely drained.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the TV's IR receiver.

- **Remote does not control TV functions:**
  - Verify that your TV model is listed in the "Compatible Samsung TV Models" section. This remote is a direct replacement and does not require programming for compatible models.

6. Specifications

Model Number	BN59-01179A
Brand	ZdalaMit
Compatible Devices	Samsung Televisions
Power Supply	2 x AAA 1.5V Alkaline Batteries (Not Included)
Special Feature	Pre-Programmed (No setup required for compatible models)
Color	Black
Product Dimensions	7 x 2 x 0.65 inches
Item Weight	2.89 ounces

7. Maintenance

- Keep the remote control clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote to extreme temperatures, direct sunlight, or moisture.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

8. Support

For any questions or assistance regarding your ZdalaMit BN59-01179A replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XT3R53B

More documents and user manuals: **https://manuals.plus/**