Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit GA806WJSA

ZdalaMit GA806WJSA Replacement Remote Control User Manual

Model: GA806WJSA | Brand: ZdalaMit

Introduction

This manual provides instructions for the ZdalaMit GA806WJSA replacement remote control. This remote is designed to be compatible with various Sharp AQUOS TV models, including LC40LE700UN, LC46LE700UN, and LC52LE700UN. No programming or pairing is required for operation; simply install batteries and begin use.

Setup

Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open it.
3. Insert two (2) 1.5V AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery insertion process.

Operating the Remote Control

Once batteries are installed, the remote control is ready for immediate use with compatible Sharp AQUOS TV models. Point the remote directly at the TV's infrared receiver.



Image: Front view of the ZdalaMit GA806WJSA remote control, showing the layout of all buttons.

Button Functions

- **Power:** Turns the TV on or off.
- **Mute:** Mutes or unmutes the TV audio.
- **TV:** Selects the TV input.
- **AUDIO/BD/DVD/VCR/CBL/SAT:** Selects various input sources.
- **SOURCE/DISPLAY:** Cycles through available input sources or displays information.

- **Number Buttons (0-9):** Directly select channels.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel.
- **INPUT:** Cycles through available input sources.
- **MENU:** Opens the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **ENTER:** Confirms selections in menus.
- **EXIT:** Exits the current menu or screen.
- **RETURN:** Returns to the previous screen or menu.
- **FAVORITE CH (A, B, C, D):** Accesses preset favorite channels or functions.
- **SLEEP:** Sets the TV sleep timer.
- **AUDIO:** Changes audio settings or tracks.
- **AV MODE:** Cycles through audio/video modes.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

Troubleshooting

- **Remote not responding:** Ensure the batteries are correctly installed and are not depleted. Replace with fresh batteries if necessary.
- **Short operating range:** Check for obstructions between the remote and the TV's infrared sensor. Ensure the remote is pointed directly at the TV.
- **Specific buttons not working:** Clean the remote's surface to ensure no debris is interfering with button presses. If the issue persists after battery replacement, the remote may require replacement.
- **TV not compatible:** Verify that your Sharp AQUOS TV model is listed as compatible with the GA806WJSA remote control.

Specifications

- **Model Number:** GA806WJSA
- **Product Dimensions:** 9.13 x 1.99 x 0.55 inches
- **Item Weight:** 3 ounces
- **Power Supply:** 2 x 1.5V AAA Batteries (not included)
- **Compatible Devices:** Sharp AQUOS Televisions (e.g., LC40LE700UN, LC46LE700UN, LC52LE700UN)
- **Color:** Black
- **Special Feature:** Ergonomic design

Warranty and Support

For any questions, concerns, or support regarding your ZdalaMit GA806WJSA replacement remote control, please contact the manufacturer or your retailer. Specific warranty details may vary; please refer to your purchase documentation for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XT7QJ68

More documents and user manuals: **https://manuals.plus/**