Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hendi 838617

HENDI Frying Pan Kitchen Line 838617 User Manual

Model: 838617

Introduction

This manual provides essential information for the safe and efficient use of your HENDI Kitchen Line Frying Pan, model 838617. Please read these instructions carefully before first use and retain them for future reference.



Image: HENDI Kitchen Line Frying Pans. This image displays three frying pans, varying in diameter, stacked one inside the other. They feature a polished aluminum exterior and long, sturdy handles, indicating a professional kitchen design.

Safety Instructions

- Always use oven mitts or pot holders when handling the hot frying pan.
- Do not leave the pan unattended on a heat source.
- Ensure the pan is stable on the cooktop to prevent spills or accidents.
- Keep out of reach of children.
- Avoid sudden temperature changes, which can warp the pan.

Setup and First Use

1. **Unpacking:** Carefully remove the frying pan from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash the pan thoroughly with warm soapy water and a soft sponge. Rinse completely and dry immediately to prevent water spots.
3. **Seasoning (Optional for Aluminum):** While not strictly necessary for aluminum, some users prefer to lightly season the pan. Heat a small amount of cooking oil in the pan over low heat for a few minutes, then wipe out excess oil.

Operating Instructions

Compatible Cooktops

This HENDI frying pan is designed for use on various cooktops, including:

- Gas stoves
- Smooth surface induction cooktops
- Electric cooktops

The encapsulated sandwich type bottom combines aluminum's heat distribution with steel's magnetic properties, ensuring optimal performance on induction surfaces.

Cooking Guidelines

- **Heat Management:** Start with medium heat and adjust as needed. The pan's construction ensures efficient heat conduction, so high heat may not always be necessary.
- **Oil/Fat Usage:** Always use a small amount of cooking oil or fat to prevent food from sticking and to enhance flavor.
- **Utensils:** Use heat-resistant silicone, wood, or plastic utensils to avoid scratching the pan's surface.
- **Recommended Uses:** Ideal for frying, sautéing, searing, and griddling.

Maintenance and Cleaning

Daily Cleaning

- Allow the pan to cool completely before cleaning.
- Wash with warm soapy water and a non-abrasive sponge or cloth.
- For stubborn food residues, soak the pan in warm soapy water for a short period before cleaning.
- Rinse thoroughly and dry immediately to maintain the satin finish and prevent water spots.

Dishwasher Use

This frying pan is **dishwasher safe**. However, hand washing is recommended to prolong the life and appearance of the pan, especially to maintain the satin finish of all outer surfaces.

Storage

Store the pan in a dry place. If stacking with other cookware, place a soft cloth or pan protector between them to prevent scratches.

Troubleshooting

Problem	Possible Cause	Solution
Food sticking to the pan	Insufficient oil/fat; pan not hot enough; pan too hot.	Ensure adequate oil/fat. Preheat pan properly before adding food. Adjust heat to medium.
Pan not heating on induction cooktop	Cooktop not recognizing the pan; pan not centered.	Ensure the pan is correctly centered on the induction zone. Check if the cooktop is compatible with the pan's base diameter.
Discoloration or stains	Hard water deposits; overheating; certain foods.	Clean with a mixture of vinegar and water, or a specialized stainless steel cleaner. Avoid abrasive cleaners.

Specifications

Feature	Detail
Model Number	838617
Brand	Hendi
Material	Aluminum with encapsulated sandwich bottom (aluminum core, steel exterior)
Dimensions	320 mm diameter x 55 mm height
Wall Thickness	0.7 mm
Capacity	4.2 liters
Color	Polished Aluminium
Compatible Devices	Gas, Smooth Surface Induction
Product Care	Dishwasher Safe
Item Weight	1.44 kg
Included Components	Frying pan - without lid

Warranty and Support

For warranty information or product support, please contact Hendi customer service directly. Refer to the original product packaging or the Hendi official website for contact details.
Manufacturer: Hendi
Model Number: 838617

© 2023 Hendi. All rights reserved.
This manual is for informational purposes only. Hendi is not responsible for any damages or injuries resulting from improper use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XYLPHST

More documents and user manuals: **https://manuals.plus/**