Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

allimity RM-ED016-IT

ALLIMITY RM-ED016 Replacement Remote Control User Manual

Model: RM-ED016-IT

Introduction

This manual provides comprehensive instructions for the ALLIMITY RM-ED016 Replacement Remote Control. This remote is designed to function as a direct replacement for original Sony LED LCD Bravia TV remote controls, offering immediate usability without complex setup procedures. Please read this manual carefully to ensure proper operation and longevity of your remote control.

Product Overview





Figure 1: ALLIMITY RM-ED016 Replacement Remote Control

This image displays the front view of the ALLIMITY RM-ED016 remote control, showcasing its button layout and design. The remote is black with clearly labeled buttons for various TV functions.

Key Features:

- Direct replacement, no programming required.
- Compatible with a wide range of Sony LED LCD Bravia TV models.
- Standard button layout for intuitive use.

Setup

Battery Installation:

The ALLIMITY RM-ED016 remote control requires two AAA alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Sony Bravia TVs. No additional pairing or programming is required.

Operating Instructions

The ALLIMITY RM-ED016 remote control features a standard layout for easy navigation and control of your Sony Bravia TV. Below is a description of common button functions:

Button/Section	Function
Power (I/O)	Turns the TV on or off.
Number Buttons (0-9)	Direct channel selection.
PROG (+/-)	Changes TV channels up or down.
Volume (+/-)	Adjusts the TV volume up or down.
Mute	Mutes or unmutes the TV sound.
Input/Source	Switches between different input sources (HDMI, AV, etc.).
Menu	Opens the TV's main menu.
Navigation (Up, Down, Left, Right, Enter)	Navigates through menus and confirms selections.
Return/Back	Goes back to the previous screen or menu.
Guide	Displays the electronic program guide (EPG).
Digital/Analog	Switches between digital and analog TV modes.
Colored Buttons (Red, Green, Yellow, Blue)	Functionality varies depending on the TV model and current menu/application.
BRAVIA Sync	Controls connected BRAVIA Sync compatible devices.
Playback Controls (Play, Pause, Stop, Rewind, Fast Forward)	Controls media playback on connected devices or TV's media player.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control or expose it to extreme temperatures, humidity, or direct sunlight.

Troubleshooting

Problem	Possible Solution

Problem	Possible Solution
Remote control not working.	◦ Check if batteries are inserted correctly with correct polarity (+/-). ◦ Replace old batteries with new ones. ◦ Ensure there are no obstructions between the remote and the TV's IR sensor. ◦ Confirm the remote is pointed directly at the TV.
Some buttons do not respond.	◦ Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris. ◦ Ensure the TV model is listed as compatible.
Remote works intermittently.	◦ Batteries may be low; replace them. ◦ Ensure no strong light sources (like direct sunlight or fluorescent lights) are interfering with the IR signal.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	RM-ED016-IT
Connectivity Technology	Infrared (IR)
Number of Keys	25
Controller Type	Button Control
Maximum Range	10 meters
Battery Type	2 x AAA Alkaline (not included)
Product Dimensions	5 x 0.49 x 15.8 cm
Weight	70 grams
UPC	606280077116

Feature	Detail
Compatible Devices	Sony LED LCD Bravia TV models including KDL-22E5300, KDL-22E5310, KDL-32V5500, KDL-32V5610, KDL-32V5800, KDL-32V5810, KDL-32W5500, KDL-32W5710, KDL-32W5720, KDL-32W5730, KDL-32W5730E, KDL-32W5740, KDL-32W5800, KDL-32W5810, KDL-32W5820, KDL-32W5830, KDL-32W5840, KDL-37V5500, KDL-37V5610, KDL-37V5800, KDL-37V5810, KDL-37W5500, KDL-37W5710, KDL-37W5720, KDL-37W5730, KDL-37W5740, KDL-37W5800, KDL-37W5810, KDL-37W5820, KDL-37W5830, KDL-37W5840, KDL-40V5500, KDL-40V5800, KDL-40V5810, KDL-40W5500, KDL-40W5720, KDL-40W5730, KDL-40W5740, KDL-40W5800, KDL-40W5810, KDL-40W5820, KDL-40W5830, KDL-40W5840, KDL-40WE5, KDL-40WE5W, KDL-46EX1, KDL-46V5500, KDL-46V5610, KDL-46V5800, KDL-46V5810, KDL-46W5500, KDL-46W5710, KDL-46W5720, KDL-46W5730, KDL-46W5740, KDL-46W5800, KDL-46W5810, KDL-46W5820, KDL-46W5830, KDL-46W5840, KDL-46WE5, KDL-52V5500, KDL-52V5610, KDL-52V5800, KDL-52V5810, KDL-52W5500, KDL-52W5800.

Warranty and Support

For warranty information or technical support regarding your ALLIMITY RM-ED016 Replacement Remote Control, please refer to the seller's return policy or contact the seller directly through the platform where the purchase was made. This product is designed for direct replacement and typically does not require specific software updates or extensive technical support beyond basic functionality.
For general inquiries or further assistance, please visit the ALLIMITY brand page or contact their customer service if available.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06Y2FTHX9

More documents and user manuals: **https://manuals.plus/**