Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 4330958156

JustFine Replacement Remote Control Instruction Manual

Model: 4330958156

Introduction
Setup
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

This manual provides instructions for the JustFine replacement remote control, designed for use with various Pioneer Home Theater AV Receiver Systems. This remote is pre-programmed and requires no additional setup for compatible models. It is a direct replacement for original remotes compatible with Pioneer VSX-324-K-P, AXD7569, VSX-822, VSX-916-K, and VSX-1022 models.

2. Setup: Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment. To install batteries, slide the cover off, insert two AAA batteries according to polarity, and then replace the cover.

Once batteries are installed, the remote is ready for use with your compatible Pioneer AV Receiver.

3. Basic Operation

This replacement remote is pre-programmed to function with the specified Pioneer AV Receiver models. Simply point the remote at your receiver and press the desired button.

- **Power Button:** Turns the receiver on or off.
- **Volume Up/Down:** Adjusts the audio output level.
- **Input Select:** Cycles through available audio/video input sources (e.g., CD, DVD, TV, Game).
- **Mute Button:** Toggles audio mute on and off.
- *Other buttons:* Refer to the original receiver's manual for specific functions of other buttons, as this remote replicates the original functionality.

4. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the receiver's infrared sensor.
  - Confirm the remote is pointed directly at the receiver.
- **Certain functions not working:**
  - This remote is a replacement and replicates the original. Some advanced functions or specific input names not present on the remote itself may not be directly accessible. Refer to your receiver's original manual for comprehensive functionality.

6. Specifications

Brand	JustFine
Model Number	4330958156
Compatible Devices	Pioneer VSX-324-K-P, AXD7569, VSX-822, VSX-916-K, VSX-1022 Home Theater AV Receivers
Connectivity Technology	Infrared
Batteries Required	2 x AAA (not included)
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces

7. Warranty and Support

This product is sold with a 30-day quality warranty. For any issues or support inquiries, please contact the seller directly. Hassle-free returns are available within the specified period.

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06ZYCX6JY

More documents and user manuals: **https://manuals.plus/**