iJoy LGO-PRE-RGD

iJoy Bluetooth Headphones User Manual

Model: LGO-PRE-RGD

1. Product Overview

The iJoy Bluetooth Headphones are designed for versatile audio enjoyment, offering both wireless Bluetooth and wired connectivity. With a comfortable over-ear design, built-in microphone, FM radio, and Micro SD card slot, these headphones provide a comprehensive listening experience.



Figure 1.1: iJoy Bluetooth Headphones (Rose Gold)

Key Features:

- **Wireless & Wired Connectivity:** Seamlessly switch between Bluetooth and 3.5mm AUX cable.
- **Integrated Controls:** Easy access to play/pause, volume, track navigation, and equalizer settings.
- **Built-in Microphone:** For hands-free calling.

- **FM Radio & Micro SD Card Slot:** Multiple audio source options.
- **Foldable Design:** Compact and portable for travel.
- **Comfortable Fit:** Soft protein padding and adjustable headband for extended wear.

2. What's in the Box

Upon unboxing your iJoy Bluetooth Headphones, please ensure all components are present:

- iJoy Bluetooth Headphones
- USB Charging Cable
- 3.5mm AUX Audio Cable



Figure 2.1: Included Accessories

3. Setup Guide

3.1 Charging the Headphones

Before first use, fully charge your iJoy Bluetooth Headphones. A full charge takes approximately 2 hours.

1. Locate the Micro Charging Port on the headphone ear cup.
2. Connect the smaller end of the provided USB Charging Cable to the headphone's charging port.
3. Connect the larger end of the USB Charging Cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light will illuminate during charging and turn off or change color when fully charged.



Figure 3.1: Micro Charging Port and 3.5mm AUX Port

3.2 Bluetooth Pairing

To connect your headphones wirelessly to a device:

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power/Multi-function button until the indicator light flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "iJoy Headphones" (or similar name) from the list of found devices.
5. Once connected, the indicator light will typically show a solid blue or slow flashing blue.

3.3 Wired Connection

For a wired connection, use the provided 3.5mm AUX Audio Cable:

1. Insert one end of the 3.5mm AUX Audio Cable into the 3.5mm AUX Plug-in Port on the headphones.

2. Insert the other end into the 3.5mm audio jack of your device.
3. The headphones will automatically switch to wired mode.

4. Operating Instructions

The iJoy Bluetooth Headphones feature intuitive controls located on the ear cup.



Figure 4.1: Control Buttons Overview

4.1 Basic Controls

- **Power ON/OFF:** Press and hold the Multi-function button.
- **Play/Pause:** Press the Multi-function button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

- **Equalizer (EQ):** Press the 'EQ' button to cycle through sound modes.

4.2 Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button.
- **Redial Last Number:** Double-press the Multi-function button.

4.3 FM Radio Mode

To use the built-in FM radio:

1. Press the 'M' (Mode) button to switch to FM Radio mode.
2. Press the Multi-function button once to auto-scan and save available FM stations.
3. Use the '+' and '-' buttons to navigate between saved stations.

4.4 Micro SD Card Playback

To play music from a Micro SD card:

1. Insert a Micro SD card with MP3 audio files into the Micro SD Card Slot.
2. The headphones will automatically switch to Micro SD card playback mode. If not, press the 'M' (Mode) button to select it.
3. Use the play/pause, volume, and track navigation controls as described above.

5. Maintenance and Care

To ensure the longevity and optimal performance of your iJoy Bluetooth Headphones, follow these care guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Avoid Moisture:** Do not expose the headphones to water or excessive moisture.
- **Handle with Care:** Avoid dropping or subjecting the headphones to strong impacts.
- **Charging:** Only use the provided charging cable or a certified equivalent. Do not overcharge.

6. Troubleshooting

If you encounter issues with your iJoy Bluetooth Headphones, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones won't turn on.	Low battery.	Charge the headphones for at least 2 hours.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (flashing blue/red). Turn device Bluetooth off/on. Move headphones closer to device (within 10 meters).

Problem	Possible Cause	Solution
No sound.	Volume too low; incorrect source selected; wired cable not fully inserted.	Increase headphone and device volume. Check mode (Bluetooth, FM, SD card, AUX). Ensure 3.5mm cable is fully inserted.
Poor sound quality.	Weak Bluetooth signal; audio file quality; ear cup fit.	Move closer to the Bluetooth device. Try a different audio file. Adjust headphones for a snug fit.
FM radio not working.	Poor signal; not in FM mode.	Move to an area with better FM reception. Press 'M' button to ensure FM mode is active, then auto-scan.

7. Specifications

Feature	Detail
Model Name	LGO-PRE-RGD
Connectivity Technology	Wired, Wireless (Bluetooth)
Bluetooth Range	Up to 10 meters
Headphones Jack	3.5 mm Jack (through included AUX cable)
Frequency Range	20 Hz - 20,000 Hz
Charging Time	Approx. 2 Hours
Ear Placement	Over Ear
Noise Control	Sound Isolation
Material	Memory Protein (ear cushions)
Item Weight	9.5 ounces

8. Warranty and Support

8.1 Warranty Information

Your iJoy Bluetooth Headphones come with a **6 MONTHS exchange warranty**. If your headset breaks or is damaged for any reason, Pranx will provide you with a FREE replacement.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Pranx customer support through the retailer's platform or their official website.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question