Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garmin 010-01750-05

Garmin Dash Cam 65 User Manual

Model: 010-01750-05

Introduction

The Garmin Dash Cam 65 is a small and discreet GPS-enabled dash camera designed to automatically record your drive in high-quality 1080p video. It features an extra-wide 180-degree field of view, capturing more of the environment, including cross-traffic. This device also provides advanced driver alerts, such as forward collision and lane departure warnings, and alerts for red light and speed cameras. Voice control allows for hands-free operation, enabling you to start/stop audio recording, take still pictures, or activate the Travelapse video capture feature. Footage can be easily synced wirelessly to your smartphone via the free VIRB Mobile app for viewing and sharing.

Setup

Before using your Garmin Dash Cam 65, ensure all components are present and follow these steps for initial setup.

What's in the Box:

- Garmin Dash Cam 65W
- Magnetic Mount
- Vehicle Power Cable
- USB Cable
- microSD Card
- Quick Start Manual

Installation Steps:

1. **Insert microSD Card:** Locate the microSD card slot on the side of the device and insert the included microSD card until it clicks into place.
2. **Mounting the Device:** Attach the magnetic mount to your vehicle's windshield in a location that does not obstruct your view of the road. Ensure the adhesive has sufficient time to set for a secure attachment. The camera then magnetically attaches to this mount.
3. **Power Connection:** Connect the vehicle power cable to the dash cam and plug the other end into your vehicle's power outlet. The device will automatically power on and begin recording when your vehicle starts.



Image: The Garmin Dash Cam 65 shown with its magnetic mount, illustrating how the camera attaches to the mount for windshield installation.

Operating Instructions

The Garmin Dash Cam 65 is designed for ease of use, with many features operating automatically.

Automatic Recording:

Once powered on, the dash cam automatically begins continuous loop recording. Older, unsaved footage is overwritten as the microSD card fills.

Incident Detection (G-Sensor):

In the event of an incident, the built-in G-Sensor automatically detects impacts and saves the current recording, protecting it from being overwritten. This footage is stored in a separate, protected folder on the microSD card.

Voice Control:

Use voice commands for hands-free control of key functions. Supported commands include:

- "OK Garmin, save video" - Saves the current video segment.
- "OK Garmin, take a picture" - Captures a still image.
- "OK Garmin, start Travelapse" - Initiates Travelapse video recording.
- "OK Garmin, stop audio" / "OK Garmin, start audio" - Controls audio recording.

Driver Alerts:

The dash cam provides audible and visual alerts for enhanced driving awareness:

- **Forward Collision Warning:** Alerts if you are driving too close to the vehicle ahead.
- **Lane Departure Warning:** Alerts if you drift out of your lane.
- **"Go" Alert:** Notifies you when stopped traffic ahead begins to move.
- **Red Light and Speed Camera Alerts:** Provides alerts for upcoming red light and speed cameras (availability varies by region).

VIRB Mobile App:

Download the free Garmin VIRB Mobile app to your smartphone to wirelessly connect to your Dash Cam 65. This allows you to view, edit, and share recorded videos and photos directly from your phone.



Image: The rear view of the Garmin Dash Cam 65, showing the 2.0-inch LCD screen and control buttons on the side, used for navigating menus and accessing features.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Garmin Dash Cam 65.

Cleaning the Lens:

Regularly clean the camera lens with a soft, lint-free cloth to ensure clear video recordings. Avoid abrasive materials or harsh chemicals that could scratch the lens.

MicroSD Card Management:

While the dash cam uses loop recording, it is recommended to periodically format the microSD card (at least once a month) to maintain its performance and prevent data corruption. This can typically be done through the device's settings menu or by connecting the card to a computer.

Firmware Updates:

Garmin periodically releases firmware updates to improve device performance, add new features, and resolve potential issues. It is recommended to keep your dash cam's firmware updated. Updates can usually be performed via the Garmin Express software on a computer.

Storage:

When not in use, store the dash cam in a cool, dry place away from direct sunlight and extreme temperatures to prevent damage to the internal components and battery.

Troubleshooting

If you encounter issues with your Garmin Dash Cam 65, refer to the following common solutions.

Device Not Powering On:

- Ensure the vehicle power cable is securely connected to both the dash cam and the vehicle's power outlet.
- Check if the vehicle's power outlet is functioning correctly.
- Verify that the vehicle's ignition is on or in accessory mode.

Recording Issues (e.g., blurry video, no recording):

- Clean the camera lens thoroughly.
- Ensure the microSD card is properly inserted and not full. Format the card if necessary (this will erase all data).
- Try using a different, compatible microSD card.

Voice Commands Not Responding:

- Ensure you are speaking clearly and directly towards the device.
- Check the device's settings to confirm voice control is enabled.
- Minimize background noise in the vehicle.

Overheating:

While the Dash Cam 65 is designed to operate in various temperatures, prolonged exposure to direct sunlight in a hot vehicle can cause it to temporarily shut down. If this occurs, allow the device to cool down before resuming operation.

Ensure it is mounted in a location with adequate airflow.

Connectivity Issues with VIRB App:

- Ensure Bluetooth and Wi-Fi are enabled on your smartphone.
- Restart both the dash cam and your smartphone.
- Ensure the VIRB app is updated to the latest version.

Specifications

Feature	Specification
Product Dimensions	1.6 x 0.8 x 2.2 inches
Item Weight	3.52 ounces
Model Number	010-01750-05
Battery Type	1 Lithium Ion battery (included)
Video Capture Resolution	1080p
Field of View	180-degree
Special Features	Automatic Incident Detection, G-Sensor, Voice Control
Connectivity	USB, Wireless
Mounting Type	Adhesive Mount
Color	Black

Warranty and Support

The Garmin Dash Cam 65 is covered by Garmin's standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Garmin website.
For further assistance, technical support, or to access additional resources such as software updates and FAQs, please visit the official Garmin support website or contact Garmin customer service directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0716G7DVQ

More documents and user manuals: **https://manuals.plus/**