De'Longhi EC 695.W

DeLonghi Dedica Style EC 695.W Espresso Machine User Manual

1. Introduction

Welcome to the user manual for your DeLonghi Dedica Style EC 695.W Espresso Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

The DeLonghi Dedica Style EC 695.W is a compact, semi-automatic espresso machine designed to prepare authentic espresso and frothed milk for cappuccinos and lattes. It features a Thermoblock heating system for rapid heat-up, a professional filter holder, and an adjustable cappuccino system.

2. Safety Instructions

- Always ensure the machine is connected to a grounded power outlet with the correct voltage (220-240V AC, 50/60Hz).
- Do not immerse the machine, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Avoid contact with hot surfaces, such as the steam wand and cup warmer. Use handles and knobs.
- Unplug the machine from the power outlet before cleaning and when not in use.
- Do not operate the machine with a damaged cord or plug, or if the machine malfunctions or has been damaged in any way.
- Use only cold, fresh water in the water tank. Do not use milk or other liquids.
- Never open the boiler cap while the machine is operating or hot.

3. Product Overview

Familiarize yourself with the main components of your DeLonghi Dedica Style EC 695.W espresso machine.



Figure 1: Front view of the DeLonghi Dedica Style EC 695.W espresso machine. This image shows the overall design, including the portafilter, control buttons, and steam wand on the right side.

1. **Water Tank:** Removable tank located at the back for filling with water.
2. **Cup Warmer:** Top surface to pre-heat cups.
3. **Control Panel:** Buttons for single espresso, double espresso, and steam function.
4. **Portafilter:** Holds ground coffee for brewing.
5. **Steam Wand:** Used for frothing milk and dispensing hot water.
6. **Drip Tray:** Collects excess water and coffee drips, removable for cleaning.
7. **Cup Support:** Adjustable for different cup sizes.



Figure 2: Top view of the DeLonghi Dedica Style EC 695.W, highlighting the control buttons for single espresso, double espresso, and steam, as well as the cup warming tray.

4. Setup

4.1 Unpacking and Initial Cleaning

1. Remove all packaging materials from the machine.
2. Wash the water tank, portafilter, filter baskets, and drip tray with warm water and mild detergent. Rinse thoroughly.
3. Wipe the exterior of the machine with a damp cloth.

4.2 Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold drinking water up to the MAX level indicator.
3. Replace the water tank securely in its position.

4.3 First Use Cycle (Priming)

Before making coffee, the machine must be primed to fill the internal circuits with water.

1. Ensure the water tank is filled.
2. Place a container under the portafilter and another under the steam wand.
3. Plug the machine into a power outlet. The machine will turn on, and the lights will flash.
4. Press the single espresso button. Water will start to dispense from the portafilter. Let it run until the water flow is steady and the light stops flashing.
5. Turn the steam knob to the steam position. Water will dispense from the steam wand. Let it run until the water flow is steady and the light stops flashing.
6. Turn the steam knob back to the OFF position. The machine is now primed and ready for use.

5. Operating Instructions

5.1 Making Espresso

1. Ensure the machine is on and heated (lights are steady).
2. Insert the desired filter basket (single or double) into the portafilter.
3. Fill the filter basket with finely ground espresso coffee. For a single shot, use approximately 7g; for a double shot, use approximately 14g.
4. Tamp the coffee evenly and firmly with a tamper. Wipe any excess coffee from the rim of the portafilter.
5. Attach the portafilter to the brewing head by inserting it from the left and rotating it to the right until it is firmly locked.
6. Place one or two pre-heated cups under the portafilter spouts.
7. Press the single espresso button for a single shot or the double espresso button for a double shot. The machine will automatically stop dispensing when the programmed volume is reached.
8. To manually stop the flow at any time, press the selected espresso button again.

5.2 Frothing Milk (Cappuccino System)



Figure 3: Side view of the DeLonghi Dedica Style EC 695.W, illustrating the position of the steam wand, which is used for frothing milk.

1. Fill a pitcher with cold milk (preferably skim or semi-skimmed) to about one-third full.
2. Press the steam button on the control panel. The light will flash while the machine heats up to steam temperature, then become steady.
3. Position the steam wand into the milk, just below the surface.
4. Turn the steam knob to the steam position. Steam will be released.
5. Move the pitcher up and down gently to create foam. Once the desired texture and temperature are reached, turn the steam knob back to the OFF position.
6. Immediately clean the steam wand by wiping it with a damp cloth and briefly releasing steam into an empty container to clear any milk residue.

6. Maintenance and Cleaning

6.1 Daily Cleaning

- **Drip Tray:** Empty and clean the drip tray and grid daily.
- **Portafilter and Filter Baskets:** After each use, remove the portafilter, discard the coffee grounds, and rinse the portafilter and filter basket under running water.
- **Steam Wand:** Clean immediately after frothing milk as described in section 5.2.
- **Water Tank:** Rinse the water tank regularly and refill with fresh water.

6.2 Descaling

Regular descaling is crucial to maintain machine performance and extend its lifespan. The frequency depends on water hardness and usage.

1. Use a suitable descaling solution recommended for espresso machines.
2. Follow the instructions on the descaling solution packaging for dilution and procedure.
3. Fill the water tank with the descaling solution.
4. Run the solution through the machine via the coffee spouts and steam wand, following the specific descaling cycle outlined in the full product manual (refer to manufacturer's website for detailed instructions).
5. Rinse the machine thoroughly by running several cycles of fresh water through it after descaling.

7. Troubleshooting

Problem	Possible Cause	Solution
No coffee dispensed	Water tank empty; machine not primed; coffee too finely ground or tamped too hard.	Fill water tank; perform priming cycle; use coarser grind or lighter tamp.
Weak coffee	Insufficient coffee grounds; coffee too coarsely ground; insufficient tamping.	Increase coffee amount; use finer grind; tamp more firmly.
No steam from wand	Steam button not pressed; wand blocked; machine not at steam temperature.	Press steam button and wait for steady light; clean steam wand; allow machine to heat up.
Water leaking from machine	Water tank not correctly inserted; drip tray full; seals worn.	Re-insert water tank; empty drip tray; contact customer support if seals are worn.

8. Specifications

Feature	Specification
Brand	De'Longhi
Model Number	EC 695.W
Color	White
Dimensions (W x D x H)	14.9 x 30.3 x 33 cm
Weight	4.2 kg

Feature	Specification
Water Tank Capacity	1.1 Liters
Power	1300 Watts
Voltage	220-240 V AC
Frequency	50/60 Hz
Material	Stainless Steel
Special Features	Programmable, Removable Water Reservoir, Thermoblock Heating System

9. Warranty and Support

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical support, spare parts, or service inquiries, please contact De'Longhi customer service in your region. Contact information can typically be found on the De'Longhi official website or in the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question