JVC SI32HS

JVC SI32HS Smart TV User Manual

Model: SI32HS

1. Important Safety Information

Please read all safety and operating instructions carefully before using this television. Keep these instructions for future reference.

- Do not block ventilation openings.
- Do not install near any heat sources.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

2. Product Overview

The JVC SI32HS is a 32-inch Full HD Smart TV designed for an immersive viewing experience. It features built-in Wi-Fi, allowing access to popular streaming services like Netflix and YouTube.



Figure 2.1: Front view of the JVC SI32HS Smart TV. This image shows the sleek design of the television with its screen and stand.

3. Setup Guide

3.1 Unpacking

Carefully remove the TV from its packaging. Ensure all accessories are present: remote control, batteries, and TV stand components.

3.2 Attaching the Stand

Place the TV screen-down on a soft, flat surface. Align the stand components with the screw holes on the bottom of the TV. Secure the stand using the provided screws.

3.3 Connecting Power

Plug the power cord into the TV's power input, then into a wall outlet. The TV is designed to operate on 110-240V, 50/60Hz AC power.

3.4 Connecting External Devices

The JVC SI32HS TV offers various connectivity options:



Figure 3.1: Rear view of the JVC SI32HS Smart TV's input panel. This image highlights the various ports available for connecting external devices, including HDMI, USB, and composite video inputs.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes. The TV has multiple HDMI inputs.
- **USB:** Connect USB drives for media playback.
- **Composite Video:** For older devices using RCA cables (yellow, white, red).
- **Antenna/Cable:** Connect an antenna or cable TV signal for broadcast channels.

3.5 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Network Setup:** Connect to your Wi-Fi network. Select your network name and enter the password.
3. **Channel Scan:** Scan for available broadcast channels (if an antenna or cable is connected).
4. **Time Zone:** Set the correct time zone.

4. Operating Instructions

4.1 Remote Control Functions

The remote control provides full functionality for your JVC Smart TV. Ensure batteries are correctly inserted (2 AA batteries required, included).





Figure 4.1: JVC Smart TV remote control. This image displays the layout of the remote control, including power, navigation, volume, channel, input, and dedicated app buttons.

- **POWER:** Turns the TV on or off.
- **Numbers (0-9):** Select channels directly.
- **VOL +/-:** Adjusts volume level.
- **CH +/-:** Changes channels.
- **SOURCE:** Selects input source (HDMI, USB, AV, TV).
- **USB:** Direct access to USB media player.
- **APPS:** Opens the Smart TV application menu.
- **Netflix** / **YouTube:** Dedicated buttons for direct access to these streaming services.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate menus and select options.
- **EXIT:** Exits the current menu or application.
- **MENU:** Opens the main settings menu.

4.2 Smart TV Features

With built-in Wi-Fi, your JVC SI32HS TV allows you to access a world of entertainment:

- **Streaming Apps:** Enjoy pre-installed apps like Netflix and YouTube. Additional apps may be available through the TV's app store.
- **Web Browser:** Browse the internet directly on your TV.
- **Media Playback:** Play videos, music, and photos from a connected USB device.

4.3 Menu Navigation

Press the **MENU** button on your remote to access the TV's settings. Use the navigation buttons to browse categories such as:

- **Picture:** Adjust brightness, contrast, color, and picture mode.
- **Sound:** Adjust volume, sound mode, and audio output.
- **Network:** Manage Wi-Fi connections.
- **System:** General settings, language, time, and software updates.

5. Maintenance

5.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of screen cleaner. Do not spray cleaner directly onto the screen. For the TV casing, use a soft, dry cloth.

5.2 Storage

If storing the TV for an extended period, unplug it from the power outlet and cover it to protect from dust. Store in a cool, dry place.

6. Troubleshooting

Before contacting support, try the following solutions for common issues:

Problem	Possible Cause	Solution
No Power	Power cord unplugged; outlet not working.	Check power cord connection; test outlet with another device.
No Picture, but Sound is Present	Incorrect input source selected; external device issue.	Press SOURCE button to select correct input; check external device connection.
No Sound, but Picture is Present	Volume muted or too low; audio cable loose.	Unmute volume or increase level; check audio cable connections.
Remote Control Not Working	Batteries dead or incorrectly inserted; obstruction.	Replace batteries; ensure line of sight to TV's IR sensor.
Cannot Connect to Wi-Fi	Incorrect password; router issue; TV too far from router.	Verify password; restart router; move TV closer or use a Wi-Fi extender.

7. Specifications

Feature	Detail
Brand	JVC
Model	SI32HS
Screen Size	32 Inches (82 cm visible diagonal)
Display Technology	LED
Resolution	720p (1366 x 768)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Smart TV Features	Built-in Wi-Fi, Netflix, YouTube
Connectivity	HDMI, USB, Composite Video, Digital Audio Out
Dimensions (with stand)	73.3 x 17.85 x 47.8 cm
Weight	5.5 kg

Feature	Detail
Power Supply	110-240V, 50/60Hz

8. Warranty and Support

This JVC product is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support or service inquiries, please contact JVC customer service through their official website or the contact information provided in your product packaging.
For additional support, visit the official JVC website:www.jvc.com

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I tune channels on the JVC SI32HS Smart TV?

To tune or scan for channels on your JVC SI32HS Smart TV, follow these steps:Connect your Signal: Ensure your antenna or cable TV cable is securely connected to the Antenna/Cable port on the rear...

Read full answer