Cirbic B0716WFMW1

Instruction Manual

Cirbic Extra Large Talking Button Clock

Model: B0716WFMW1

Introduction

The Cirbic Extra Large Talking Button Clock is designed for individuals with low vision, hearing impairment, or cognitive challenges. This user-friendly device provides clear audio announcements of the current time and date with a simple press of a large button. It also features an alarm function and adjustable voice volume settings.

Safety Information

- Keep the device away from water and excessive moisture.
- Do not expose to extreme temperatures or direct sunlight.
- Use only the specified battery type (AAA) and ensure correct polarity during installation.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified personnel for service.
- Keep batteries out of reach of children. Dispose of used batteries responsibly.

Package Contents

Please check that all items are present:

- Cirbic Extra Large Talking Button Clock (Blue)
- Instruction Manual (this document)

Note: Three AAA batteries are required and are not included.

Product Overview

Familiarize yourself with the components of your talking clock:



Figure 1: Front View of the Talking Clock

This image shows the main blue button on top of a silver circular base, which is the primary interface for the clock.

Figure 2: Pressing the Button

A human hand is shown pressing down on the large blue button, demonstrating the simple interaction required to activate the clock's voice function.



Figure 3: Side Profile

This image provides a side view of the clock, highlighting its compact and rounded design.



Figure 4: Bottom View with Controls

The underside of the clock is visible, featuring the battery compartment cover, a switch labeled "HI" and "LO" for volume adjustment, and a small "SET" button for configuration.



Figure 5: Product Dimensions

A diagram illustrating the clock's approximate dimensions: 4.5 inches in width and 2.5 inches in height.

Setup

1. Battery Installation

1. Turn the clock upside down to locate the battery compartment cover (refer to Figure 4).
2. Remove the battery compartment cover.
3. Insert three (3) AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover securely.

2. Setting Time and Date

The clock features audio instructions for setting. Locate the small "SET" button on the bottom of the clock (refer to Figure 4).

1. Press and hold the "SET" button until the clock announces "Setting Time".
2. Follow the audio prompts to set the hour, minute, year, month, and day. Each press of the main blue button will advance the setting.
3. Once all settings are confirmed, the clock will exit setup mode automatically.

3. Adjusting Volume

On the bottom of the clock, locate the "HI/LO" switch (refer to Figure 4). Slide the switch to your desired volume level: "HI" for high volume or "LO" for low volume.

Operating Instructions

1. Announcing Time

Press the large blue button once to hear the current time announced (e.g., "The time is 10:28 AM").

2. Announcing Date

After hearing the time, press the large blue button a second time to hear the current date announced (e.g., "The date is July 14th, Tuesday").

3. Setting and Using the Alarm

Detailed instructions for setting and activating the alarm are provided via audio prompts when entering the alarm setup mode. Typically, this involves a specific sequence of presses on the "SET" button and the main blue button.
When the alarm sounds, press the large blue button to silence it.

Maintenance

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the clock will not be used for an extended period, remove the batteries to prevent leakage.
- Ensure the speaker on the bottom of the clock is not obstructed for optimal sound clarity.

Troubleshooting

Problem	Possible Cause	Solution
No sound or faint sound.	Batteries are low or incorrectly installed. Volume switch is on "LO" or speaker is obstructed.	Replace batteries with fresh AAA batteries, ensuring correct polarity. Adjust the volume switch to "HI". Ensure the speaker on the bottom is clear of obstructions.
Incorrect time or date announced.	Time/date was not set correctly or batteries were removed/replaced.	Re-set the time and date using the "SET" button and audio instructions.
Alarm does not sound.	Alarm is not set or is turned off.	Verify the alarm settings using the audio instructions. Ensure the alarm is activated.

Specifications

Model: B0716WFMW1

Brand: Cirbic

Color: Blue

Dimensions: 4.5 inches (Width) x 2.5 inches (Height)

Weight: Approximately 6.4 ounces

Power Source: 3 x AAA Batteries (not included)

Voice Accent: North American (English Male)

Features: Time announcement, Date announcement, Alarm function, Adjustable volume (High/Low)

First Available: May 14, 2017

Country of Origin: China

Warranty and Support

Specific warranty information for the Cirbic Extra Large Talking Button Clock is not provided in this manual. For details

regarding warranty coverage, technical support, or service inquiries, please contact the manufacturer, Cirbic, directly through their official channels or the retailer from whom the product was purchased.

© 2025 Cirbic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question