Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BN59-01054A

ZdalaMit BN59-01051A BN59-01054A Replacement Remote Control User Manual

Model: BN59-01054A | Brand: ZdalaMit

Introduction

This document provides comprehensive instructions for the ZdalaMit BN59-01051A BN59-01054A replacement remote control. This remote is designed to function as a direct replacement for your original Samsung 3D TV remote, offering essential control without the need for complex programming.

Compatible Samsung TV Models:

- PS63C7790, UA40C7000, UA46C7000, UA46C8000, UA55C7000, UA55C8000, UA65C8000
- UE40C7000, UE40C7700, UE40C7705, UE40C8000, UE40C8700, UE40C8705, UE40C8780, UE40C8790
- UE46C7000, UE46C7700S, UE46C7705, UE46C8000, UE46C8700, UE46C8705, UE46C8780, UE46C8790, UE46C9000
- UE55C7000, UE55C7700, UE55C8000, UE55C8700, UE55C8705, UE55C8780, UE55C8790, UE55C9000
- UE65C8000, UE65C8700, UE65C8705, UE65C8780, UE65C8790
- PS50C7000, PS50C7700, PS50C7705, PS50C7780, PS50C7790, PS63C7000, PS63C7700, PS63C7705, PS63C7780
- UN40C7000, UN40C8000, UN46C7000, UN46C8000, UN55C8000

Setup

Installing Batteries

The remote control requires two (2) 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

No programming or pairing is required. Once batteries are installed, the remote is ready for use with compatible Samsung TVs.



Image: Front view of the ZdalaMit replacement remote control, showing all buttons and its ergonomic design.

Operating Instructions

To operate your television, point the remote control directly at the TV's infrared (IR) receiver. Ensure there are no obstructions between the remote and the TV.

Key Functions:

- **Power ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P↑/P↓):** Changes TV channels.
- **Mute:** Silences the TV audio.
- **Menu:** Accesses the TV's main menu.
- **Content:** Opens content-related features.
- **Tools:** Provides quick access to various TV functions and settings.

- **Directional Pad (Up, Down, Left, Right) & Enter:** Navigates menus and confirms selections.
- **Return (↶):** Returns to the previous screen or menu.
- **Exit:** Exits the current menu or application.
- **Colored Buttons (A, B, C, D):** Used for specific functions within certain TV applications or menus, as indicated on-screen.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Record):** Controls media playback on compatible devices or TV functions.
- **3D:** Activates or deactivates 3D mode on compatible TVs.
- **AD:** Audio Description function.
- **P.SIZE:** Picture Size adjustment.
- **SUBT:** Subtitle control.



Image: Angled view of the ZdalaMit replacement remote control, highlighting the button layout and silver finish.

Maintenance

Cleaning the Remote Control

- To clean the remote control, use a soft, dry cloth.
- Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Care and Replacement

- If the remote control becomes unresponsive or its range decreases, replace both AAA batteries with new ones.

- Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.
- Dispose of used batteries according to local regulations.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA alkaline batteries.
- **Line of Sight:** Make sure there is a clear path between the remote control and the TV's IR receiver. Remove any obstructions.
- **Remote Sensor:** Ensure the TV's IR sensor is not blocked or dirty.
- **TV Power:** Confirm that the TV is powered on and not in standby mode.

Specific Buttons Not Working

- If only certain buttons are unresponsive, try cleaning the remote control as described in the Maintenance section.
- Ensure the TV model is listed as compatible. While this remote is a replacement, some advanced or smart TV specific functions might vary slightly from the original remote.

Specifications

- **Model Number:** BN59-01054A
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Product Dimensions:** Approximately 8 x 2 x 1 inches (20.3 x 5.1 x 2.5 cm)
- **Item Weight:** Approximately 3 ounces (85 grams)
- **Compatible Devices:** Samsung Televisions (specific models listed in Introduction)
- **Special Feature:** Ergonomic design
- **Color:** Silver

Warranty and Support

This product is designed for reliable performance. Specific warranty details are not provided in this manual. For any queries, technical assistance, or support regarding your ZdalaMit replacement remote control, please contact the seller or manufacturer directly.

Your satisfaction is important. Do not hesitate to reach out if you encounter any issues or have questions about the remote's functionality.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0718YQBS1

More documents and user manuals: **https://manuals.plus/**