JustFine Compatible with Samsung UN40D550DAFXZA, UN48JU6500FX, UN55J6300AFZA, UN60JU650D, UN75JU6500FXZA, UN55JU6500F

JustFine Replacement Remote Control User Manual

Compatible with Samsung Smart LED LCD HD TVs

This manual provides instructions for the JustFine replacement remote control, designed for use with various Samsung Smart LED LCD HD TV models. This remote is pre-programmed and requires no additional setup beyond battery installation.

1. Setup

1.1 Battery Installation

The remote control requires two AA batteries (not included).

1. Locate the battery compartment cover on the back of the remote.
2. Slide the cover downwards to open.
3. Insert two AA batteries, ensuring correct polarity (+ and - terminals).
4. Slide the cover back into place until it clicks.

Note: For optimal performance and extended battery life, alkaline batteries are recommended.


SOURCE
SPORTS
SEARCH
EXTRA
1
2
3
4
5
6
7
8
9
0
PRE-CH
MUTE
VOL
CH
CH LIST
MENU
GUIDE
TOOLS
INFO
RETURN
EXIT
A
B
C
D
E-MANUAL
CC
MTS
PIC SIZE
PICTURE
SOUND

This image displays the rear of the remote control, highlighting the battery compartment cover. A label on the remote advises that if the backlight button is set to 'ON', battery consumption will be higher, and recommends using alkaline batteries to extend battery life.

2. Operating the Remote Control

This replacement remote functions identically to your original Samsung TV remote for the compatible models. Point the remote directly at your television's infrared receiver.

2.1 Power On/Off

Press the **POWER** button to turn your television on or off.

2.2 Channel Selection

Use the **CH +/-** buttons to navigate through channels. Enter specific channel numbers using the numeric keypad.

2.3 Volume Control

Adjust the volume using the **VOL +/-** buttons. Press the **MUTE** button to silence the audio.

2.4 Smart Hub / Menu Access

Access your TV's Smart Hub or main menu functions using the dedicated buttons, typically labeled **SMART HUB**, **MENU**, or **HOME**.

2.5 Navigation and Selection

Use the directional arrow buttons (**UP, DOWN, LEFT, RIGHT**) to navigate menus and select options. Confirm selections with the **ENTER** or **OK** button.

3. Care and Maintenance

Proper care ensures the longevity of your remote control.

3.1 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.

3.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type (AA).

3.3 Storage

Store the remote in a dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

4. Troubleshooting Common Issues

If you experience problems with your remote control, refer to the following solutions:

4.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity. Replace old batteries with new AA alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Remote Sensor:** Clean the infrared emitter on the front of the remote and the TV's sensor with a soft cloth.

4.2 Short Battery Life

- If your remote features a backlight button and it is set to "ON", battery consumption will be higher. Consider turning off the backlight when not needed to extend battery life.
- Always use high-quality alkaline batteries for best performance and longevity.

5. Product Specifications

Brand	JustFine
Compatible Devices	Samsung Televisions (UN40D550DAFXZA, UN48JU6500FX, UN55J6300AFZA, UN60JU650D, UN75JU6500FXZA, UN55JU6500F)
Connectivity Technology	Infrared
Controller Type	Button Control
Battery Type	AA (2 required)
Product Dimensions	20.32 x 5.08 x 1.27 cm
Item Weight	77 g

6. Warranty and Customer Support

6.1 Quality Warranty

This product comes with a 30-day quality warranty. If you encounter any issues within this period, please contact customer support.

6.2 Return Policy

A hassle-free return policy is offered, along with a money-back guarantee.

6.3 Contact Support

For any problems or inquiries, please email customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question