Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RMT-B116A-ZDLMT

ZdalaMit RMT-B116A Replacement Remote Control User Manual

Model: RMT-B116A-ZDLMT

Introduction

This user manual provides comprehensive instructions for the ZdalaMit RMT-B116A Replacement Remote Control. This remote is designed as a direct replacement for original Sony Blu-Ray DVD Player remote controls, offering immediate functionality without the need for complex programming or setup.

Key Features:

- No programming or pairing required.
- Ready to use immediately after battery installation.
- Compatible with various Sony Blu-Ray DVD Player models.

Compatibility

The ZdalaMit RMT-B116A remote control is compatible with the following Sony Blu-Ray DVD Player models:

- BDP-BX58
- BDP-BX38
- BDP-S280
- BDPBX58
- BDPBX38
- BDPS280

Setup

Battery Installation

The remote control requires two (2) 1.5V AA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control showing the battery compartment.

This image displays the back of the ZdalaMit RMT-B116A remote control. The battery cover is removed, revealing two slots for AA batteries. The correct polarity markings are visible within the compartment, guiding the user on proper battery insertion.

Once batteries are installed, the remote control is ready for immediate use with your compatible Sony Blu-Ray DVD Player.

Operating Instructions

Basic Remote Functions

The ZdalaMit RMT-B116A remote control provides all the essential functions for operating your Sony Blu-Ray DVD Player. Simply point the remote towards your player and press the desired button.



Image: Front view of the remote control with button layout.

This image displays the front of the ZdalaMit RMT-B116A remote control, showcasing its full button layout. Key buttons include power, numerical keypad, volume controls, playback controls (play, pause, stop, prev, next), menu navigation, and dedicated buttons for functions like Netflix, Top Menu, and Pop Up/Menu.

Common button functions include:

- **Power (I/O):** Turns the Blu-Ray player on or off.
- **Open/Close:** Opens or closes the disc tray.
- **Input:** Selects the input source (if applicable).
- **Number Buttons (0-9):** For direct track selection or input.
- **VOL (+/-):** Adjusts the volume.
- **Audio:** Cycles through audio tracks.
- **Subtitle/Display:** Controls subtitle display or shows on-screen information.
- **Color Buttons (Yellow, Blue, Red, Green):** For specific functions within menus or applications.
- **Top Menu:** Accesses the main menu of a disc.
- **Pop Up/Menu:** Accesses the pop-up menu of a disc.
- **Navigation Pad (Up, Down, Left, Right, Enter):** For navigating menus and selecting options.
- **Return:** Goes back to the previous screen or menu.
- **Options:** Displays additional options for the current content.
- **Playback Controls (PREV, PAUSE, PLAY, NEXT, Fast Forward, Rewind, STOP):** Standard controls for disc playback.
- **Netflix:** Dedicated button for quick access to the Netflix application (if supported by your player).

Maintenance

Care and Cleaning

To ensure the longevity and proper functioning of your remote control, follow these care guidelines:

- Wipe the remote control regularly with a soft, dry cloth to remove dust and fingerprints.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.
- Do not drop the remote or subject it to strong impacts.

Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AA alkaline batteries. Dispose of used batteries according to local regulations.

Troubleshooting

If you experience issues with your ZdalaMit RMT-B116A remote control, try the following troubleshooting steps:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh 1.5V AA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the Blu-Ray player's infrared sensor.
  - Make sure you are within the effective operating range of the player.
- **Certain buttons not working:**
  - This remote is a direct replacement and does not require programming. If a specific button does not work, ensure it is a function supported by your specific Sony Blu-Ray DVD Player model.
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing proper contact.

If the issue persists after trying these steps, the remote control may be faulty and require replacement.

Product Specifications

Model Number:	RMT-B116A-ZDLMT
Brand:	ZdalaMit
Compatible Devices:	Sony Blu-Ray DVD Players (BDP-BX58, BDP-BX38, BDP-S280, etc.)
Power Supply:	2 x 1.5V AA Alkaline Batteries
Product Dimensions:	6 x 2 x 1 inches (approximately)
Item Weight:	2 ounces (approximately)
Color:	Black
Special Feature:	Pre-Programmed (No setup required)

Warranty and Support

Information regarding product warranty and customer support is not available in the provided product data. Please refer to the product packaging or contact the seller directly for details on warranty coverage and support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071CMGHGH

More documents and user manuals: **https://manuals.plus/**