Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arebos AR-HE-GH30CM

Arebos 2-Burner Gas Hob Instruction Manual

Model: AR-HE-GH30CM

1. Introduction

Thank you for choosing the Arebos 2-Burner Gas Hob. This appliance is designed for efficient and versatile cooking, featuring a durable glass-ceramic surface and robust construction. This manual provides essential information for the safe and effective operation, installation, and maintenance of your new gas hob. Please read it thoroughly before use and keep it for future reference.

2. Safety Instructions

Your safety and the safety of others are paramount. Always adhere to the following safety precautions:

- **Professional Installation:** Installation and conversion between natural gas and propane gas must be performed by a qualified professional. Incorrect installation can lead to gas leaks, fire, or explosion.
- **Gas Type:** The hob comes with pre-installed nozzles for natural gas (20mBar). Propane gas nozzles (50mBar) are included for conversion. Ensure the correct gas type is used and that the conversion is done professionally.
- **Integrated Ignition Protection:** The hob features an integrated ignition protection system that automatically shuts off the gas supply if the flame extinguishes. Do not attempt to bypass or modify this safety feature.
- **Ventilation:** Ensure adequate ventilation in the kitchen area when the gas hob is in use.
- **Flammable Materials:** Keep flammable materials away from the hob during operation.
- **Children and Pets:** Keep children and pets away from the appliance when it is in use and while it is cooling down.
- **Hot Surfaces:** The hob surface and pan supports will become hot during use. Use oven mitts or pot holders when handling hot cookware.



Image: The Arebos gas hob showing the gas nozzles for different gas types. Professional installation is required for gas conversion.

3. Product Features

The Arebos 2-Burner Gas Hob is designed for performance and durability:

- **Dual Burners:** Equipped with one 3000 W rapid burner and one 1750 W semi-rapid burner for versatile cooking.
- **Glass-Ceramic Surface:** Features a polished safety glass surface that is easy to clean and resistant to temperature fluctuations.
- **Robust Pan Supports:** Matte enameled grates provide stable support for various cookware types.
- **Piezo Ignition:** Convenient and reliable ignition system.
- **Precise Control:** Rotary knobs allow for accurate flame adjustment.



Image: The Arebos 2-burner gas hob with its sleek glass-ceramic surface and active flames.

4. Setup and Installation

Proper installation is crucial for the safe and efficient operation of your gas hob. It is highly recommended that installation be carried out by a certified technician.

4.1 Gas Connection

- The hob is factory-fitted with nozzles for natural gas (20mBar).
- If using propane gas (50mBar), the included propane nozzles must be installed by a qualified professional.
- Ensure all gas connections are secure and leak-free after installation.

4.2 Dimensions and Cut-out

Refer to the following dimensions for proper integration into your kitchen countertop:

- Product Dimensions: 30.3 cm (D) x 52 cm (W) x 9.5 cm (H)
- Cut-out Dimensions (approximate): 27 cm (D) x 48 cm (W) (Please verify with actual product and installation manual for precise cut-out requirements).



Image: Dimensional diagram of the Arebos gas hob, indicating overall and cut-out measurements for installation.

5. Operating Instructions

5.1 Ignition

1. Place appropriate cookware on the pan support over the desired burner.
2. Push down and turn the corresponding control knob counter-clockwise to the maximum flame setting.
3. The piezo ignition will spark, igniting the gas. Hold the knob down for a few seconds to allow the thermocouple to heat up and activate the safety shut-off.
4. If the flame does not ignite, release the knob and repeat the process. If using a gas lighter, ignite the gas manually while

turning the knob.

5.2 Flame Adjustment

Once ignited, adjust the flame size by rotating the control knob. Turn clockwise to reduce the flame and counter-clockwise to increase it. Always ensure the flame is contained within the base of the cookware.

5.3 Suitable Cookware

The Arebos gas hob is compatible with various types of cookware, including:

- Stainless Steel Cooking Pots/Pans
- Aluminum Cooking Pots/Pans
- Granite Cooking Pots/Pans
- Copper Pans/Pots
- Iron Pans/Pots



Image: Examples of suitable cookware, including stainless steel, aluminum, granite, copper, and iron pots and pans.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your gas hob.

- **Daily Cleaning:** After each use, allow the hob to cool completely. Wipe the glass-ceramic surface with a soft cloth and a mild detergent. Avoid abrasive cleaners or scouring pads that can scratch the surface.
- **Pan Supports:** The enameled pan supports are removable for easy cleaning. Wash them with warm soapy water and dry thoroughly before placing them back on the hob.
- **Burner Caps and Rings:** Periodically remove the burner caps and rings. Clean them with warm soapy water, ensuring all food debris is removed. Dry completely before reassembling. Ensure the burner ports are not clogged.
- **Spills:** Clean up spills immediately to prevent them from baking onto the surface, which can make them harder to remove later.

7. Troubleshooting

If you encounter issues with your Arebos gas hob, refer to the following common troubleshooting steps:

- **Burner Not Igniting:** Check if the gas supply is on. Ensure the control knob is pushed down fully and held for a few seconds during ignition. Clean the burner caps and rings to ensure no debris is blocking the gas flow or spark.
- **Flame is Irregular or Too Small/Large:** Ensure the burner caps and rings are correctly seated. Check for any blockages in the burner ports. If the flame is consistently too large after professional installation, it might indicate an incorrect nozzle for the gas type; contact a professional.
- **Gas Odor:** If you smell gas, immediately turn off the gas supply to the appliance and open windows for ventilation. Do not operate any electrical switches or appliances. Contact a qualified gas technician or your gas supplier immediately.

For issues not covered here or if problems persist, please contact a qualified service technician or the manufacturer's support.

8. Specifications

Feature	Specification
Brand	Arebos
Model Number	AR-HE-GH30CM
Manufacturer	Canbolat Vertriebs GmbH
Product Dimensions	30.3 x 52 x 9.5 cm
Weight	5.5 kg
Burner 1 Power	3000 W (Rapid Burner)
Burner 2 Power	1750 W (Semi-Rapid Burner)
Fuel Type	Natural Gas (20mBar), Propane Gas (50mBar)
Surface Material	Glass Ceramic (Tempered Glass)
Ignition Type	Piezoelectric

Feature	Specification
Control Type	Rotary Knob
Color	Black
Country of Origin	China

9. Warranty and Support

For information regarding warranty coverage and customer support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. The manufacturer is Canbolat Vertriebs GmbH.

Keep your proof of purchase for any warranty claims.

© 2024 Arebos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071DGX4PV

More documents and user manuals: **https://manuals.plus/**