NUBWO HW02

NUBWO Portable Bluetooth Wireless Speaker User Manual

Brand: NUBWO
Model: HW02 (A9)

Introduction

This manual provides essential information for the safe and efficient operation of your NUBWO Portable Bluetooth Wireless Speaker. The NUBWO A9 speaker is designed for enhanced sound and features True Wireless Stereo (TWS) capabilities. It boasts a sleek aluminum exterior and a cool-blue light-wheel, combining premium design with powerful audio. Equipped with a 5W large internal magnetic horn and DSP Digital Signal Processing Technology, it delivers powerful and high-definition surround sound without distortion. The speaker supports multiple playback methods including Bluetooth, AUX, and TF card, ensuring compatibility with a wide range of devices such as iPhones, iPads, Macs, tablets, and laptops. It also includes a built-in microphone for hands-free calls.



Figure 1: NUBWO Portable Bluetooth Speaker

Setup

What's in the Box

- 1 x NUBWO Bluetooth Speaker
- 1 x Charging Cable (Micro USB to AUX/USB)
- 1 x User Manual

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the Micro USB port on the speaker and the USB end to a compatible power source (e.g., computer USB port, USB wall adapter). The speaker's light will indicate

charging status. A full charge typically takes 1 to 2 hours and provides 6-10 hours of continuous playtime.



Figure 2: Speaker bottom showing Micro USB charging socket and TF card slot.

Operating Instructions

Powering On/Off

To power on the speaker, press and hold the power button (located on the bottom control panel) for more than 5 seconds until the blue light illuminates. To power off, press and hold the power button again.

Bluetooth Pairing

Once powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue light. On your device (phone, tablet, laptop), enable Bluetooth and search for "NUBWO A9" (or similar). Select it to connect. A confirmation sound will indicate successful pairing.

[redacted]

Video 1: Official NUBWO Portable Bluetooth Speaker overview and demonstration. This video shows the unboxing, features, and sound quality of the speaker.

True Wireless Stereo (TWS) Pairing

To pair two NUBWO A9 speakers for a stereo experience:

1. Turn on both NUBWO A9 speakers and ensure they are in Bluetooth mode.
2. Double-click the power button on one of the speakers. You will hear a "beep" twice (after a 5-second interval) indicating successful connection between the two speakers.
3. Once paired, connect your device to one of the speakers via Bluetooth as described above.
4. To disconnect TWS pairing, double-click the power button on either speaker.



Figure 3: Two NUBWO A9 speakers ready for TWS pairing to create a stereo sound experience.

Controls

The control buttons are located on the bottom of the speaker:

- **Power Button:** Press and hold to turn on/off.
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Mode (M):** Press to switch between Bluetooth, AUX, and TF card modes.
- **Call/Play/Pause:** Press to answer/end calls or play/pause music.

Multi-Way Playback

In addition to Bluetooth, the NUBWO A9 speaker supports:

- **AUX Mode:** Connect an audio device using the provided AUX cable.
- **TF Card Mode:** Insert a TF (Micro SD) card with your music files into the designated slot.

Maintenance

To ensure the longevity of your NUBWO speaker:

- Keep the speaker in a clean and dry environment. This product is**NOT waterproof**. Avoid exposure to water, rain, or high humidity.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.

Troubleshooting

Problem	Solution
Speaker does not turn on.	Ensure the speaker is charged. Press and hold the power button for at least 5 seconds.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing blue light). Check your device's Bluetooth settings and ensure it's discoverable. Move the speaker closer to your device.

Problem	Solution
Volume control is difficult or skips songs.	For volume adjustment, press and hold the '+' or '-' buttons. A quick press may skip tracks. Alternatively, control volume directly from your connected device.
Sound quality is poor or distorted.	Ensure the speaker is not placed on a surface that vibrates excessively (e.g., glass desk). Reduce volume if distortion occurs at high levels. Check the audio source for quality.

Specifications

Feature	Detail
Model Name	A9
Item Model Number	HW02
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth, Auxiliary
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Audio Output Mode	Surround, Stereo
Speaker Maximum Output Power	3 Watts
Audio Driver Size	40 Millimeters
Battery Life	8 Hours
Battery Capacity	600 Milliamp Hours
Control Method	Touch
Product Dimensions	3"D x 3.8"W x 3.8"H
Item Weight	11 ounces
Is Waterproof	FALSE

Warranty and Support

The NUBWO Portable Bluetooth Wireless Speaker comes with a **Limited Warranty**. For any questions or technical consultation, NUBWO offers:

- 24 hours online customer service
- 2 Years maintenance service
- Life-long Technical Consultation

Please refer to the service card included with your product for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question