CuleedTec Wii U Pro Controller

CuleedTec Wireless Pro Controller for Wii U - Instruction Manual

Model: Cooleader

Introduction

This instruction manual provides essential information for the setup, operation, and maintenance of your CuleedTec Wireless Pro Controller for Wii U. Designed for accessibility and extended gameplay comfort, this controller features dual analog sticks and an ergonomic button layout, compatible with the Wii U game console.

Product Overview

The CuleedTec Wireless Pro Controller is a third-party replacement controller specifically designed for the Wii U game console. It offers a wireless connection for an enhanced gaming experience.

Key Features

- Designed for Wii U game console compatibility.
- Ergonomic design with dual analog sticks and button layout for comfort.
- Wireless connection for freedom of movement.
- Rechargeable battery with included charging cable.

Component Identification

Familiarize yourself with the various buttons and components of your controller.



This image displays the front and back of the CuleedTec Wireless Pro Controller, highlighting key components such as the shoulder buttons (LB, LT, RB, RT), analog sticks, D-Pad, face buttons (A, B, X, Y), Home, Select, Start, and Power buttons. It also points out the SYNC button, Reset button, battery cover, charging indicator, and LED channel indicators.

Setup Instructions

How to Pair the Wii U Pro Controller with the Wii U Console

1. While on the Wii U Menu, press the SYNC Button on the Wii U Console to display the controller pairing screen.
2. Press the SYNC button on the console again until the screen shows the controller type you want to pair.
3. Press the SYNC button on the Wii U Pro Controller.
4. Follow the on-screen instructions.
5. The Player LED on the controller will light up when the pairing is complete. The Player LED indicates the player number of the controller currently in use.

Sync Button for Paring



How to Pair a Wii U Pro controller with the Wii U Console?

Step 1. While on the Wii U Menu, press the SYNC Button on the Wii U Console to display the controller pairing screen.

Step 2. Press the SYNC button on the console again until the screen shows the controller type you want to pair.

Step 3. Press the SYNC button on the Wii U Pro Controller.

Step 4. Follow the on-screen instructions.

Step 5. The Player LED on the controller will light up when the pairing is complete. The Player LED indicates the player number of the controller currently in use.

This image clearly indicates the position of the SYNC button on the rear of the controller, which is essential for pairing with the Wii U console.



This image illustrates the battery charging indicator (red for low, yellow for charging) and the player LED lights, which show the assigned player number once the controller is paired.

Operating the Controller

Charging the Controller

The controller is rechargeable via the included USB cable. Connect the cable to the controller and a Wii U console, computer, or wall charger with a USB port. The LED indicator will show charging status. The LED light will turn off automatically when fully charged, which typically takes less than 4 hours.

Usage Tips for Better Performance

- Ensure the controller is fully charged before use.
- Keep the controller within a proper range (recommended within 5 meters) for optimal wireless connection.
- Avoid strong wireless interference to maintain stable performance.

Troubleshooting

Controller Reset

If the vibration does not respond properly or behaves abnormally, you can reset the controller. Gently press the RESET hole on the back of the controller using a pin for 2-3 seconds, then reconnect it to the console.

Product Specifications

Brand	CuleedTec
Model Name	Wii U Pro Controller
Compatible Devices	Nintendo Wii U
Controller Type	Gamepad
Connectivity Technology	Wireless, USB
Additional Features	Ergonomic, Wireless
Button Quantity	15
Hardware Platform	Wii U
Power Source	Battery Powered, Corded Electric
Item Weight	7 Ounces / 224 g
Item Dimensions (L x W x H)	4.33 x 6.3 x 1.5 inches / 11 x 16 x 3.8 cm
Color	Black



This image provides a visual representation of the controller's dimensions, showing its length, width, and height in millimeters.

Warranty and Support

This product includes a 1-year after-sales service and lifetime technical support from Cooleader. For any issues or inquiries, please contact Cooleader customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question