Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

vidaXL 243449

vidaXL Modern Farmhouse-Style TV Cabinet

INSTRUCTION MANUAL - MODEL 243449

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

WARNING: Furniture Tip-Over Hazard

Children have died from furniture tip-over. To prevent tip-over:

- **NEVER** allow children to stand, climb, or hang on drawers, doors, or shelves.
- **ALWAYS** secure your television with an anchor device or mount the television on a wall.



This image illustrates the critical safety warning regarding furniture tip-over, emphasizing the need to secure furniture and prevent children from climbing.

This product may expose you to chemicals, including wood dust, which is known to the State of California to cause cancer. For more information, consult relevant safety guidelines. Do not exceed the maximum load capacity to ensure stability and safety.

2. Product Overview

The vidaXL Modern Farmhouse-Style TV Cabinet (Model 243449) is designed to provide a stylish and functional solution for your entertainment needs. Constructed from high-quality MDF with a PVC cover and a durable metal frame, this gray TV stand offers ample storage and efficient cable management.



This image shows the complete vidaXL TV cabinet from the front, highlighting its gray finish, two closed compartments, and central open shelves.

Key Features:

- **Ample Storage:** Includes two open shelves and two compartments with doors for organizing media devices, DVDs, or other items.
- **Cable Management:** Features two cable outlets to help keep wires tidy and out of sight.
- **Durable Construction:** Made from high-quality MDF with a PVC cover and a sturdy metal frame.
- **Modern Aesthetic:** Gray finish designed to complement various living space decors.

3. Setup and Assembly

This functional media console is designed for straightforward assembly. Please ensure all components are present before beginning.

Components Checklist:

- Cabinet panels (top, bottom, sides, shelves, doors)
- Metal frame/legs
- Handles

- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip hardware (for securing to a wall)

Assembly Steps:

1. Unpack all components and verify against the checklist. Place them on a soft, clean surface to prevent scratches.
2. Attach the metal legs to the bottom panel of the cabinet using the provided hardware. Ensure they are securely fastened.
3. Assemble the main cabinet structure by connecting the side panels, central dividers, and shelves to the top and bottom panels. Follow the detailed diagrams in the included assembly guide for correct orientation.
4. Install the doors onto the side compartments using the provided hinges. Adjust hinges as necessary for proper alignment.
5. Attach the handles to the doors.
6. Position the TV cabinet in its desired location.
7. **Crucially, secure the cabinet to a wall using the provided anti-tip hardware.** This step is essential for safety.



This image displays the interior of the TV cabinet with both doors open, revealing the two storage compartments and the central open shelves, along with cable outlets, which are important for assembly and setup.



A direct front view of the vidaXL TV cabinet, showcasing its two closed storage compartments with black handles and the two central open shelves, providing a visual reference for the assembled unit.

4. Operating Instructions

Once assembled and securely placed, your vidaXL TV cabinet is ready for use.

Placement and Usage:

- Place the TV cabinet on a flat, stable surface.
- Carefully place your television on the top surface. Ensure the television's base fits securely and does not overhang excessively.
- Utilize the two open shelves for media players, game consoles, or soundbars.
- Store DVDs, remote controls, or other accessories in the two closed compartments to maintain a tidy appearance.
- Route all necessary cables through the designated cable outlets at the back of the open shelves to manage wires effectively and prevent tangles.

Weight Capacity:

Do not exceed the maximum load capacity of the top surface or shelves. Overloading can compromise the stability and structural integrity of the cabinet. Consult the specific load capacity details in your assembly guide or contact customer support if unsure.



This image provides the key dimensions of the vidaXL TV cabinet: 120 cm (47.2 inches) length, 40 cm (15.7 inches) depth, and 45 cm (17.7 inches) height, including the 14.5 cm (5.7 inches) leg height. These dimensions are crucial for planning placement and ensuring compatibility with your television and space.

5. Maintenance

Proper care will ensure the longevity and appearance of your TV cabinet.

Cleaning Instructions:

- For general cleaning, wipe the surfaces with a damp cloth.
- Immediately follow with a dry cloth to remove any moisture and prevent water marks.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the PVC cover or finish.
- Regularly check all screws and fittings to ensure they remain tight. Retighten if necessary.

6. Troubleshooting

If you encounter any issues with your TV cabinet, refer to the following common solutions.

Common Issues and Solutions:

- **Wobbly or Unstable Cabinet:**
  - Ensure the cabinet is placed on a level surface.
  - Check that all assembly screws and fasteners are tightened securely.
  - Verify that the anti-tip hardware is correctly installed and anchored to the wall.
- **Doors Not Aligning Properly:**
  - Adjust the hinges on the doors. Most hinges allow for minor adjustments to align the doors vertically, horizontally, and in depth.
  - Ensure the cabinet frame is square and not twisted during assembly.
- **Missing or Damaged Parts:**
  - Carefully re-check all packaging materials to ensure no small parts were overlooked.
  - Contact vidaXL customer support with your model number (243449) and a description of the missing or damaged part for assistance.

7. Specifications

Brand	vidaXL
Model Number	243449
ASIN	B071NGPLWJ
Material	Engineered Wood (MDF with PVC cover)
Color	Grey
Product Dimensions	47.2 x 15.7 x 17.7 inches (120 x 40 x 45 cm)
Item Weight	39.9 pounds (18.15 kg)
Style	Modern
Included Components	Compartments, Shelves, Stand
Product Care Instructions	Wipe with Damp Cloth, then with Dry Cloth

8. Warranty and Support

For warranty information and customer support, please contact vidaXL directly. Details regarding specific warranty periods and terms are typically provided with your purchase documentation or can be found on the official vidaXL website.

When contacting support, please have your product model number (**243449**) and purchase details readily available.

You can visit the vidaXL store for more information:vidaXL Store on Amazon

© 2026 vidaXL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071NGPLWJ

More documents and user manuals: **https://manuals.plus/**