Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Logilink ID0139

LogiLink ID0139 Wireless Ergonomic Mouse User Manual

Model: ID0139

Introduction

Thank you for choosing the LogiLink ID0139 Wireless Ergonomic Mouse. This manual provides essential information for setting up, operating, and maintaining your new mouse. Designed for comfort, this ergonomic mouse helps promote a more natural hand and wrist posture, potentially reducing strain during extended use.

Please read this manual thoroughly before using the product to ensure proper function and longevity.

Product Overview

The LogiLink ID0139 is a 2.4 GHz wireless ergonomic mouse featuring an optical sensor with adjustable DPI settings. It includes 6 buttons for enhanced functionality.



Figure 1: Top-down view of the LogiLink ID0139 mouse, showing the main left and right click buttons, scroll wheel, and DPI button.



Figure 2: Side view of the LogiLink ID0139 mouse, highlighting the ergonomic design and textured thumb rest area.



Figure 3: Another side view of the LogiLink ID0139 mouse, showing the additional programmable buttons located near the thumb.

Package Contents

Please check the package for the following items:

- 1 x LogiLink ID0139 Wireless Ergonomic Mouse
- 1 x USB Receiver (typically stored inside the mouse battery compartment)
- 2 x AAA Alkaline Batteries
- 1 x User Manual (this document)

Setup

1. **Install Batteries:**

Locate the battery compartment on the underside of the mouse. Open the cover and insert the two AAA batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.

2. **Connect USB Receiver:**

   Remove the USB receiver from its storage slot, usually located near the battery compartment. Plug the USB receiver into an available USB port on your computer (PC or Laptop).

3. **Power On:**

   Turn on the mouse using the power switch, typically located on the underside. Your computer should automatically detect and install the necessary drivers. The mouse will be ready for use once the installation is complete.

Operating Instructions

Basic Mouse Functions

- **Left Click:** Primary selection and activation button.
- **Right Click:** Opens context menus.
- **Scroll Wheel:** Scrolls documents and web pages vertically. Can also be pressed for middle-click functionality.
- **Forward/Backward Buttons:** (Located near the thumb rest) Used for navigating web pages or folders.

DPI Adjustment

The LogiLink ID0139 mouse features an adjustable optical sensor with three sensitivity settings: 1000, 1200, and 1600 DPI (Dots Per Inch).

- To change the DPI setting, press the **DPI Shift button** (usually located behind the scroll wheel).
- Each press cycles through the available DPI settings. Select the sensitivity that best suits your preference and task.

Maintenance

- **Cleaning:**

  To clean the mouse, gently wipe its surface with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the device.

- **Battery Replacement:**

  When the mouse performance degrades or it stops responding, it may be time to replace the batteries. Open the battery compartment, remove the old AAA batteries, and insert new ones, observing correct polarity. Dispose of used batteries responsibly.

- **Storage:**

  When not in use for extended periods, turn off the mouse to conserve battery life. Store the USB receiver in its dedicated slot within the mouse to prevent loss.

Troubleshooting

- **Mouse not responding:**
  - Ensure the mouse is powered on.
  - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
  - Verify that the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
  - Move the mouse closer to the USB receiver to ensure it's within the 10-meter operating range.
- **Erratic or jumpy cursor movement:**

- Clean the optical sensor on the underside of the mouse.
- Use the mouse on a clean, non-reflective, and uniform surface. Avoid glass or highly reflective surfaces.
- Check for potential interference from other wireless devices.

- **DPI adjustment not working:**
  - Ensure the mouse is powered on and connected.
  - Press the DPI button firmly.

Specifications

Feature	Detail
Model	ID0139
Brand	LogiLink
Connectivity	2.4 GHz Wireless (Radio Frequency)
Operating Range	Up to 10 meters
Sensor Type	Optical
DPI Sensitivity	Adjustable: 1000 / 1200 / 1600 DPI
Number of Buttons	6 (5 standard + 1 DPI Shift button)
Hand Orientation	Right-handed
Power Source	2 x AAA Batteries (included)
Dimensions (L x W)	100 x 79 mm (approx.)
Weight	149 Grams (approx.)
Compatible Operating Systems	Windows, Linux
Material	Plastic
Color	Black

Warranty Information

LogiLink products are manufactured with quality and reliability in mind. This product is covered by a manufacturer's warranty against defects in materials and workmanship. The EU spare part availability duration is 1 year.

For specific warranty terms and conditions, please refer to the warranty card included with your product or contact your local LogiLink distributor or retailer. Keep your purchase receipt as proof of purchase.

Support

If you encounter any issues that cannot be resolved using the troubleshooting guide, or if you require further assistance,

please contact your retailer or the LogiLink customer support team.

For the latest support information, drivers, and FAQs, please visit the official LogiLink website or the website of your regional distributor.

© 2023 LogiLink. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071PD3ZPP

More documents and user manuals: **https://manuals.plus/**