Samsonite 88538-1041

Samsonite Flux Spinner 68/25 Expandable Luggage User Manual

Model: 88538-1041

Introduction

This manual provides instructions for the proper use, setup, and maintenance of your Samsonite Flux Spinner 68/25 Expandable Hand Luggage. Designed for durability and convenience, this luggage features a robust polypropylene shell, smooth-rolling double wheels, and an expandable capacity for increased packing volume.

Key Features

- **360-Degree Multidirectional Double Wheels:** For effortless maneuverability in any direction.
- **Expandable Capacity:** Hidden expandability on all sizes to accommodate additional packing needs.
- **Fully Lined Interior:** Includes a zipped divider pad, a large hinge pocket, and functional elastic cross ribbons for organized packing.
- **Integrated TSA Combination Lock:** Provides security for your belongings while allowing airport security to inspect luggage without damage.
- **Double Tube Wheel Handle:** For comfortable handling and stability.

Setup

Setting the Combination Lock

Your Samsonite Flux luggage is equipped with an integrated TSA combination lock. The default combination is 0-0-0.

1. Open the lock by sliding the button (A) to the side. The zipper pullers (B) will release.
2. With the lock open, push the small reset button (C) with a pen or pointed object until you hear a "click".
3. Set your desired 3-digit combination by turning the dials (D).
4. Slide the button (A) again. The reset button (C) will return to its original position with a "click". Your new combination is now set.
5. To lock, align your chosen combination and insert the zipper pullers (B) into the lock. Scramble the numbers to secure.



Image: Close-up view of the integrated TSA combination lock on the Samsonite Flux luggage. The image highlights the three-digit dials, the release button, and the small reset button, which are essential for setting a personalized security code.


Samsonite



Image: Front view of the Samsonite Flux Spinner luggage in black. This image displays the overall design, including the textured polypropylene shell, the integrated TSA lock on the side, and the multidirectional double wheels at the base.

Operating Instructions

Using the Expandability Feature

The Flux Spinner luggage offers a hidden expandability feature to increase its packing volume when needed.

1. Locate the secondary zipper running along the perimeter of the luggage, typically behind the main zipper.
2. Unzip this secondary zipper completely to expand the luggage shell, providing additional depth for packing.
3. To return to the standard size, zip the secondary zipper back up.



Image: Interior view of the Samsonite Flux luggage when fully opened. It displays the fully lined compartments, a zipped divider pad on one side, and elastic cross ribbons on the other, designed for secure and organized packing. The expansion zipper is visible along the perimeter.

Telescopic Handle Operation

The double tube telescopic handle can be adjusted to multiple heights for comfortable maneuvering.

- To extend the handle, press the button located on the top of the handle grip and pull upwards.
- Release the button at your desired height.
- To retract, press the button and push the handle downwards until it is fully nested.



Image: A close-up view of the telescopic handle of the Samsonite Flux luggage, extended upwards. The image also shows the top carry handle and a portion of the luggage's textured surface.

Maneuvering with Double Spinner Wheels

The luggage is equipped with four double spinner wheels, allowing for smooth 360-degree rotation and easy gliding in any direction.

- For upright rolling, push the luggage alongside you.
- For pulling behind you, tilt the luggage onto two wheels.



Image: The Samsonite Flux luggage standing upright in a room, demonstrating its stability and the functionality of its four double spinner wheels. The telescopic handle is partially extended.

Interior Organization

The fully lined interior is designed for efficient packing:

- **Zipped Divider Pad:** Separates the two main compartments, often featuring additional pockets for smaller items.
- **Elastic Cross Ribbons:** Secure your packed items in place, preventing shifting during transit.
- **Large Hinge Pocket:** Provides extra storage for documents or accessories.

Maintenance

Proper care will extend the life of your luggage.

- **Cleaning the Exterior:** Wipe the polypropylene shell with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners.
- **Cleaning the Interior:** Spot clean the interior lining with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheels and Handle:** Periodically check wheels for debris and clean as necessary. Ensure the telescopic handle extends and retracts smoothly. Do not force a stuck handle.
- **Zippers:** Keep zippers free of dirt and debris. Lubricate with a zipper lubricant if they become stiff.

Troubleshooting

- **Stuck Telescopic Handle:** Ensure no items are obstructing the handle mechanism inside the lining. Gently wiggle the handle while pressing the release button. Do not apply excessive force.
- **Stiff Wheels:** Check for hair, lint, or other debris caught in the wheel axles. Clean thoroughly. If wheels remain stiff, contact customer support.
- **Combination Lock Issues:** If you forget your combination, there is no master reset. You may need to try combinations or contact Samsonite customer service for assistance.
- **Zipper Malfunction:** Ensure the zipper teeth are aligned. If a zipper is stuck, try applying a small amount of lubricant (e.g., graphite from a pencil) to the teeth.

Specifications

Feature	Detail
Model Name	Flux Spinner 68/25 Expandable Hand Luggage
Model Number	88538-1041
Brand	Samsonite
Material	Polypropylene
Dimensions (H x W x D)	68 cm x 34 cm x 47 cm (26.77 x 13.39 x 18.5 inches)
Weight	3.5 kg (7.7 pounds)
Capacity	85 Liters (expandable)
Wheels	4 Double Spinner Wheels
Lock Type	Integrated TSA Combination Lock



Image: A size comparison chart illustrating different Samsonite luggage sizes (S, M, L, XL) with their approximate heights and recommended trip durations. This visual aid helps users understand the relative size of the 68 cm (M) luggage.

Warranty and Support

Samsonite products are manufactured to stringent standards and undergo rigorous quality control. In the unlikely event of a defect in material or workmanship, Samsonite offers a limited global warranty.
For detailed warranty information, to register your product, or for customer support, please visit the official Samsonite website or contact their customer service department. Keep your proof of purchase for warranty claims.
Official Samsonite Website: www.samsonite.com

© 2025 Samsonite. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question