AEG MBE2658D-M

AEG MBE2658D-M Integrated Microwave Oven User Manual

Model: 947 608 679

Introduction

This user manual provides essential information for the safe and efficient operation, installation, and maintenance of your AEG MBE2658D-M Integrated Microwave Oven. Please read this manual thoroughly before using the appliance and keep it for future reference.

Safety Information

Always adhere to the following safety precautions to prevent electric shock, fire, or injury:

- Do not operate the oven if the door is damaged or if the seals are worn.
- Ensure proper ventilation around the appliance.
- Only use microwave-safe cookware.
- Do not heat sealed containers, as they may explode.
- Supervise children when the appliance is in use.

Product Overview



Figure 1: Front view of the AEG MBE2658D-M Integrated Microwave Oven, showing the black glass door, control panel with digital display, and touch controls. The AEG logo is visible at the bottom.

The AEG MBE2658D-M is a 26-liter integrated microwave oven designed for seamless integration into your kitchen cabinetry. It features a sleek black and grey finish with touch controls and a digital display for precise operation. With 900 watts of power, it is suitable for various cooking and reheating tasks.

Setup and Installation

This appliance is designed for built-in installation. Professional installation is recommended to ensure proper fit and electrical connection.

Unpacking

1. Carefully remove all packaging materials.
2. Inspect the oven for any damage. Do not install if damaged.
3. Retain packaging for future transport or service.

Electrical Connection

The oven operates on 230 Volts. Ensure the electrical supply matches the appliance's requirements. A dedicated circuit is recommended.

Mounting

Refer to the separate installation template and instructions provided with the appliance for precise cabinet cutout

dimensions and mounting procedures. Ensure adequate ventilation space as specified.

Operating Instructions

Control Panel Overview

The control panel features a digital display and touch-sensitive buttons for various functions. The main rotary knob allows for time and power level adjustments.

Setting the Time

1. Press the **Clock** button.
2. Use the rotary knob to set the hour.
3. Press the **Clock** button again.
4. Use the rotary knob to set the minutes.
5. Confirm by pressing the **Clock** button or waiting a few seconds.

Microwave Cooking

1. Place food in a microwave-safe dish and put it inside the oven.
2. Close the oven door securely.
3. Select the desired power level (e.g., 900W for full power) using the **Power** button or touch controls.
4. Set the cooking time using the rotary knob.
5. Press the **Start** button to begin cooking.

Defrost Function

The oven features a manual defrost function. For best results, turn food over halfway through the defrosting process.

1. Press the **Defrost** button.
2. Enter the weight of the food or desired defrost time using the rotary knob.
3. Press **Start**.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your microwave oven.

Interior Cleaning

- Wipe the interior with a damp cloth and mild detergent after each use.
- For stubborn stains, place a bowl of water with lemon slices inside and microwave for 2-3 minutes to loosen residue.
- Do not use abrasive cleaners or metal scouring pads.

Exterior Cleaning

Clean the exterior surfaces with a soft, damp cloth. For stainless steel parts, use a specialized stainless steel cleaner.

Turntable Care

The glass turntable can be removed for cleaning and is dishwasher safe.

Troubleshooting

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly; Power outage; Fuse blown.	Ensure door is fully closed; Check power supply; Check household fuse/circuit breaker.
Food not heating	Incorrect power level/time set; Microwave-safe dish not used.	Adjust power and time; Use appropriate cookware.
Unusual noise during operation	Turntable not correctly placed; Food item touching oven walls.	Re-position turntable; Ensure food clears oven interior.

If the problem persists after attempting these solutions, please contact qualified service personnel.

Specifications

Feature	Detail
Brand	AEG
Model Name	MBE2658D-M
Model Number	947 608 679
Capacity	26 Liters
Wattage	900 watts
Voltage	230 Volts
Installation Type	Built-In
Product Dimensions (L x W x H)	23.46 x 15.91 x 18.07 inches
Item Weight	39.7 pounds (18000 Grams)
Color	Black Gray
Material Type	Stainless Steel Glass
Inner Material Type	Stainless Steel
Controller Type	Touch
Human Interface Input	Touchscreen
Noise Level	60 dB
Oven Cooking Mode	Microwave Radiation
Defrost Type	Manual Defrost

Warranty and Support

This AEG appliance comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. For technical support, service, or to inquire about replacement parts, please

visit the official AEG website or contact their customer service department. Keep your proof of purchase for warranty claims.

Note: Warranty details and support contact information may vary by region.

© 2024 AEG. All rights reserved.
This manual is for informational purposes only and is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question