DreamSky 4330349659

DreamSky Digital Alarm Clock Radio User Manual

Model: 4330349659
Brand: DreamSky

Introduction

Thank you for purchasing the DreamSky Digital Alarm Clock Radio. This manual provides detailed instructions for setting up, operating, and maintaining your new device. Please read this manual thoroughly before use to ensure proper function and to maximize your user experience.



Overview of key features: Time, Alarm, FM Radio, USB Port, Dimmer, Sleep Timer, and Earphone Jack.

Safety Information

- Do not expose the unit to rain or moisture to prevent fire or shock hazards.
- Do not expose the unit to direct sunlight or extreme temperatures.
- Ensure proper ventilation; do not block ventilation openings.
- Use only the power adapter supplied with the unit.
- Do not attempt to disassemble or modify the unit. Refer all servicing to qualified personnel.
- Keep away from strong magnetic fields.
- Dispose of batteries properly, following local regulations.

Package Contents

Please check the package for the following items:

- DreamSky Digital Alarm Clock Radio Unit
- Power Adapter
- User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your DreamSky Digital Alarm Clock Radio.



Front view of the DreamSky Digital Alarm Clock Radio.

Top Panel Controls:

- **SNOOZE/DIMMER/SLEEP Button:** Press to snooze alarm, long press to adjust display brightness, press repeatedly to set sleep timer.
- **ALARM Button:** Press to set alarm time, activate/deactivate alarm.
- **TIME Button:** Press to set current time.
- **RADIO Button:** Press to turn FM radio on/off.
- **+/- Buttons:** Adjust volume, tune radio frequency, set time/alarm.
- **AL ON/OFF Button:** Quickly turn alarm on or off.

Rear Panel Connections:

- **DC IN Jack:** For power adapter connection.
- **USB Charging Port:** For charging external devices.
- **3.5mm Headphone Jack:** For private listening.
- **Battery Compartment:** For backup batteries (2 x AAA, not included).

Setup

1. Power Connection

1. Insert the DC plug of the power adapter into the DC IN jack on the back of the unit.
2. Plug the power adapter into a standard AC wall outlet (100-240V, 50/60Hz).

3. The display will light up, indicating the unit is powered on.

2. Battery Backup Installation

The unit requires 2 x AAA batteries (not included) for backup power. These batteries maintain time and alarm settings during a power outage but do not power the clock display or functions.

1. Open the battery compartment cover on the bottom of the unit.
2. Insert 2 AAA batteries, observing the correct polarity (+ and -) as marked inside the compartment.
3. Close the battery compartment cover securely.

3. Initial Time Setting

1. Press and hold the **TIME** button for 3 seconds. The hour digits will start flashing.
2. Use the **+/-** buttons to adjust the hour. Press **TIME** again to confirm the hour.
3. The minute digits will start flashing. Use the **+/-** buttons to adjust the minutes. Press **TIME** again to confirm the minutes.
4. Press **TIME** one more time to select 12-hour or 24-hour format. Use **+/-** to toggle. Press **TIME** to confirm.
5. The time is now set.

Operating Instructions

Setting the Alarm

1. Press and hold the **ALARM** button for 3 seconds. The alarm hour digits will flash.
2. Use the **+/-** buttons to adjust the alarm hour. Press **ALARM** again to confirm.
3. The alarm minute digits will flash. Use the **+/-** buttons to adjust the alarm minutes. Press **ALARM** again to confirm.
4. Select the alarm source: Use **+/-** to choose between **BUZZER** or **RADIO**. Press **ALARM** to confirm.
5. If RADIO is selected, use **+/-** to set the desired alarm volume (L01-L15). Press **ALARM** to confirm.
6. The alarm is now set and activated. A small alarm icon will appear on the display.

To activate/deactivate the alarm quickly, press the **AL ON/OFF** button. The alarm icon will appear/disappear.



The alarm function is designed for a gentle wake-up experience.

Using the Snooze Function

When the alarm sounds, press the large **SNOOZE/DIMMER/SLEEP** button on top. The alarm will pause for 9 minutes and then sound again. This can be repeated multiple times.
To cancel the snooze and turn off the alarm completely, press the **AL ON/OFF** button or any other button except SNOOZE.

FM Radio Operation

1. Press the **RADIO** button to turn the FM radio on. The current frequency will be displayed.
2. **Manual Tuning:** Press the **+/-** buttons briefly to adjust the frequency step by step.
3. **Auto Scan:** Press and hold the **+/-** buttons for 2 seconds to automatically scan for the next available station.
4. **Volume Adjustment:** While the radio is playing, press the **+/-** buttons to adjust the volume level.
5. To turn off the radio, press the **RADIO** button again.



Enjoy private listening using the 3.5mm headphone jack.

Sleep Timer Function

The sleep timer allows you to fall asleep to the radio, which will automatically turn off after a set period.

1. While the radio is playing, repeatedly press the **SNOOZE/DIMMER/SLEEP** button to cycle through sleep timer options: 10, 15, 30, 45, 60, 90, 120 minutes, or OFF.
2. The radio will play for the selected duration and then automatically turn off.

USB Charging Port Usage

The unit features a 5V/1A USB port for charging your mobile devices.

1. Connect your smartphone, tablet, or other USB-powered device to the USB port on the back of the alarm clock using a compatible USB cable (not included).
2. The device will begin charging automatically.



The integrated USB port allows convenient charging of your mobile devices.

Display Dimmer Adjustment

You can adjust the brightness of the LED display to suit your preference.

1. Press and hold the **SNOOZE/DIMMER/SLEEP** button for 3 seconds.
2. The display brightness will cycle between High and Low settings. Release the button when the desired brightness is reached.



Adjust the display brightness for comfortable viewing.

Headphone Jack Usage

For private listening of the FM radio, connect any standard 3.5mm headphones (not included) to the headphone jack on the back of the unit.
When headphones are connected, the built-in speaker will be muted.

Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the unit for an extended period, disconnect it from power and remove the backup batteries. Store in a cool, dry place.
- **Antenna:** The FM antenna is a wire at the back of the unit. For best reception, extend it fully and adjust its position.

Troubleshooting

Problem	Possible Cause	Solution
No display/Unit not powering on.	Power adapter not connected or faulty outlet.	Ensure power adapter is securely plugged into the unit and a working wall outlet.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm not activated or set incorrectly.	Check if the alarm icon is displayed. Re-set the alarm time and source. Ensure alarm volume is not set to L00 if using radio alarm.
Poor FM radio reception.	Antenna not extended or interference.	Fully extend the FM wire antenna and try repositioning it. Move the unit away from other electronic devices that may cause interference.
USB charging not working.	Device not compatible or cable faulty.	Ensure your device is compatible with 5V/1A charging. Try a different USB cable.
Time/settings lost after power outage.	Backup batteries not installed or drained.	Install 2 new AAA batteries in the battery compartment.

Specifications

Feature	Detail
Brand	DreamSky
Model Number	4330349659
Display Type	Digital LED (1.8 inch)
Power Source	Corded Electric, Battery Powered (2 x AAA for backup)
USB Charging Output	5V/1A
Radio Frequency	FM
Dimensions (L x W x H)	8.2 x 4 x 1.7 inches
Item Weight	0.64 ounces (approx. 18.14 g)
Material	Plastic



Product dimensions for the DreamSky Digital Alarm Clock Radio.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided by your retailer or visit the official DreamSky website. Keep your purchase receipt for warranty claims.

DreamSky Store: https://www.amazon.com/stores/DreamSky/page/A77B43AC-E42E-451A-A58D-8BE8A4B441B5

© 2024 DreamSky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question