Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AVI-8 AV-4052-05

AVI-8 Hawker Hunter Retrograde Chronograph Watch

Brand: AVI-8

Model: AV-4052-05

Introduction

The AVI-8 Hawker Hunter Retrograde Chronograph is a meticulously designed timepiece that pays homage to the iconic Hawker Hunter jet. Inspired by the collaboration between pilots and engineers, this watch brings the essence of military aviation to your wrist. It combines robust construction with precise Japanese Quartz movement, offering both functionality and a distinctive aesthetic.

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your AVI-8 Hawker Hunter watch, ensuring you can fully enjoy its features and maintain its performance.

Product Overview



Figure 1: Front view of the AVI-8 Hawker Hunter Retrograde Chronograph watch. This image showcases the watch's black case, black dial with textured details, and striking blue hour markers and hands. The three sub-dials for chronograph functions are clearly visible, along with the date window at the 4 o'clock position. The watch features a black leather strap with blue stitching.



Figure 2: Side view of the AVI-8 Hawker Hunter watch. This perspective highlights the robust stainless steel case and the design of the crown and chronograph pushers on the right side of the watch. The texture of the leather strap is also visible.



Figure 3: Close-up of the AVI-8 Hawker Hunter watch face. This detailed view emphasizes the intricate dial design, including the retrograde minute sub-dial, the 24-hour sub-dial, and the small seconds sub-dial. The luminous hands and markers are also visible, along with the AVI-8 branding.

Setup

1. Initial Inspection

Upon unboxing your AVI-8 Hawker Hunter watch, carefully inspect it for any signs of damage. Ensure all protective films are removed from the crystal and case back.

2. Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to its outermost position. This will stop the second hand.
2. **Set the time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time. When setting the time, ensure you differentiate between AM and PM, especially when setting the date. The date will change around midnight.
3. **Set the date:** Push the crown in one click to the middle position. Rotate the crown to adjust the date. If the date changes during the day, adjust it to the previous day, then pull the crown out to the outermost position and advance the time past midnight until the correct date is displayed. Continue to set the correct time.
4. **Push in the crown:** Once the time and date are set, push the crown back into its original position against the watch case. The second hand will resume movement.

Note: Avoid setting the date between 9:00 PM and 3:00 AM, as this can damage the date mechanism. If you need to set the date within this period, first set the time outside this window, adjust the date, and then reset the time.

Operating the Chronograph

Your AVI-8 Hawker Hunter watch features a Japanese Quartz Chronograph movement with a 10-minute retrograde function. The chronograph allows you to measure elapsed time independently of the main time display.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and design of the AVI-8 Hawker Hunter watch. This video provides a dynamic view of the watch's face, case, and strap, highlighting its intricate details and overall aesthetic. It showcases the watch from various angles, giving a comprehensive visual overview of the product.

Chronograph Functions:

- **Start/Stop Button:** The pusher located at the 2 o'clock position (top right) is used to start and stop the chronograph.
- **Reset Button:** The pusher located at the 4 o'clock position (bottom right) is used to reset the chronograph hands to zero.
- **10-Minute Retrograde Sub-dial:** This sub-dial, typically located at the 9 o'clock position, measures elapsed minutes up to 10 minutes. Once it reaches 10 minutes, the hand will instantly snap back to zero and begin counting again.
- **24-Hour Sub-dial:** This sub-dial, typically located at the 3 o'clock position, displays time in a 24-hour format, useful for tracking AM/PM.
- **Small Seconds Sub-dial:** This sub-dial, typically located at the 6 o'clock position, displays the continuous running seconds for the main timekeeping.

How to Use:

1. **To Start:** Press the 2 o'clock pusher once. The chronograph hands will begin to move, measuring elapsed time.
2. **To Stop:** Press the 2 o'clock pusher again. The chronograph hands will stop, indicating the elapsed time.
3. **To Reset:** After stopping the chronograph, press the 4 o'clock pusher. All chronograph hands will instantly return to their zero positions.
4. **Intermediate Time Measurement (Split Time):** This model may not support split time. Refer to the specific movement manual if this feature is desired.

Maintenance and Care

Proper care will ensure the longevity and performance of your AVI-8 Hawker Hunter watch.

- **Water Resistance:** Your watch has a water resistance of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, but not for diving or prolonged water immersion. Avoid operating the crown or pushers when the watch is wet.
- **Cleaning:** Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean the leather strap with a damp cloth and mild soap if necessary, then allow it to air dry completely.
- **Temperature Extremes:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement and seals.
- **Magnetic Fields:** Keep your watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones), as these can affect the accuracy of the quartz movement.
- **Battery Replacement:** The watch is powered by a product-specific battery. When the battery runs low, the second hand may jump in 2-second intervals as an End-of-Life (EOL) indicator. Battery replacement should be performed by a qualified watchmaker to ensure proper sealing and function.

Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low battery.	Replace the battery. Contact a qualified watchmaker.
Time is incorrect.	Time not set correctly; exposure to strong magnetic fields.	Reset the time as per "Setting the Time and Date" section. Keep watch away from magnetic sources.
Date does not change at midnight.	AM/PM not set correctly.	Advance the time by 12 hours.
Chronograph hands do not reset to zero.	Requires calibration.	Consult a watch repair specialist for calibration.
Condensation inside the crystal.	Water ingress; sudden temperature change.	Immediately take the watch to a qualified watchmaker for inspection and repair to prevent further damage.

Specifications

Feature	Detail
Model Number	AV-4052-05
Movement	Japanese Quartz Chronograph with 10 Minutes Retrograde and Date
Case Material	Stainless Steel
Case Diameter	45mm
Strap Material	Genuine Leather (22mm)
Lens Material	Mineral with Anti-Reflective Coating

Feature	Detail
Water Resistance	50m (5 ATM)
Product Dimensions	4.72 x 4.72 x 4.72 inches; 3.53 ounces
Battery	1 Product Specific battery (included)

Warranty and Support

International Warranty

Your AVI-8 watch is warranted against any manufacturing defect for a period of**twenty-four (24) months** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.
To claim warranty service, please retain your proof of purchase. For detailed warranty terms and conditions, please refer to the official AVI-8 website or contact customer support.

Customer Support

For any questions, technical assistance, or service requests not covered by this manual, please contact AVI-8 customer support through their official website or authorized service centers. Please have your model number (AV-4052-05) and purchase details ready when contacting support.
Official Website: www.avi-8.co.uk

© 2025 AVI-8. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0722RB7HX

More documents and user manuals: **https://manuals.plus/**