GOJOOASIS 10' x 30' with 8 Walls

GOJOOASIS 10' x 30' White Canopy Tent Instruction Manual

Model: 10' x 30' with 8 Walls | Brand: GOJOOASIS

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your GOJOOASIS 10' x 30' White Canopy Tent. Designed for temporary outdoor events, this tent offers ample space and protection. Please read all instructions carefully before setup to ensure safe and correct usage.

Key Features:

- Spacious design, seating 20 to 30 people with tables and chairs.
- High-quality double-stitched 110g Polyethylene Cover.
- Durable 0.5/0.6mm steel tube frame.
- Water-resistant and blocks 90% UV sun rays.
- Easy and fast setup by 4+ people.



Image: Close-up view of the tent's waterproof polyethylene fabric, demonstrating its water-resistant properties with water droplets visible on the surface.

Important Safety Information

- This product is designed for garden and leisure events in**GOOD weather conditions only**.
- **DO NOT** use or leave set up in windy or adverse weather conditions, including heavy rain.
- In rainy conditions, ensure no water accumulates on the top, as this may cause the tent to collapse.
- Assembly requires at least 4 people for safe and efficient setup.
- Always secure the tent properly with all provided hardware (ropes, stakes) to prevent movement.

Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged. Refer to the assembly diagram for part identification.



Image: A six-panel diagram illustrating the sequential assembly of the tent's metal frame, starting from laying out poles on the ground to forming the complete roof structure.

Components List:

Part No.	Description	Quantity
1	Long Straight Pole	8
2	Medium Straight Pole	4
3	Short Straight Pole	16
4	Corner Pole	8
5	Vertical Leg Pole	8
6	Roof Ridge Pole	8
7	Roof Corner Connector	2
8	Roof Middle Connector	3
9	Peak Connector	1
10	Foot Pad	4
11	Ground Stakes & Ropes	16

Part No.	Description	Quantity
-	Roof Cover	1
-	Sidewalls with Windows	8

Setup Instructions

Follow these steps for a smooth and secure assembly of your canopy tent. It is recommended to have at least 4 people for assembly.

Step 1: Assemble the Top Frame

Lay out the numbered poles on a flat surface. Connect the poles according to the provided diagram to form the rectangular top frame of the tent. Ensure all connections are secure.



Image: A six-panel diagram illustrating the sequential assembly of the tent's metal frame, starting from laying out poles on the ground to forming the complete roof structure.

Your browser does not support the video tag.

Video: "Party Tent Installation for Beginners" - This video demonstrates the step-by-step process of assembling the tent's frame, including connecting poles and raising the structure.

Step 2: Attach the Roof Cover

Carefully drape the roof cover over the assembled top frame. Ensure it is centered and evenly distributed. Secure the cover to the frame using the integrated ties or fasteners.



Image: A close-up view of a tent pole connection, highlighting the secure and stable joint of the frame components.

Step 3: Install Vertical Legs and Foot Pads

Attach the vertical leg poles to the top frame. Slide the foot pads onto the bottom of each vertical leg. Insert ground nails through the foot pads to secure the tent to the ground. Fasten ropes to the tent's grommets and secure them with additional ground nails for extra stability.

Your browser does not support the video tag.

Video: "10'x30' White Outdoor Gazebo Canopy Wedding Party Tent" - This video provides a visual guide to the full assembly process, including securing the tent to the ground.

Step 4: Attach Sidewalls

The tent includes 8 removable sidewalls with windows. Attach these to the tent frame using the integrated Velcro straps or ties. You can customize the placement of the sidewalls to suit your needs, creating enclosed spaces or open entrances.



Image: An exterior shot of the fully assembled 10' x 30' canopy tent, showcasing all 8 sidewalls with their distinctive arched window designs.

Your browser does not support the video tag.

Video: "10x30 party tent with Mesh Window" - This video highlights the installation of sidewalls, including those with mesh windows, demonstrating how to secure them to the tent structure.

Operating Instructions

Your GOJOOASIS canopy tent is designed for temporary use during outdoor events. It provides shade and shelter from

light weather conditions.

General Use:

- Ensure the tent is always securely anchored to the ground using all provided stakes and ropes.
- Periodically check all connections and anchors to ensure they remain tight and secure, especially during prolonged use.
- The sidewalls can be opened or closed as needed for ventilation or privacy.



Image: An interior perspective of the 10' x 30' canopy tent, highlighting the expansive covered area and the underlying roof frame structure.

Weather Considerations:

- This tent is not intended for permanent installation.
- In anticipation of strong winds, heavy rain, or snow, the tent should be disassembled and stored to prevent damage or injury.
- Do not use in windy or rainy conditions. Do not leave set up in adverse weather for several days.

Maintenance

- **Cleaning:** Clean the tent fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the fabric to dry completely before storage to prevent mildew.
- **Storage:** Disassemble the tent and store all components in a dry, cool place away from direct sunlight when not in use.
- **Inspection:** Regularly inspect poles, connectors, fabric, ropes, and stakes for any signs of wear or damage. Replace damaged parts immediately.

Troubleshooting

Tent Stability Issues:

- Ensure all poles are fully inserted into their connectors and clips are engaged.
- Verify that all ground stakes are firmly driven into the ground and ropes are taut.
- If the ground is soft, consider using sandbags or weights on the foot pads for additional stability.

Water Accumulation on Roof:

- This indicates improper setup or use in unsuitable weather. Immediately remove any accumulated water to prevent collapse.
- Ensure the roof cover is stretched tightly and evenly across the frame to prevent sagging.

For further assistance or replacement parts, please contact GOJOOASIS customer support.

Specifications

Feature	Detail
Brand	GOJOOASIS
Model	10' x 30' with 8 Walls
Material	Alloy Steel (Frame), 110g Polyethylene (Cover)
Color	White
Recommended Uses	Camping, Outdoor Activities, Party
UV Protection	Blocks 90% UV sun rays
Water Resistance Level	Water Resistant
Pole Material Type	Alloy Steel, Metal
Number of Guylines	16
Frame Type	Steel
Assembly Required	Yes
Product Dimensions	120 x 120 x 120 inches (Note: This seems to be a generic cube dimension, actual tent is 10'x30')
Item Weight	58.6 pounds
UPC	709586410523

Warranty & Support

GOJOOASIS honors its customers with replacement parts for anything they need. Please do not hesitate to message if any problem arises.

- **Returns:** 30-day easy returns.
- **Customer Support:** For any issues or inquiries, please contact the seller directly.

For more information, visit the GOJOOASIS Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question