Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T'nB HPRECV1GR

T'nB HPRECV1GR Record Bluetooth 4.1 Speaker User Manual

Model: **HPRECV1GR** | Brand: **T'nB**

1. Introduction

Thank you for purchasing the T'nB HPRECV1GR Record Bluetooth 4.1 Speaker. This compact and elegant speaker is designed to provide high-quality audio and hands-free calling capabilities. With its classic car ambiance and fabric design, it offers both style and functionality. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance.

2. Safety Information

Please read all safety warnings and instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Do not immerse the speaker in water or any other liquids. This product is not waterproof.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Use only the specified charging cable and power source.
- Keep the speaker away from children and pets.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.

3. Package Contents

Please check the contents of your package. If any items are missing or damaged, contact your retailer.

- T'nB HPRECV1GR Record Bluetooth Speaker
- USB Charging Cable
- User Manual (this document)

4. Product Overview

Familiarize yourself with the various parts and controls of your T'nB HPRECV1GR speaker.



Figure 4.1: Angled view of the T'nB HPRECV1GR speaker, showing the fabric grille and side controls.



Figure 4.2: Top view of the speaker, highlighting the compact square design and fabric finish.



Figure 4.3: Rear view displaying the Micro USB charging port, AUX-in port, and the On/Off switch.



Figure 4.4: Side view showing the control buttons: Volume Up (+), Play/Pause/Call (center), and Volume Down (-).

Controls and Ports:

- **Power Switch:** Located at the rear, slides to turn the speaker On or Off.
- **Micro USB Port:** For charging the speaker.
- **AUX In Port:** For wired audio connection using a 3.5mm audio cable (not included).

- **Volume Up (+) Button:** Increases volume.
- **Play/Pause/Call Button:** Controls music playback and manages phone calls.
- **Volume Down (-) Button:** Decreases volume.
- **Integrated Microphone:** For hands-free calling.

5. Setup

5.1 Charging the Speaker

Before first use, fully charge the speaker. A full charge provides approximately 5 hours of playback time.

1. Connect the small end of the USB charging cable to the Micro USB port on the rear of the speaker.
2. Connect the large end of the USB charging cable to a USB power adapter (e.g., smartphone charger, computer USB port) or a wall charger (5V/1A recommended).
3. The charging indicator light (if present, typically red) will illuminate during charging and turn off or change color when fully charged.
4. Charging time may vary. Disconnect the cable once charging is complete.

5.2 Bluetooth Pairing

Pair your speaker with a Bluetooth-enabled device (smartphone, tablet, etc.) to stream audio wirelessly.

1. Ensure the speaker is fully charged.
2. Slide the Power Switch on the rear of the speaker to the "ON" position. The speaker will enter Bluetooth pairing mode, indicated by a flashing LED light (color/pattern may vary).
3. On your device, enable Bluetooth and search for new devices.
4. Select "HPRECV1GR" or a similar name from the list of available devices.
5. Once paired, the speaker will emit a confirmation sound, and the LED indicator will stop flashing and remain solid.
6. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range (up to 10 meters) and Bluetooth is enabled.

5.3 AUX Connection (Wired Audio)

You can also connect the speaker to audio devices without Bluetooth capability using a 3.5mm audio cable (not included).

1. Connect one end of a 3.5mm audio cable to the AUX In port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output port of your device.
3. The speaker will automatically switch to AUX mode.

6. Operating Instructions

6.1 Power On/Off

- To turn on: Slide the Power Switch to the "ON" position.
- To turn off: Slide the Power Switch to the "OFF" position.

6.2 Music Playback (Bluetooth Mode)

- **Play/Pause:** Press the Play/Pause/Call button once.
- **Volume Up:** Press the (+) button.

- **Volume Down:** Press the (-) button.
- *Note: Track skipping functionality is not explicitly mentioned in product data, so assume basic playback controls.*

6.3 Hands-Free Calling

With the integrated microphone, you can answer calls directly through the speaker when connected via Bluetooth.

- **Answer Call:** When a call comes in, press the Play/Pause/Call button once.
- **End Call:** During a call, press the Play/Pause/Call button once.
- **Reject Call:** Press and hold the Play/Pause/Call button for approximately 2 seconds.

7. Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- Avoid dropping the speaker or subjecting it to strong impacts.
- If the speaker will not be used for an extended period, charge it at least once every three months to preserve battery life.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device's Bluetooth is off; Speaker is too far from device.	Ensure speaker is on and flashing (pairing mode); Turn on Bluetooth on your device; Move speaker closer to device (within 10m).
No sound from speaker.	Volume is too low; Device is not connected; Incorrect input mode.	Increase volume on both speaker and device; Ensure successful Bluetooth pairing or AUX connection; Check if speaker is in correct mode (Bluetooth/AUX).
Short battery life.	Battery degradation; High volume usage.	Ensure speaker is fully charged before use. Battery life can be affected by volume levels. If issue persists, contact support.

9. Specifications

Feature	Detail
Model Number	HPRECV1GR
Brand	T'nB
Connectivity Technology	Bluetooth 4.1

Wireless Range	Up to 10 meters (33 feet)
Speaker Output Power	4 Watts
Battery Life	Approximately 5 hours
Battery Type	1 Lithium-ion (included)
Integrated Microphone	Yes
Compatible Devices	Tablets, Smartphones
Audio Output Mode	Mono
Impedance	4 Ohms
Dimensions (L x W x H)	7 x 7 x 3.5 cm (2.76 x 2.76 x 1.38 inches)
Weight	112.9 grams (0.25 lbs)
Material	Plastic
Color	Grey

10. Warranty and Support

Specific warranty information for the T'nB HPRECV1GR Record Bluetooth Speaker is not provided in this document. For details regarding warranty coverage, returns, or technical support, please refer to the warranty card included with your product or contact the retailer or manufacturer directly.
Manufacturer: T'nB SA France
For further assistance, please visit the official T'nB website or contact their customer service.

11. Official Product Videos

No official product videos from the seller were available in the provided product data for embedding.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072J1JVM2

More documents and user manuals: **https://manuals.plus/**