Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Suptig RSX-161

Suptig LCD Screen RSX-161 Instruction Manual

Model: RSX-161 | Brand: Suptig

1. Product Overview

The Suptig 2.0 Inch LCD BacPac (Model RSX-161) is a non-touch display designed to enhance your GoPro camera experience. It allows users to view real-time images, preview photos and videos, and monitor battery life directly on the camera. This accessory is particularly useful for framing shots and reviewing footage in the field.



Image: Suptig LCD BacPac attached to a GoPro camera, showing live view.

1.1 Package Contents

- 1x Suptig LCD Screen (Model RSX-161)
- 2x BacPac Backdoors (for waterproof housing compatibility)
- 1x Microfiber Cleaning Cloth

1.2 Compatibility

This LCD BacPac is compatible with the following GoPro camera models:

- GoPro Hero 4 Black
- GoPro Hero 4 Silver
- GoPro Hero 3+
- GoPro Hero 3
- GoPro Hero 2

The screen is waterproof up to 114 ft (approximately 35 meters) when installed with the appropriate extended back cover and a compatible waterproof housing, making it suitable for diving, snorkeling, and other water activities.

2. Setup Instructions

Follow these steps to attach the Suptig LCD BacPac to your compatible GoPro camera:

1. **Prepare your GoPro camera:** Ensure your GoPro camera is powered off.
2. **Remove the standard waterproof housing back cover:** If your GoPro is in a waterproof housing, carefully remove its standard back cover.
3. **Attach the LCD BacPac:** Align the LCD BacPac with the expansion port on the back of your GoPro camera and firmly press it into place until it clicks securely.
4. **Select and install the appropriate extended BacPac backdoor:** Choose one of the provided extended BacPac backdoors that fits your waterproof housing with the LCD screen attached. This is crucial for maintaining the waterproof seal.
5. **Fasten the extended backdoor:** Securely close the waterproof housing with the extended backdoor. Ensure all latches are properly engaged to prevent water ingress.



Image: Installation steps for the LCD BacPac with waterproof housing.

For optimal performance, ensure the connection between the LCD BacPac and the camera is clean and free of debris before attachment.

3. Operating Instructions

Once the LCD BacPac is securely attached and your GoPro camera is powered on, the screen will automatically display the camera's live view or playback content.

- **Live View:** The screen provides a real-time display of what your GoPro camera is capturing, aiding in framing your shots accurately.
- **Playback:** You can review recorded photos and videos directly on the screen using your GoPro's playback controls.
- **Battery Monitoring:** The LCD screen will also display the camera's battery status, allowing you to monitor power levels during use.

This is a non-touch screen. All navigation and settings adjustments must be performed using the physical buttons on your GoPro camera.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Suptig LCD BacPac.

- **Cleaning:** Use the provided microfiber cleaning cloth to gently wipe the screen surface. Avoid abrasive materials or harsh chemicals that could scratch or damage the display.
- **Storage:** When not in use, store the LCD BacPac in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Waterproof Seals:** Regularly inspect the rubber seals on the extended BacPac backdoors for any signs of wear or damage. Replace them if necessary to maintain the waterproof integrity.
- **Connector Care:** Keep the electrical connector pins on the back of the LCD BacPac clean and dry. Avoid touching them directly to prevent corrosion or damage.

5. Troubleshooting

If you encounter issues with your Suptig LCD BacPac, consider the following:

- **Screen Not Displaying:**
  - Ensure the LCD BacPac is securely attached to the GoPro camera's expansion port.
  - Verify that the GoPro camera is powered on and functioning correctly.
  - Check the camera's settings to ensure external display output is enabled, if applicable.
- **Image Quality Issues:**
  - Clean the screen surface with the microfiber cloth to remove smudges or dust.
  - Ensure the camera lens is clean.
- **Water Leakage (when used with waterproof housing):**
  - Confirm that the correct extended BacPac backdoor is used and properly sealed.
  - Inspect the backdoor's rubber gasket for any damage or debris.
  - Ensure the waterproof housing latches are fully secured.

If problems persist, refer to your GoPro camera's user manual or contact Suptig customer support.

6. Specifications

Suptig LCD Screen RSX-161 Technical Specifications

Feature	Detail
Model Number	RSX-161
Brand	Suptig
Screen Size	2 Inches
Resolution	320(rgb)x240dot (Native: 320 x 240 Pixels)

Feature	Detail
Aspect Ratio	4:3
Screen Surface Description	Glossy
Refresh Rate	60 Hz
Display Type	LCD
Viewing Angle	6 Degrees
Color Screen	Yes (262K High Contrast)
Item Dimensions (L x W x H)	5.79 cm x 3.99 cm x 0.99 cm (2.28 in x 1.57 in x 0.39 in)
Item Weight	32 g (1.13 ounces)
Voltage	5 Volts (DC)
Connectivity Technology	DisplayPort
Hardware Connectivity	USB
Specific Uses	Action sports and outdoor activities
Color	Black
Waterproof Depth	Up to 114 ft (35 meters) with extended back cover



Image: Dimensions of the Suptig LCD BacPac (Length: 2.28 inches, Width: 1.57 inches, Height: 0.39 inches).

7. Warranty and Support

For warranty information and customer support, please contact Suptig directly. The manufacturer's contact information is provided below:

Manufacturer: Suptig

Address: BRIGHTON, CO 80601, US

Please retain your proof of purchase for any warranty claims.

© 2024 Suptig. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072K25157

More documents and user manuals: **https://manuals.plus/**