Ingersoll I04604

Ingersoll Hawley I04604 Automatic Watch User Manual

Model: I04604

Introduction

This manual provides detailed instructions for the proper use, care, and maintenance of your Ingersoll Hawley I04604 Automatic Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece. The Ingersoll Hawley I04604 is an analog automatic watch featuring a stainless-steel case, a black leather strap, and a grey dial. It is water-resistant up to 50 meters.

Product Overview

Familiarize yourself with the main components of your Ingersoll Hawley I04604 watch.



Image 1: Front view of the Ingersoll Hawley I04604 Automatic Watch, showing the grey dial, hands, and black leather strap.

- **Crown:** Used for winding the watch and setting the time/date.

- **Dial:** Displays the time and date.
- **Hands:** Hour, minute, and second hands.
- **Case:** Stainless steel housing for the watch movement.
- **Strap:** Black leather strap with a deployment buckle.

Setup and Initial Winding

Your Ingersoll Hawley I04604 is an automatic watch, meaning it is powered by the motion of your wrist. However, for initial setup or after a period of inactivity, manual winding is recommended.

1. **Unscrew the Crown (if applicable):** Some watches have a screw-down crown for enhanced water resistance. If your crown is screw-down, gently turn it counter-clockwise until it springs free.
2. **Manual Winding:** With the crown in its normal (pushed-in) position, turn it clockwise approximately 20-30 times. This will provide enough power reserve to start the watch.
3. **Setting the Time:**
    - Pull the crown out to the second click position.
    - Turn the crown to move the hands clockwise until the correct time is displayed.
    - Push the crown back into the normal position.
4. **Setting the Date (if applicable):**
    - Pull the crown out to the first click position.
    - Turn the crown clockwise or counter-clockwise (depending on the movement) to adjust the date.
    - *Avoid setting the date between 9 PM and 3 AM* as this can damage the date mechanism. If the time is within this range, first set the time outside this range, adjust the date, then reset the time.
    - Push the crown back into the normal position.
5. **Screw Down the Crown (if applicable):** If your crown is screw-down, push it in and turn it clockwise firmly until it is securely tightened against the case. This ensures water resistance.

Once set, the watch will continue to run as long as it is worn regularly. If unworn, it will stop after its power reserve is depleted (typically 36-40 hours) and will need to be re-wound and re-set.

Operating Your Watch

Wearing the Watch

Wear your Ingersoll Hawley I04604 watch daily to keep it wound. The natural motion of your wrist will power the automatic movement.

Deployment Buckle Operation

The watch features a deployment buckle for secure and comfortable wear.

1. **Opening:** Press the buttons on the sides of the buckle to release the clasp.
2. **Closing:** Fold the clasp over until it clicks securely into place.
3. **Adjusting Length:** The strap length can be adjusted by moving the pin on the buckle to a different hole on the leather strap. Ensure a snug but comfortable fit.

Water Resistance (50 meters / 5 ATM)

Your watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands.

- **Do NOT** operate the crown or pushers while the watch is wet or submerged.
- **Do NOT** expose the watch to hot water or steam (e.g., hot showers, saunas), as this can compromise the water seals.
- Ensure the crown is always fully pushed in and, if applicable, screwed down, before exposing the watch to water.

Maintenance and Care

Proper care will help maintain the appearance and functionality of your Ingersoll Hawley I04604 watch.

- **Cleaning:** Wipe the watch case and crystal with a soft, dry, lint-free cloth. For the leather strap, avoid excessive moisture and clean with a specialized leather cleaner if necessary.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme hot or cold temperatures, or sudden temperature changes.
- **Avoid Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetics, as these can damage the case, strap, and seals.
- **Magnetic Fields:** Automatic watches can be affected by strong magnetic fields (e.g., from speakers, refrigerators, certain electronic devices). Keep your watch away from such sources to maintain accuracy.
- **Leather Strap Care:** Leather straps are susceptible to wear and tear from moisture, sweat, and sunlight. Avoid prolonged exposure to water and direct sunlight. Replace the strap if it shows signs of significant wear.
- **Servicing:** It is recommended to have your automatic watch serviced by a qualified watchmaker every 3-5 years to ensure its continued accuracy and water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Insufficient power reserve.	Manually wind the watch by turning the crown clockwise 20-30 times. Wear the watch regularly.
Watch runs too fast or too slow.	Exposure to strong magnetic fields; needs regulation.	Keep away from magnetic sources. If problem persists, consult a qualified watchmaker for demagnetization or regulation.
Date does not change or changes at the wrong time.	Incorrect date setting procedure; mechanism damage.	Ensure date is not set between 9 PM and 3 AM. If issue persists, seek professional service.
Condensation under the crystal.	Water resistance compromised.	Immediately take the watch to a qualified watchmaker for inspection and repair to prevent further damage.

Specifications

Feature	Detail
Model Number	I04604
Movement Type	Automatic
Display Type	Analog

Feature	Detail
Case Material	Stainless Steel
Case Diameter	44 mm
Case Thickness	15 mm
Band Material	Leather
Band Color	Black
Dial Color	Grey
Water Resistance Depth	50 Meters (5 ATM)
Clasp Type	Deployment Clasp
Item Weight	121 Grams
Additional Features	Date display (Datum)

Warranty and Support

For warranty information and customer support, please refer to the official Ingersoll website or contact your authorized retailer. Keep your purchase receipt as proof of purchase.

Manufacturer: Ingersoll

Model Number: I04604

© 2026 Ingersoll. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question