Holstein Housewares HF-09036R

Holstein Housewares HF-09036R Waffle Bowl Maker User Manual

Model: HF-09036R

Introduction

Thank you for purchasing the Holstein Housewares HF-09036R Waffle Bowl Maker. This appliance is designed to create two delicious waffle bowls simultaneously, perfect for a variety of sweet and savory fillings. Please read this manual thoroughly before first use to ensure safe and efficient operation.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Features

- **Dual Waffle Bowl Capacity:** Makes two waffle bowls simultaneously.
- **Non-Stick Coating:** Ensures easy food release and simplifies cleaning.
- **Durable Construction:** Features a rust-resistant stainless steel upper housing.
- **Compact Design:** Allows for space-saving vertical storage.
- **Indicator Lights:** Power and ready indicator lights for optimal cooking.



The Holstein Housewares Waffle Bowl Maker features a compact design for convenient vertical storage.

Setup

1. **Unpacking:** Carefully remove the waffle bowl maker and all packaging materials. Retain packaging for future storage or transport if needed.

2. **Initial Cleaning:** Before first use, wipe the non-stick cooking plates with a damp cloth or sponge. Dry thoroughly. The exterior can be wiped with a damp cloth. Do not immerse the appliance in water.
3. **Placement:** Place the appliance on a stable, heat-resistant, and dry surface, away from water sources and flammable materials. Ensure adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. The power indicator light will illuminate.

Operating Instructions

1. **Preheating:** Close the lid and plug in the appliance. The power indicator light will turn on. Allow the unit to preheat until the ready indicator light illuminates, typically 3-5 minutes.
2. **Preparing Batter:** Prepare your favorite waffle batter. For best results, use a batter that is not too thick or too thin.
3. **Adding Batter:** Once preheated, carefully open the lid. Pour approximately 1/4 to 1/3 cup of batter into each waffle bowl cavity. Do not overfill, as batter may overflow during cooking.
4. **Cooking:** Close the lid. The ready indicator light may turn off during cooking and then re-illuminate when the waffle bowls are done. Cooking time typically ranges from 3-6 minutes, depending on the batter and desired crispness.
5. **Checking Doneness:** You can carefully lift the lid to check the waffle bowls. If they are golden brown and crisp, they are ready.
6. **Removing Waffle Bowls:** Use a heat-resistant, non-metallic utensil (e.g., plastic or wooden spatula) to carefully remove the cooked waffle bowls from the non-stick plates. Do not use metal utensils, as they can damage the non-stick coating.
7. **Repeat:** Close the lid to allow the unit to reheat for the next batch, if necessary.



The non-stick coating ensures easy release of waffle bowls and simplifies the cleaning process.



The appliance makes two waffle bowls in minutes, ready to be filled with your favorite ingredients.

Cleaning and Maintenance

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Cleaning Plates:** Wipe the non-stick cooking plates with a damp cloth or sponge. For stubborn residue, a small amount of cooking oil can be applied to soften it before wiping. Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.
3. **Exterior Cleaning:** Wipe the exterior housing with a soft, damp cloth. Do not immerse the appliance in water or any other liquid.
4. **Storage:** Once clean and dry, the waffle bowl maker can be stored vertically to save space. Ensure the cord is neatly wrapped.

Troubleshooting

Problem	Possible Cause	Solution
Waffle bowls stick to plates.	Plates not properly seasoned or insufficient oil/butter in batter.	Lightly brush cooking plates with cooking oil before each use. Ensure batter contains adequate fat.
Waffle bowls are not crisp.	Insufficient cooking time or batter too thin.	Increase cooking time slightly. Adjust batter consistency if too thin.
Waffle bowls are too dark/burnt.	Excessive cooking time or batter contains too much sugar.	Reduce cooking time. Adjust sugar content in batter if necessary.
Batter overflows.	Too much batter added.	Reduce the amount of batter. Start with 1/4 cup per cavity and adjust as needed.

Specifications

Model Number: HF-09036R

Brand: Holstein Housewares

Color: Red - Stainless Steel

Material: Stainless Steel

Special Feature: Non-Stick Coating

Included Components: Waffle Bowl Maker

Product Dimensions: 9.44 x 4.37 x 9.21 inches (L x W x H)

Item Weight: 3.8 Pounds

UPC: 813966023828

GTIN: 813966023828

Warranty and Support

This Holstein Housewares HF-09036R Waffle Bowl Maker comes with a limited warranty. For specific warranty details, terms, and conditions, please refer to the warranty card included with your purchase or contact Holstein Housewares customer support directly.

For technical assistance, troubleshooting, or to inquire about replacement parts, please visit the official Holstein Housewares website or contact their customer service department.

Manufacturer: Holstein Housewares

Website: Visit Holstein Housewares Store on Amazon (for general brand information)

© 2023 Holstein Housewares. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question